ALLIMITY ZCM-ME688-398GR08WEPH01T-TGSF-CC

Allimity 398GR08WEPH01T Replacement Remote Control User Manual

Compatible with Philips Smart LCD LED TV

Introduction

Thank you for choosing the Allimity 398GR08WEPH01T Replacement Remote Control. This remote is designed to be compatible with various Philips Smart LCD LED TV models, offering a seamless replacement for your original remote. This manual will guide you through the setup, operation, and maintenance of your new remote control.

Setup

Battery Installation

The Allimity 398GR08WEPH01T remote control requires two AAA alkaline batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the markings inside the compartment. Incorrect insertion can prevent the remote from functioning.
4. Slide the battery cover back into place until it clicks securely.



Image: Rear view of the Allimity remote control with the battery cover removed, illustrating the battery insertion process. Ensure correct polarity when inserting batteries.

Initial Use

No pairing or programming is required for this replacement remote control. Once the batteries are correctly installed, the remote is ready for immediate use with compatible Philips Smart LCD LED TVs.

Operating Instructions

To ensure proper functionality, point the remote control directly at the IR sensor located on your television. Ensure that there are no objects blocking the path between the remote control and the TV's IR sensor.





Image: Front view of the Allimity 398GR08WEPH01T remote control, displaying its layout and various function buttons.

Key Functions

- **Power Button ( )**: Turns the TV on or off.
- **Navigation Pad (▲ ▼ ◀ ►) & OK Button**: Used to navigate menus and confirm selections.
- **Volume Up/Down (+/-)**: Adjusts the audio volume.
- **Channel Up/Down (+/-)**: Changes TV channels.
- **Mute Button ( )**: Mutes or unmutes the TV audio.
- **Home Button ( )**: Accesses the TV's main smart hub or home screen.
- **Back Button (↶)**: Returns to the previous screen or menu.
- **Source Button**: Selects input sources (HDMI, AV, etc.).
- **TV Guide Button**: Displays the electronic program guide.
- **Setup Button**: Accesses TV settings.
- **Info Button**: Displays information about the current program or input.
- **Colored Buttons (Red, Green, Yellow, Blue)**: Provide access to specific functions within smart TV applications or menus, as indicated on screen.

Maintenance

Battery Replacement

If the remote control becomes unresponsive or its range decreases, it is likely time to replace the batteries. Always replace both batteries simultaneously with new alkaline batteries of the same type (AAA). Do not mix old and new batteries, or different types of batteries.

Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the remote's finish or internal components.

Troubleshooting

If you experience issues with your Allimity replacement remote control, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Remote is not working or unresponsive.	Dead or incorrectly installed batteries.	Replace batteries with new alkaline AAA batteries, ensuring correct polarity.
Remote has limited range or intermittent response.	Low batteries; Obstruction between remote and TV sensor.	Replace batteries. Ensure a clear line of sight between the remote and the TV's IR sensor. Remove any objects blocking the signal.
Certain buttons do not function.	Remote may not be fully compatible with all TV functions; Button malfunction.	While designed for broad compatibility, some specific TV functions might not be supported. If multiple buttons fail, try replacing batteries.

Specifications

Feature	Detail
Model Number	ZCM-ME688-398GR08WEPH01T-TGSF-CC
Brand	ALLIMITY
Compatible Devices	Philips Smart LCD LED Television
Connectivity Technology	Infrared (IR)
Power Source	2 x AAA Batteries (not included)
Product Dimensions	7.02 x 0.6 x 2 inches (17.83 x 1.52 x 5.08 cm)
Item Weight	2.46 ounces (69.74 grams)
Color	Black

Support

For any questions, doubts, or problems regarding your Allimity replacement remote control, please do not hesitate to contact us. We are committed to replying to our customers within 24 hours to provide assistance.
Please refer to your purchase documentation or the seller's contact information for specific support channels.

© 2024 Allimity. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question