Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY RMT-24

Allimity RMT-24 Replacement Remote Control User Manual

For Westinghouse LCD TVs

Introduction

This manual provides instructions for the setup, operation, and maintenance of your Allimity RMT-24 replacement remote control. This remote is designed to be compatible with various Westinghouse LCD TV models.
Please read this manual thoroughly to ensure proper use and to maximize the lifespan of your remote control.

Safety Information

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.

Setup

1. Battery Installation

The remote control requires two AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Figure 1: Battery compartment on the back of the remote control.

2. Initial Use

This replacement remote control is pre-programmed and typically requires no additional setup for compatible Westinghouse LCD TV models. Simply install the batteries and begin use.
To operate your TV:

- Point the remote control directly at the infrared (IR) sensor on your television.
- Ensure there are no obstructions between the remote control and the TV's IR sensor.

Operating Instructions

The Allimity RMT-24 remote control features standard buttons for navigating your Westinghouse LCD TV. Refer to the image below for button layout and descriptions.





Figure 2: Front view of the RMT-24 remote control with button layout.

Button Functions:

- **Power (●)**: Turns the TV on or off.
- **Mute (☒)**: Mutes or unmutes the TV audio.
- **Number Buttons (0-9)**: Directly select channels.
- **P.MODE (Picture Mode)**: Cycles through picture presets (e.g., Standard, Dynamic, Movie).
- **S.MODE (Sound Mode)**: Cycles through sound presets (e.g., Standard, Music, Movie).
- **MTS (Multi-channel Television Sound)**: Selects audio tracks (e.g., Stereo, SAP).
- **SLEEP**: Sets the sleep timer for automatic TV shutdown.
- **SOURCE**: Selects input sources (e.g., HDMI, AV, Component).
- **CH+ / CH- (Channel Up/Down)**: Changes the channel.
- **VOL+ / VOL- (Volume Up/Down)**: Adjusts the volume level.
- **INFO**: Displays current channel information.
- **CC (Closed Caption)**: Toggles closed captions on or off.
- **V-CHIP**: Accesses V-Chip parental control settings.
- **CH.LIST (Channel List)**: Displays the list of available channels.
- **ASPECT**: Changes the screen aspect ratio (e.g., 16:9, 4:3).
- **Navigation Buttons (Up, Down, Left, Right, OK)**: Navigate menus and confirm selections.
- **MENU**: Opens the main TV menu.
- **EXIT**: Exits the current menu or function.
- **FAV (Favorite)**: Accesses favorite channels.
- **ADD/ERASE**: Adds or removes channels from the favorite list.
- **FAV+ / FAV-**: Navigates through favorite channels.

Maintenance

Battery Replacement

If the remote control's performance degrades or it stops responding, replace the batteries. Always replace both batteries at the same time with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the remote's surface or internal components.

Troubleshooting

- **Remote not responding:**
  - Ensure the remote is pointed directly at the TV's IR sensor.
  - Check for any objects blocking the path between the remote and the TV.
  - Replace the batteries with new AAA alkaline batteries, ensuring correct polarity.
- **Some functions not working:**
  - Verify that your TV model is listed as compatible. While this remote is designed for many Westinghouse LCD TVs, specific models may have unique functions not supported by all replacement remotes.
  - Consult your TV's original user manual for specific function details.
- **Compatibility concerns:**
  If your specific Westinghouse TV model number is not explicitly listed in the product description, or if you experience compatibility issues, please contact customer support for assistance before returning the product.

Specifications

Brand	ALLIMITY
Model Number	RMT-24 (Item model number: ZCM-RMT-24-WD)
Compatible Devices	Westinghouse LCD Televisions (e.g., WD24FT1360, WD28HC1160, WD32HB1120, WD32HB1120C, WD32HB1120-C, WD32HT1360, WD40FX1170, WD40FX1360, WD40FX1400, WD40FX1450, WD50FC1120, etc.)
Power Source	2 x AAA Batteries (not included)
Product Dimensions	7.02 x 0.6 x 2 inches
Item Weight	1.76 ounces
Color	Black
Special Feature	Ergonomic design

Support

For any questions, concerns, or issues regarding your Allimity RMT-24 replacement remote control, please contact our customer service. We aim to respond to all inquiries within 24 hours.
Please provide your product model number and a detailed description of the issue when contacting support to facilitate a quicker resolution.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C6M1Y8VT

More documents and user manuals: **https://manuals.plus/**