LG WM22WV26SR

LG WM22WV26SR Front Load Washing Machine User Manual

Model: WM22WV26SR

Introduction

This manual provides essential information for the safe and efficient use of your LG WM22WV26SR Front Load Washing Machine. Please read all instructions carefully before installation and operation. This appliance features a large capacity drum, AI DD (Artificial Intelligence Direct Drive) for intelligent fabric care, 6 Motion DD technology for varied wash motions, and LG ThinQ connectivity for smart control.

Safety Information

Always follow basic safety precautions to reduce the risk of fire, electric shock, or injury to persons when using this appliance.

- Read all instructions before use.
- Do not wash articles that have been previously cleaned in, washed in, soaked in, or spotted with gasoline, dry-cleaning solvents, or other flammable or explosive substances.
- Do not allow children to play on or in the appliance. Close supervision of children is necessary when the appliance is used near children.
- Do not reach into the appliance if the tub or agitator is moving.
- Do not install or store this appliance where it will be exposed to the weather.
- Do not tamper with controls.
- Do not repair or replace any part of the appliance or attempt any servicing unless specifically recommended in the user-maintenance instructions or in published user-repair instructions that you understand and have the skills to carry out.

Setup and Installation

1. Unpacking and Inspection

Carefully remove all packaging materials. Inspect the washing machine for any damage during transit. Report any damage

immediately to your retailer.

2. Removing Shipping Bolts

Before operating the washing machine, you must remove the shipping bolts located at the rear of the unit. These bolts secure the drum during transport and must be removed to prevent severe vibration and damage during operation.



Image: Rear view of the washing machine, highlighting the areas where shipping bolts are typically found. These bolts must be removed before first use.

3. Leveling the Machine

Ensure the washing machine is perfectly level to prevent excessive vibration and noise. Adjust the leveling feet at the bottom of the machine until it is stable and does not rock.

4. Connecting Water Hoses

Connect the hot and cold water inlet hoses to the corresponding valves on the back of the machine and to your household water supply. Ensure connections are tight to prevent leaks.

5. Connecting Drain Hose

Securely attach the drain hose to the drain outlet at the rear of the machine and route it to a standpipe or laundry tub. Ensure the hose is not kinked and is properly secured to prevent dislodging during drainage.

6. Electrical Connection

Plug the power cord into a grounded electrical outlet. Do not use extension cords or adapters. Ensure the electrical supply matches the requirements specified on the appliance's rating label.

Operating Instructions

1. Control Panel Overview

The washing machine features a touch control panel with a central dial for cycle selection and a digital display. Familiarize yourself with the various buttons and indicators.



Image: Detailed view of the touch control panel, including the program selection dial and digital screen.

2. Loading Laundry

Open the door and load laundry into the drum. Do not overload the machine; leave enough space for clothes to tumble freely. Close the door firmly.



Image: The washing machine with its front door open, showing the interior of the stainless steel drum ready for loading.

3. Adding Detergent and Additives

Pull out the detergent dispenser drawer. Add the appropriate amount of detergent to the main wash compartment. Add fabric softener or bleach to their designated compartments if desired.

4. Selecting a Wash Cycle

Turn the cycle selector dial to choose the desired wash program. The machine offers various cycles, including:

- **Normal:** For everyday cottons and mixed fabrics.
- **Heavy Duty:** For durable fabrics and heavily soiled items.
- **Delicates:** For fragile items requiring gentle care.
- **Sportswear:** Optimized for athletic apparel.
- **AI DD Technology:** Automatically detects fabric type and weight to optimize wash motions.
- **6 Motion DD Technology:** Provides 6 different wash motions for enhanced fabric care.

5. Starting a Wash Cycle

Press the Start/Pause button to begin the selected wash cycle. The machine will automatically proceed through the wash, rinse, and spin phases.

6. Using LG ThinQ Connectivity

Download the LG ThinQ app to your smartphone to connect your washing machine. This allows for remote control, cycle monitoring, and voice assistant integration. You can ask your AI speaker, "What cycle is the washer on?" to check its status.

Maintenance

1. Cleaning the Exterior

Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.

2. Cleaning the Drum

Periodically run a 'Tub Clean' or 'Drum Clean' cycle (if available) with a washing machine cleaner to remove detergent residue and odors.



Image: A detailed view of the stainless steel drum, showing its textured surface designed for effective washing.

3. Cleaning the Detergent Dispenser

Remove the detergent dispenser drawer and rinse it under warm water to clear any buildup. Dry thoroughly before reinserting.

4. Cleaning the Drain Filter

Regularly check and clean the drain pump filter (usually located at the bottom front of the machine) to prevent blockages and ensure efficient drainage.

Troubleshooting

Before contacting service, review the following common issues and solutions:

- **Machine does not start:** Check if the power cord is securely plugged in, the door is fully closed, and the water supply taps are open.
- **Excessive vibration or noise:** Ensure the machine is level and that all shipping bolts have been removed. Check if the load is balanced inside the drum.
- **Water leaks:** Verify that water inlet and drain hoses are securely connected and not damaged. Check the drain filter for blockages.
- **Error codes on display:** Refer to the full user manual for specific error code meanings and troubleshooting steps.

Specifications

Model Number	WM22WV26SR
Brand	LG
Type	Front Load Washing Machine
Capacity	22 Kg
Color	White
Dimensions (D x W x H)	74 cm x 81 cm x 106 cm
Special Features	Smart Control, Smart Home, AI DD Technology, 6 Motion DD Technology
Control Type	Touch
Maximum Spin Speed	670 RPM
Number of Wash Cycles	6 (including Cotton, Sportswear, Delicates)
Drum Material	Stainless Steel
Motor Type	Inverter Direct Drive



Image: Dimensional diagram of the washing machine, indicating its height, width, and depth.

Warranty and Support

Warranty Information

This LG WM22WV26SR washing machine comes with a one-year manufacturer's warranty. Please retain your proof of purchase for warranty claims. For detailed terms and conditions, refer to the warranty card included with your appliance or visit the official LG website.

Customer Support

For technical assistance, troubleshooting beyond this manual, or to schedule service, please contact LG Customer Support. Contact information can be found on the LG website or in the documentation provided with your appliance.