USHINING T3105

USHINING 4G Unlocked Flip Phone User Manual

Model: T3105

Introduction

This user manual provides comprehensive instructions for the USHINING T3105 4G Unlocked Flip Phone. Designed with seniors in mind, this phone features large buttons, a clear display, and a simple operating system for ease of use. Please read this manual carefully to ensure proper operation and maintenance of your device.

Package Contents

Upon opening the package, please verify that all the following items are included:

- USHINING T3105 4G Senior Cell Phone (Red)
- Rechargeable Lithium-Ion Battery (1200mAh)
- Charging Dock
- Charging Cord (Power Adapter)
- SpeedTalk SIM Card
- User Manual



Figure 1: Package Contents. This image displays all items included in the USHINING T3105 phone package, including the phone, charging dock, battery, charging cord, SpeedTalk SIM card, and user manual.

Phone Overview

Familiarize yourself with the physical components of your USHINING T3105 flip phone.



Figure 2: Front View and Charging Dock. This image shows the USHINING T3105 flip phone in its open position, displaying the large keypad and inner screen, alongside its charging dock.



Figure 3: Internal Components. This image provides a view of the phone's internal compartment, revealing the slots for the SIM card and Micro SD card, located beneath the battery cover.

Keypad and Display Features

- **Large Buttons:** Designed for easy dialing and navigation.
- **Inner Screen (2.8 inches):** Main display for menus, calls, and messages.
- **External Screen (1.77 inches):** Displays time, date, and incoming call information without opening the phone.
- **Big Icon Display:** Simplified interface with large, easy-to-read icons.



Figure 4: Large Keypad and Big Icons. This image highlights the user-friendly design of the phone, featuring an oversized keypad and large, clear icons on the display for enhanced readability.

Setup

1. Installing the SIM Card and Micro SD Card

1. Open the back cover of the phone by gently prying it open from the notch.
2. Remove the battery if it is already installed.
3. Locate the SIM card slot(s). This phone supports a standard SIM card and a Micro SD card (expandable up to 32GB).
4. Insert the SIM card(s) into the designated slot(s) with the gold contacts facing down, ensuring it clicks into place.
5. If using, insert the Micro SD card into its slot.
6. Reinsert the battery and replace the back cover.

2. Installing the Battery

1. Ensure the phone is powered off.
2. Remove the back cover.
3. Align the battery's gold contacts with the contacts in the battery compartment.
4. Gently press the battery down until it is securely in place.
5. Replace the back cover.

3. Charging the Phone

Before first use, fully charge the phone's battery. The phone can be charged using the included charging dock or directly with the charging cord.

- **Using the Charging Dock:** Place the phone into the charging dock, ensuring it sits correctly. The charging indicator on the phone will illuminate.
- **Using the Charging Cord:** Connect the charging cord to the phone's charging port and plug the adapter into a power outlet.

A full charge typically takes approximately 3 hours. The battery provides 5-6 hours of talk time or over 100 hours (4 days) of standby time.



Figure 5: Charging the Phone. This image shows the USHINING T3105 phone placed in its convenient charging dock, illustrating the charging process and highlighting its 1200mAh battery for long standby time.

Operating Instructions

Power On/Off

- **To Power On:** Press and hold the Power/End Call button (red button) until the screen illuminates.
- **To Power Off:** Press and hold the Power/End Call button until the power off options appear, then select "Power off".

Making and Receiving Calls

- **Making a Call:**
  a. Enter the phone number using the large keypad.
  b. Press the Call button (green button) to initiate the call.
- **Receiving a Call:**

- When the phone rings, open the flip to answer the call, or press the Call button.
- To hang up, close the flip or press the Power/End Call button.

Adjusting Volume

Use the volume buttons located on the side of the phone to adjust the call volume during a conversation or the ringtone volume when idle.

SOS Emergency Calls

The SOS button is a critical safety feature, allowing you to quickly contact pre-set emergency numbers.

1. **Setting up SOS Contacts:** Navigate to the SOS settings in the phone's menu. You can preset up to 5 emergency contact numbers.
2. **Using the SOS Button:** In an emergency, press and hold the SOS button (located on the back or side of the phone, depending on model variation) for a few seconds. The phone will automatically dial the pre-set emergency contacts in sequence until one answers. It will also send an emergency SMS message to these contacts.



Figure 6: SOS Emergency Call Feature. This diagram illustrates how the SOS button functions, allowing the user to quickly dial up to five pre-set emergency contacts in a crisis situation.

Speed Dial

Assign frequently called numbers to speed dial keys (2-9) for quick access.

1. Go to the phone's settings or contacts menu to assign numbers to speed dial keys.
2. To use, simply press and hold the assigned number key (e.g., '2' for the second speed dial contact) to dial the number.

Other Practical Functions

Your USHINING T3105 phone includes several useful features:



Figure 7: Phone Features Overview. This image displays icons representing key functionalities of the USHINING T3105, including Calendar, Dual SIM support, SOS button, Alarm Clock, Speed Dial, Camera, Torch (flashlight), and FM Radio.

- **Camera:** Capture photos with the integrated 2.0MP camera.
- **FM Radio:** Listen to your favorite radio stations. The phone supports external FM radio, meaning it can function without headphones as an antenna.
- **Flashlight:** Activate the powerful 30M flashlight for illumination.
- **Alarm Clock:** Set multiple alarms for reminders.
- **Calculator:** Perform basic arithmetic calculations.
- **Calendar:** Keep track of dates and appointments.
- **Bluetooth:** Connect to compatible Bluetooth devices like headsets.
- **Blacklist:** Block unwanted numbers from calling you.
- **Multi-language Support:** The phone supports English, French, Spanish, German, Italian, and Dutch.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the phone's exterior. Avoid using liquid cleaners or aerosols.
- **Battery Care:**
  - Avoid exposing the battery to extreme temperatures.
  - Do not puncture, disassemble, or short-circuit the battery.
  - If the phone will not be used for an extended period, charge the battery to about 50% and store it in a cool, dry place.

- **Storage:** Store the phone in a dry environment, away from direct sunlight and extreme temperatures.
- **Handling:** Handle the phone with care. Avoid dropping it or subjecting it to strong impacts.

Troubleshooting

If you encounter issues with your USHINING T3105 phone, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
Phone does not power on.	Battery is depleted. Charge the phone for at least 30 minutes. Ensure battery is correctly installed.
Cannot make or receive calls.	SIM card not inserted correctly or not activated. Check network signal strength. Ensure your carrier is compatible (T-Mobile and MVNOs, not CDMA).
Poor call quality / Low volume.	Adjust call volume using side buttons. Ensure microphone and speaker are not obstructed. Move to an area with better network coverage.
Battery drains quickly.	Excessive use of features like flashlight or radio. Poor network signal can increase battery consumption. Battery may be old and require replacement.
Phone freezes or is unresponsive.	Remove and reinsert the battery to perform a soft reset.

Specifications

Feature	Detail
Model	T3105
Dimensions	104 x 53.5 x 18.8 mm
Weight	112 g
Operating System	Nucleus OS
Inner Display	2.8 inches QVGA (240 x 320 resolution)
External Display	1.77 inches
Camera	2.0 MP
Memory (RAM)	64 MB
Storage (ROM)	128 MB
Expandable Storage	Micro SD card up to 32GB
Battery Capacity	1200 mAh Lithium-Ion
Talk Time	5-6 hours
Standby Time	Over 100 hours (4 days)

Feature	Detail
Network Compatibility	4G LTE (T-Mobile and compatible MVNOs; Not for CDMA networks like Verizon, Sprint, Boost, PagePlus)
SIM Card Support	Standard SIM card
Connectivity	Bluetooth
Languages	English, French, Spanish, German, Italian, Dutch

Warranty and Support

For warranty information and technical support, please refer to the documentation provided with your purchase or contact USHINING customer service. Keep your purchase receipt as proof of purchase for warranty claims.
For further assistance, you may visit the official USHINING website or contact their support channels as listed on the product packaging or their website.

© 2024 USHINING. All rights reserved.

Model: T3105