chefhandy 1600

Chefhandy Baby Food Maker Instruction Manual

Model 1600

Important Safety Instructions

- Read all instructions before using the appliance.
- Do not immerse the main unit in water or other liquids to avoid electric shock.
- Always supervise children when the appliance is in use.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer service for assistance.
- Avoid contact with moving parts.
- Use only purified water in the water tank to prevent limescale buildup.
- Always ensure the lid is securely locked before operating the blending function.
- Exercise extreme caution when handling hot liquids or steam.

Product Overview

The Chefhandy Baby Food Maker Model 1600 is a versatile 5-in-1 appliance designed to simplify baby meal preparation. It combines steaming, blending, sterilizing, and bottle warming functions in one compact unit.



Figure 1: Chefhandy Baby Food Maker Model 1600 with various food items.

Main Components:

- **Main Unit:** Houses the motor, water tank, and control panel.
- **Blending Cup:** Transparent cup with a detachable stainless steel blade for blending.
- **Stainless Steel Steam Basket:** Used for steaming food items.
- **Lid:** Secures the blending cup and steam basket during operation.
- **Control Panel:** Digital display with touch buttons for various functions (Sterilize, Auto Blend, Manual Blend, Steam, Warm, Power, +/-).
- **Bottle Warmer Slot:** Integrated slot for warming baby bottles.



Figure 2: Overview of the Chefhandy Baby Food Maker's functions.

Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Initial Cleaning:** Before first use, wash the blending cup, lid, and stainless steel steam basket with warm soapy water. Rinse thoroughly and dry. Wipe the main unit with a damp cloth.
3. **Assembly:** Place the blending cup onto the main unit, ensuring it clicks securely into place. Insert the stainless steel steam basket into the blending cup if steaming.
4. **Fill Water Tank:** Open the water tank cover on the main unit and fill with purified water up to the MAX line. Close the cover securely.
5. **Power On:** Plug the appliance into a suitable power outlet. The control panel will illuminate.



Figure 3: Filling the water tank with purified water.

Operating Instructions

1. Steaming Food

1. Prepare food by washing, peeling, and cutting into small pieces (approximately 1 cm cubes).
2. Place the cut food into the stainless steel steam basket.
3. Ensure the blending cup is on the main unit and the steam basket is inside. Secure the lid.
4. Press the 'Steam' button on the control panel. Use the '+' and '-' buttons to adjust the steaming time (e.g., 15-20 minutes for most vegetables).
5. The appliance will automatically steam and beep when finished.

2. Blending Food

1. After steaming, carefully remove the steam basket using the anti-scald handle.
2. Pour any excess water from the blending cup if desired, then transfer the steamed food directly into the blending cup.
3. Secure the lid onto the blending cup.
4. Choose your blending mode:
    - **Auto Blend:** Press the 'Auto Blend' button for automatic blending to a smooth consistency.
    - **Manual Blend:** Press and hold the 'Manual Blend' button for pulsed blending to achieve desired texture. Release to stop.
5. Once blending is complete, carefully remove the blending cup and serve or store the pureed food.



Figure 4: Step-by-step process for steaming and blending baby food.

3. Bottle Warming

1. Ensure the water tank is filled with purified water.
2. Place the baby bottle into the designated bottle warmer slot on the main unit.
3. Press the 'Warm' button on the control panel. Use '+' and '-' to adjust the warming time or temperature if applicable.

4. The appliance will warm the bottle and beep when finished. Always check the milk temperature before feeding.



Figure 5: Using the bottle warming function.

4. Sterilizing

1. Ensure the water tank is filled with purified water.
2. Place small items like pacifiers or bottle nipples into the stainless steel steam basket within the blending cup.
3. Secure the lid onto the blending cup.
4. Press the 'Sterilize' button on the control panel. Use '+' and '-' to adjust the sterilizing time.
5. The appliance will sterilize the items and beep when finished. Allow items to cool before handling.



Figure 6: Sterilizing small baby items.

Official Product Videos

Your browser does not support the video tag.

Video 1: An overview of the Chefhandy Baby Food Maker's features and ease of use, demonstrating its multi-functionality for preparing baby food.

Your browser does not support the video tag.

Video 2: A demonstration of the Chefhandy 5-in-1 Baby Food Processor, highlighting its steaming basket and various functions for efficient meal preparation.

Cleaning and Maintenance

1. **Daily Cleaning:** After each use, unplug the appliance. Disassemble the blending cup, lid, and steam basket. Wash these parts with warm, soapy water. The detachable blade can be carefully removed for thorough cleaning. Rinse and dry completely.
2. **Main Unit:** Wipe the main unit with a damp cloth. Do not immerse the main unit in water.
3. **Descaling:** Over time, mineral deposits (limescale) may build up in the water tank. To descale, mix 1 part white vinegar with 2 parts water, or use a citric acid solution. Pour into the water tank and run a steam cycle without food. Rinse the water tank thoroughly several times with fresh water afterward.



Figure 7: Visual guide for disassembling and cleaning the appliance parts.

Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in or power issue.	Ensure the power cord is securely plugged into a working outlet.
E1 Error displayed.	Low water in the water tank.	Add purified water to the water tank up to the MAX line.
Blending function not working.	Lid not securely closed or blending cup not properly installed.	Ensure the blending cup is correctly seated and the lid is securely locked.
Food not steaming properly.	Insufficient water or incorrect steaming time.	Check water level in the tank and adjust steaming time as needed.



Figure 8: The 'E1' error code indicates low water in the tank.

Specifications

Feature	Detail
Brand	chefhandy
Model Name	1600
Product Dimensions	12"D x 5.6"W x 11"H
Item Weight	0.705 ounces
Power Source	Corded Electric
Blade Material	Stainless Steel or Metal
Special Feature	Baby food maker (5-in-1: Steamer, Blender, Sterilizer, Bottle Warmer, Auto/Manual Blend)
Recommended Uses	Blend, Steam, Warm, Sterilize
Product Care Instructions	Hand Wash
Included Components	Baby food maker, Stainless Steel Basket, 6 Baby Food Pouches, Spill-proof cover, User Manual, Quick Start Guide, Baby Food Recipes

Warranty and Support

The Chefhandy Baby Food Maker is designed for durability and performance. For specific warranty information or to inquire about replacement parts, please refer to the warranty card included in your product packaging or contact Chefhandy customer support directly.

For any questions, technical assistance, or service requests, please visit the official Chefhandy website or contact their customer service team. Keep your purchase receipt for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question