Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JOZZBY SH0001

JOZZBY Shoe Cabinet Storage with 3 Flip Drawers

Model: SH0001

1. Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your JOZZBY Shoe Cabinet Storage with 3 Flip Drawers. This white, slim, freestanding shoe organizer is designed to provide efficient storage for your entryway, hallway, or living room, helping to maintain an organized space.



Image 1.1: The JOZZBY Shoe Cabinet, a white, slim unit with three flip-down drawers, positioned in an entryway next to a white door and a small grey ottoman. The top surface holds a small vase with greenery and a decorative frame.

2. Safety Information

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- **Anti-Toppling Device:** It is mandatory to secure the shoe cabinet to the wall using the provided anti-toppling device. This prevents accidental tipping, especially important in households with children or pets.
- **Weight Limit:** Do not exceed the maximum weight limit of 33 pounds on the top surface. Overloading can compromise the stability of the cabinet.
- **Assembly:** Ensure all parts are correctly assembled and fasteners are tightened securely before use.
- **Placement:** Place the cabinet on a flat, stable surface to prevent wobbling.



Image 2.1: A close-up view of the anti-toppling device, a small white plastic anchor with a screw, designed to secure the cabinet to a wall for stability.

3. Package Contents

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Shoe Cabinet Panels (Numbered)
- 3 Flip Drawers
- Gold Handles (3 pieces)
- Assembly Hardware (screws, dowels, cam locks, etc.)
- Anti-Toppling Device
- Instruction Manual

4. Setup and Assembly

Assembly is required for this product. Please follow the detailed instructions provided in the included assembly guide. All parts are numbered for easy identification.

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify each part using the numbering system.
3. Assemble the main frame of the cabinet according to the step-by-step diagrams.
4. Attach the flip drawer mechanisms and install the drawers.
5. Secure the gold handles to the front of each drawer.
6. Once assembled, position the cabinet in its desired location.
7. **Crucially, install the anti-toppling device by securing the cabinet to the wall.**



Image 4.1: A close-up view of the bottom corner of the shoe cabinet, showing the secure screw connections that hold the panels together, indicating sturdy construction.



Image 4.2: An internal view of the shoe cabinet's flip drawers, showing the mechanism and compartments designed to hold shoes. The drawers are open, revealing shoes stored inside.

5. Operating Instructions

The JOZZBY Shoe Cabinet is designed for convenient and space-saving shoe storage.

5.1. Using the Flip Drawers

- Each of the three flip drawers can hold 2-3 pairs of shoes when placed side-by-side.
- For increased capacity, shoes can be stacked up and down within each drawer, allowing for up to 5 pairs per drawer, depending on shoe style and size.
- To open a drawer, gently pull the gold handle outwards. The drawer will flip down, revealing the shoe compartments.

- To close, push the drawer upwards until it clicks securely into place.
- The flip-down design helps keep shoes away from dust and protects them from pets.

5.2. Top Surface Storage

The spacious top surface of the cabinet can be used to place accessories, keys, wallets, or small decorative items, providing easy access to frequently used items.



Image 5.1: A diagram illustrating the dimensions of the shoe cabinet (41.2"H x 22.8"W x 6.7"D) and the internal drawer dimensions. It also shows various shoe types (high heels, sneakers, leather shoes, slippers) that can be stored, indicating storage capacity depends on shoe style and size.



Image 5.2: A composite image showing four key features: a spacious top surface with decorative items, ample storage capacity with shoes in open drawers, a back ventilate design for air circulation, and the anti-tipping device for safety.

6. Maintenance

Proper care will ensure the longevity and appearance of your shoe cabinet.

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the painted finish.
- **Dusting:** Regularly dust the cabinet to prevent buildup.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the engineered wood.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.

7. Troubleshooting

If you encounter any issues with your shoe cabinet, refer to the following common solutions:

- **Wobbly Cabinet:** Ensure the cabinet is placed on a level surface. Check all assembly screws and tighten any that are loose. Verify the anti-toppling device is securely installed.
- **Drawers Not Closing Properly:** Check for any obstructions inside the drawer or along the flip mechanism. Ensure shoes are not overfilling the compartments. Verify the drawer mechanism was installed correctly during assembly.
- **Damaged Parts:** If any parts were damaged during shipping or assembly, please contact JOZZBY customer support for assistance.

8. Specifications

Brand	JOZZBY
Model Name	Shoe Cabinet (SH0001)
Color	White-1pc
Product Dimensions	6.7"D x 22.8"W x 41.2"H
Mounting Type	Floor Mount
Room Type	Bedroom, Entryway, Living Room
Door Style	Sliding Doors (Flip-down mechanism)
Weight Limit (Top Surface)	33 Pounds
Included Components	Shoe Cabinet, Assembly Hardware, Anti-Toppling Device
Finish Type	Painted
Size	3 Drawer
Shape	Rectangular
Number of Shelves	3 (internal compartments)
Number of Pieces	3 (drawers)
Item Weight	30.4 Pounds
Base Type	Pedestal
Installation Type	Freestanding
Top Material Type	Engineered Wood
Handle Material	Metal
Back Material Type	Engineered Wood
Assembly Required	Yes
Frame Material	Engineered Wood

Number of Compartments	3
UPC	768679538667
Date First Available	June 2, 2023

9. Customer Support

JOZZBY is committed to providing quality products and services. If you have any questions, concerns, or require assistance with your product, please do not hesitate to contact us. We aim to respond to all inquiries within 24 hours. For further information or to explore other JOZZBY products, please visit theJOZZBY Store on Amazon.

© 2023 JOZZBY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C6XH4LY2

More documents and user manuals: **https://manuals.plus/**