Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Claesydorn P10

Claesydorn P10 Cordless Vacuum Cleaner User Manual

Model: P10

1. Introduction

This manual provides essential instructions for the safe and efficient operation, maintenance, and troubleshooting of your Claesydorn P10 Cordless Vacuum Cleaner. Please read this manual thoroughly before first use and retain it for future reference.

2. Important Safety Instructions

When using an electrical appliance, basic precautions should always be followed, including the following:

- Read all instructions before using this appliance.
- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up toxic material (e.g., chlorine bleach, ammonia cleaner, drain cleaner).
- Do not use without dust bag and/or filters in place.
- Turn off all controls before unplugging.
- Use extra care when cleaning on stairs.
- Do not use to pick up hard or sharp objects such as glass, nails, screws, coins, etc., as this may damage the machine.

3. Package Contents

Please check the package contents to ensure all items are present and undamaged:

- Main Motor (Motor & Dust Cup)
- Motorized Brush Head
- Battery Pack
- Power Adapter
- Roller Brush
- Wall Mount
- Metal Tube
- 2-in-1 Brush
- Metal Strainer
- User Manual



Image: All components included with the Claesydorn P10 Cordless Vacuum Cleaner, illustrating the main unit, various attachments, and

accessories.

4. Assembly and Setup

Follow these steps to assemble your vacuum cleaner:

1. Insert the metal tube into the main motor unit until it clicks securely into place.
2. Attach the motorized brush head to the other end of the metal tube, ensuring it locks firmly.
3. Slide the battery pack into the designated slot on the main motor unit until it clicks.
4. For storage, install the wall mount in a suitable location using the provided hardware.



Image: Visual guide demonstrating the connection points for assembling the main motor, metal tube, and motorized brush head.

5. Charging the Battery

The Claesydorn P10 is equipped with a detachable 2200mAh lithium-ion battery, providing up to 45 minutes of runtime on a single charge. To charge the battery:

1. Connect the power adapter to the charging port on the battery pack or directly to the main motor unit if the battery is attached.
2. Plug the power adapter into a wall outlet.
3. The charging indicator light will illuminate. A full charge typically takes approximately 4 hours.
4. Once fully charged, disconnect the power adapter.



Image: Close-up view of the vacuum's main unit, highlighting the battery and indicating its capacity and charging time.

6. Operating the Vacuum Cleaner

The Claesydorn P10 offers versatile cleaning with its 6-in-1 design, adapting to various surfaces and cleaning needs.

6.1 Power On/Off and Suction Modes

- Press the power button on the main unit to turn the vacuum on.
- Press the power button again to turn it off.
- The vacuum may have different suction modes. Refer to the indicator lights for the current mode and adjust as needed for different cleaning tasks.

6.2 Using Attachments

- **Motorized Brush Head:** Ideal for hard floors, hardwood floors, and low-pile carpets. The integrated LED lights illuminate dark areas, ensuring thorough cleaning under furniture and in dimly lit spaces.
- **2-in-1 Brush:** Use this attachment for cleaning upholstery, curtains, car interiors, and other delicate surfaces. It can be used as a brush or a crevice tool.
- **Metal Tube:** Connect the main motor to the motorized brush head for floor cleaning, or use the main motor with attachments directly for handheld cleaning.



Image: A user operating the Claesydorn P10 Cordless Vacuum Cleaner on a carpeted floor, demonstrating its use for general floor cleaning.



Image: Close-up of the 2-in-1 floor and carpet brush head, illustrating its adaptability for different floor types including low-pile carpet, tile, rug, and wooden floors.

6.3 Maneuverability

The vacuum's flexible design allows for easy navigation around obstacles and under furniture. The brush head can swivel 180° left and right and pivot 90° up and down.



Image: Diagrams illustrating the 180-degree left and right swivel and 90-degree up and down pivot capabilities of the vacuum head for enhanced maneuverability.

6.4 Versatile Cleaning Applications

Utilize the various configurations for comprehensive cleaning:

- **Curtains:** Use the main motor with the 2-in-1 brush for gentle cleaning.
- **Sofas:** Attach the 2-in-1 brush directly to the main motor for upholstery.
- **Automobile:** The handheld configuration is ideal for cleaning car interiors.
- **Home Furnishing:** Easily clean shelves, tabletops, and other surfaces.



Image: A collage showing the Claesydorn P10 in different cleaning scenarios, including vacuuming curtains, sofas, car interiors, and general home furnishings.

7. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

7.1 Emptying the Dustbin

The 1-liter dustbin is designed for multiple cleanings. To empty:

1. Hold the main motor unit over a trash receptacle.
2. Press the one-click release button on the dustbin to open the bottom flap and empty the contents.
3. Close the flap securely after emptying.

7.2 Cleaning the Filtration System

The vacuum features a 5-stage high-efficiency filtration system, including a HEPA filter, to capture 99.99% of fine dust. Regular

cleaning is crucial.

1. Twist and remove the dustbin from the main motor unit.
2. Carefully remove the internal filter components: the 1st cyclone, metal dust filter, multi-cone cyclonic filter, pre-filter, and H10 HEPA filter.
3. Tap off any loose dust from each component.
4. Rinse the washable components (metal dust filter, multi-cone cyclonic filter, pre-filter, and HEPA filter) under running water until clean. Do not wash the main motor unit.
5. Allow all washed components to air dry completely for at least 24 hours before reassembling. Ensure they are completely dry to prevent damage and maintain suction power.
6. Reassemble the filters in reverse order and reattach the dustbin to the main motor unit.



Image: An exploded diagram illustrating the 5-stage high-efficiency filtration system, detailing each filter component from the 1st cyclone to the H10 HEPA filter.



Image: Demonstrates the one-click dustbin emptying mechanism and the process of washing the removable filter components under running water.

7.3 Cleaning the Roller Brush

Periodically check the roller brush for tangled hair or debris. To clean:

1. Turn off the vacuum and detach the motorized brush head.
2. Locate the release mechanism for the roller brush cover and open it.
3. Remove the roller brush.
4. Use scissors or the provided cleaning tool to cut and remove any tangled hair or fibers.
5. Reinsert the roller brush and close the cover securely.

8. Troubleshooting

If you encounter issues with your vacuum cleaner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vacuum does not turn on	Battery is not charged or not properly installed.	Ensure battery is fully charged and securely clicked into place.
Low suction power	Dustbin is full. Filters are clogged. Obstruction in nozzle or tube.	Empty dustbin. Clean all filters. Check for and remove any blockages.
Brush head stops rotating	Roller brush is tangled with hair or debris. Obstruction in brush head.	Turn off vacuum, remove brush head, and clean the roller brush. Remove any obstructions.
Battery runtime is short	Battery not fully charged. Using high power mode continuously. Battery degradation.	Ensure battery is fully charged. Use standard mode for longer runtime. Contact support if battery life significantly decreases.

9. Specifications

Brand	Claesydorn
Model Number	P10
Power / Wattage	250 watts
Voltage	120 Volts
Noise Level	75 dB
Runtime	Up to 45 minutes
Dustbin Capacity	1 Liters
Item Weight	1.2 Kilograms
Product Dimensions	43.94 x 19 x 43.94 cm
Special Features	Lightweight
Filter Type	Disk (5-stage HEPA filtration)
Surface Recommendation	Hard Floor, Hardwood Floors, Low-pile Carpet
Power Source	Battery Powered
Cordless	Yes

10. Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your product or contact Claesydorn customer service through the retailer where the product was purchased. Please have your model number (P10) and purchase date available when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C72KC4ZW

More documents and user manuals: **https://manuals.plus/**