Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JOYIN 15613

JOYIN Animated Zombie Groundbreaker Outdoor Decor Instruction Manual

Model: 15613 | UPC: 840332604886

Introduction

Thank you for purchasing the JOYIN Animated Zombie Groundbreaker. This decoration is designed to create a realistic and spooky atmosphere for your Halloween events. Featuring light-up eyes, movable arms, and sound activation, it is suitable for both indoor and outdoor use.

Safety Information

- Outdoor use only.
- Unplug during inclement weather.
- Do not allow children to play on or near the display.
- Keep away from flammable materials.

Package Contents

- 1 x JOYIN Animated Zombie Groundbreaker

Note: 3 AA batteries are required and not included.

Setup

1. **Battery Installation:**
   Locate the battery compartment on the back of the zombie groundbreaker. Open the compartment (a screwdriver may be required). Insert 3 AA batteries, ensuring correct polarity. Close the compartment securely.



Figure 1: Battery compartment for 3 AA batteries.

2. **Placement:**
   Position the zombie groundbreaker in your desired indoor or outdoor location. Its design allows it to appear as if it is breaking through the ground, making it ideal for lawns, patios, or indoor Halloween displays.



Figure 2: Example outdoor placement of the zombie groundbreaker.

Operating Instructions

The JOYIN Animated Zombie Groundbreaker is designed for easy operation to enhance your Halloween decor.

1. **Power On:** After installing batteries, locate the power switch (usually near the battery compartment) and turn it to the "ON" position.
2. **Sound Activation:** The zombie is sound-activated. Any loud noise, such as a clap or a scream, will trigger its animated features.
3. **Animated Features:**
    - **Light-Up Eyes:** The zombie's eyes will glow red when activated.
    - **Movable Arms:** The arms will move in a creepy, reaching motion.
    - **Horrific Sounds:** The zombie will emit spooky sounds.



Figure 3: Zombie with light-up eyes and movable arms.



Figure 4: Sound-activated features of the zombie groundbreaker.



Figure 5: Depiction of the zombie's animated motion.

Demonstration Video

Your browser does not support the video tag.

Video 1: A short demonstration of the Animated Zombie Groundbreaker's moving arms and sound effects.

Maintenance

- **Cleaning:** Wipe the surface with a soft, dry cloth. Do not use abrasive cleaners or immerse in water.
- **Storage:** When the Halloween season is over, you can conveniently fold and store the groundbreaker for future use. Ensure it is dry before storing in a cool, dry place away from direct sunlight.
- **Battery Replacement:** Replace batteries when the animation or sound effects become weak or stop functioning. Always use fresh batteries of the same type.

Troubleshooting

Problem	Possible Cause	Solution
No animation or sound	Batteries are dead or incorrectly installed.	Check battery polarity and replace with new 3 AA batteries. Ensure the power switch is "ON".
Animation is weak or intermittent	Low battery power.	Replace with new 3 AA batteries.
Sound activation not working	Insufficient ambient noise or sensor obstruction.	Ensure the sensor is clear and try making a louder noise near the unit.

Specifications

- **Model Number:** 15613
- **Dimensions (L x W x H):** 14.76 x 8.66 x 7.28 inches (approx. 23.6 inches / 60 cm in height when arms are extended)
- **Power Source:** 3 x AA Batteries (not included)
- **Features:** Light-up eyes, movable arms, sound-activated
- **Recommended Use:** Indoor and Outdoor Halloween Decoration



Figure 6: Product dimensions.

Warranty and Support

This product comes with a standard manufacturer's warranty. For detailed warranty information, product support, or to report any issues, please contact JOYIN customer service directly. Contact information can typically be found on the product packaging or the official JOYIN website.
For more products and information, visit theJOYIN Store.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C73R9GYR

More documents and user manuals: **https://manuals.plus/**