Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl IVP1800-2500

onerbl 18V AC/DC Adapter User Manual

Model: IVP1800-2500

1. Introduction

This manual provides essential instructions for the safe and effective use of your onerbl 18V AC/DC Adapter, Model IVP1800-2500. This adapter is designed to provide reliable power to compatible devices, including the Cricut Explore Air 2 (models CXPL201, 2003638, CXPL202). Please read this manual thoroughly before use and retain it for future reference.

2. Safety Information

To ensure safe operation and prevent damage, please observe the following safety precautions:

- Use the adapter only with devices that require 18V DC input and match the adapter's connector type.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not attempt to open, modify, or repair the adapter. Refer servicing to qualified personnel.
- Ensure the power outlet is easily accessible and properly grounded.
- Unplug the adapter from the power outlet when not in use for extended periods.
- Keep out of reach of children.

3. Package Contents

Verify that all items are present in your package:

- 1 x onerbl 18V AC/DC Adapter (Model IVP1800-2500)
- 1 x AC Power Cord



Image: The included AC power cord, featuring a standard two-prong plug for wall outlets and a C7 connector for the adapter.

4. Setup

Follow these steps to set up your AC/DC adapter:

1. **Connect the AC Power Cord:** Insert the C7 connector end of the AC power cord firmly into the corresponding port on the onerbl 18V AC/DC Adapter.
2. **Plug into Wall Outlet:** Insert the two-prong plug of the AC power cord into a standard 100-240V AC wall outlet.
3. **Connect to Device:** Plug the DC output connector of the adapter into the power input port of your compatible device (e.g., Cricut Explore Air 2). Ensure a secure connection.



Image: The onerbl 18V AC/DC adapter connected to a wall outlet and a device, demonstrating a typical setup.

5. Operating Instructions

Once properly connected, the adapter will supply power to your device. The adapter is designed for continuous use within its specified voltage and current limits. Always ensure your device is compatible with the adapter's output specifications (18V DC).

- **Power Indicator:** The adapter may feature an LED indicator light to show when it is receiving power.
- **Disconnecting:** To disconnect, first power off your device, then unplug the DC connector from the device, and finally unplug the AC power cord from the wall outlet.

6. Maintenance

Proper maintenance ensures the longevity and performance of your adapter:

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.

- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures when not in use. Avoid tightly winding the cables to prevent damage.
- **Inspection:** Periodically inspect the adapter and cables for any signs of damage, such as frayed wires or cracked casing. Discontinue use if damage is found.

7. Troubleshooting

If you encounter issues with your adapter, refer to the following table:

Problem	Possible Cause	Solution
Device not powering on.	Adapter not plugged in correctly. No power from outlet. Device not compatible.	Ensure all connections are secure. Test the outlet with another device. Verify device power requirements match adapter output.
Adapter feels hot.	Normal operation under load. Poor ventilation. Overload.	Ensure adequate airflow around the adapter. Disconnect if excessively hot. Verify device power draw is within adapter limits.
Flickering power/intermittent connection.	Loose connection. Damaged cable.	Check all cable connections. Inspect cables for damage. Replace if damaged.

8. Specifications

Technical specifications for the onerbl 18V AC/DC Adapter (Model IVP1800-2500):

Feature	Detail
Model Number	IVP1800-2500
Input Voltage	AC 100-240V, 50/60Hz
Output Voltage	DC 18V
Color	Black
Plug Format	Type A
Manufacturer	Shenzhen Waweis Technology Co., Ltd



Image: Detailed dimensions of the adapter and its connected cables. The total cable length is approximately 127.8 inches, with the DC output cable being 44.3 inches and the AC input cable being 79.3 inches. The adapter body measures 4.2 inches in length and 1.8 inches in width.

9. Warranty and Support

For warranty information or technical support, please refer to the retailer's return policy or contact the manufacturer directly. Keep your purchase receipt as proof of purchase.

Return Policy: This product typically comes with a 30-day return/replacement policy from the date of purchase.

© 2023 onerbl. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C7441PRG

More documents and user manuals: **https://manuals.plus/**