SENIX Cordless Grass String Trimmer Edger Tool

SENIX 20V 10" Cordless Weed Wacker Instruction Manual

Model: GTX2-M (Cordless Grass String Trimmer Edger Tool) | Brand: SENIX

1. Introduction

Thank you for choosing the SENIX 20V 10" Cordless Weed Wacker. This versatile tool is designed for efficient and reliable lawn care, offering both trimming and edging capabilities. Its powerful brushless motor ensures consistent performance, while the telescopic shaft and adjustable head provide ergonomic comfort and ease of use. This manual provides essential information for the safe and effective operation, assembly, and maintenance of your new tool.

What's Included:

- String trimmer
- 2.5Ah lithium-ion battery
- 2A charger
- Auxiliary handle mounting hardware
- Head shield
- Mounting screw



The SENIX 20V 10" Cordless Weed Wacker, including the main unit, battery, and charger.

2. Safety Information

WARNING: To reduce the risk of injury, the user must read this instruction manual thoroughly before operation.

WARNING: Do NOT connect any power (battery) before making any adjustments or performing maintenance on the tool.

Personal Protective Equipment (PPE):

Always wear appropriate personal protective equipment when operating the weed wacker. This includes, but is not limited to, safety glasses, hearing protection, long pants, sturdy footwear, and protective gloves.



It is recommended to wear protective gloves during assembly and operation.

3. Setup and Assembly

Follow these steps to assemble your SENIX Cordless Weed Wacker. Ensure the battery is removed before beginning assembly.

3.1 Unpacking

Carefully open the product box and remove all components. Inspect for any damage. Refer to the included parts list to ensure all items are present.



The main components of the trimmer after unpacking.

3.2 Shaft Assembly

1. Align the middle pipe with the lower pipe, ensuring the internal wiring is not pinched.
2. Push the pipes together until they click into place, securing the connection.
3. Repeat the process for the upper pipe, connecting it to the middle pipe.

3.3 Guard Installation

1. Position the head shield over the trimmer head, aligning the tabs and slots.
2. Press firmly until the guard snaps securely into place.
3. Ensure the guard is properly seated and does not wobble.

3.4 Battery Installation/Removal

To install the battery, slide it into the battery slot on the tool handle until it clicks securely. To remove, press the unlock button on the battery and slide it out.



The 20V MAX Lithium Ion Battery for your SENIX tool.

Assembly Video Guide:

This video provides a detailed guide on unpacking and assembling the SENIX 20V Cordless Grass String Trimmer and Edger, including connecting the shaft sections, installing the guard, and attaching the battery.

4. Operating Instructions

Your SENIX Cordless Weed Wacker is designed for ease of use and versatility in various lawn care tasks.

4.1 Powering On/Off

To operate the tool, first ensure the battery is securely installed. Press the safety switch (usually a button or lever) and then squeeze the trigger to start the motor. Release the trigger to turn off the tool.

4.2 Adjustable Head and Handle

The auxiliary handle can be adjusted for improved ergonomics and comfort during operation. The trimmer head also features an adjustable angle, allowing you to customize it for different cutting needs.



The adjustable head and auxiliary handle allow for ergonomic operation and precise cutting angles.

4.3 Telescoping Shaft

The telescoping shaft allows for easy adjustment of the tool's length, accommodating users of different heights and improving reach in various situations. This also aids in compact storage.



Key features of the trimmer, including the telescoping shaft for adjustable length.

4.4 2-in-1 Trimming & Edging

This tool offers a 2-in-1 function, allowing you to switch between trimming and edging modes. The 360-degree turn capability enables precise cuts for both tasks.



Easily switch between trimming and edging for a clean lawn finish.

4.5 Auto Line Feed

The trimmer features an automatic line feed system, which advances the .065" trimmer line as needed without manual intervention, ensuring continuous cutting performance.



The auto line feed system ensures continuous cutting without manual line advancement.

Operation Demonstration Video:

This video demonstrates the SENIX 20V Cordless Grass String Trimmer in action, showcasing its trimming and edging capabilities.

5. Maintenance

Regular maintenance ensures the longevity and optimal performance of your SENIX weed wacker.

5.1 Battery Charging

The 2.5Ah lithium-ion battery can fully charge in approximately 90 minutes. Always ensure the battery is fully charged before use for optimal run time (up to 38 minutes).



The 2.5Ah battery provides ample runtime for typical lawn care tasks.

5.2 Cleaning and Storage

- After each use, disconnect the battery and clean the trimmer head and guard to remove grass clippings and debris.
- Use a dry cloth or soft brush for cleaning. Do not use harsh chemicals or abrasive materials.
- Store the tool in a dry, secure location, away from direct sunlight and extreme temperatures.

6. Troubleshooting

If you encounter any issues with your SENIX Cordless Weed Wacker, please refer to the following general advice:

- **Tool not starting:** Ensure the battery is fully charged and properly inserted. Check that the safety switch is engaged before pressing the trigger.
- **Poor cutting performance:** Check the trimmer line for wear or breakage. Ensure the line is feeding correctly.
- **Unusual noise or vibration:** Discontinue use immediately. Check for loose parts, damaged components, or obstructions in the cutting head.

For more detailed troubleshooting or persistent issues, please contact SENIX customer support.

7. Specifications

Feature	Detail
Brand	SENIX
Model Number	Cordless Grass String Trimmer Edger Tool (GTX2-M)
Power Source	Battery Powered (20V Max)
Battery Type	1 Lithium Ion battery required (included)
Battery Capacity	2.5 Ah
Charging Time	Approx. 90 minutes
Item Weight	4.32 Pounds
Cutting Width	10 Inches
Product Dimensions	38.98"L x 9.84"W
Speed	7000 RPM
Assembly Required	Yes
Cordless	Yes
Recommended Uses	Edging, Trimming
Country of Origin	China

8. Warranty and Support

Your SENIX 20V 10" Cordless Weed Wacker comes with a**5-year limited warranty** for peace of mind. This warranty covers defects in materials and workmanship under normal use.

Customer Support:

For warranty claims, technical assistance, or any questions regarding your product, please visit the official SENIX website or contact their customer service department. Keep your purchase receipt as proof of purchase for warranty purposes.

Visit the SENIX Store for more information and product accessories.

© 2025 SENIX. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question