Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit RC-1236

ZdalaMit RC-1236 Replacement Remote Control User Manual

For Denon Sound Bar Models: DHT-S216, DHT-S216H, DHT-S517

1. Introduction

This manual provides instructions for the ZdalaMit RC-1236 Replacement Remote Control. This remote is designed to function as a direct replacement for the original remote controls of specific Denon Sound Bar models, offering immediate usability without complex setup procedures. It is compatible with Denon Sound Bar models DHT-S216, DHT-S216H, and DHT-S517.

2. Package Contents

- 1x ZdalaMit RC-1236 Replacement Remote Control

Note: Batteries and additional manuals are not included in the package.

3. Setup

3.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two (2) 1.5V AAA Alkaline batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery compartment cover securely.



Image: Rear view of the RC-1236 remote control, illustrating the location of the battery compartment for AAA battery insertion.

Important: Ensure batteries are inserted correctly. Incorrect polarity can prevent the remote from functioning.

4. Operating Instructions

The ZdalaMit RC-1236 remote control requires no programming. Once batteries are installed, it is ready for immediate use with compatible Denon Sound Bar models.

4.1 Compatible Models

- Denon DHT-S216 Sound Bar
- Denon DHT-S216H Sound Bar

- Denon DHT-S517 Sound Bar

4.2 Button Functions





Image: Front view of the RC-1236 remote control, displaying all functional buttons.

Button	Function
Power ( )	Turns the sound bar on or off.
Mute ( )	Mutes or unmutes the sound.
TV	Selects TV audio input.
HDMI	Selects HDMI audio input.
AUX	Selects Auxiliary audio input.
DTS Virtual:X	Activates or deactivates DTS Virtual:X surround sound mode.
PURE	Activates or deactivates Pure audio mode.
BASS (+/-)	Adjusts the bass level.
VOL (+/-)	Adjusts the main volume level.
MOVIE	Selects Movie sound mode.
NIGHT	Selects Night sound mode.
MUSIC	Selects Music sound mode.
DIALOG ENHANCER (LOW, MED, HIGH)	Adjusts the dialog enhancement level.

5. Maintenance

5.1 Cleaning

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these may damage the remote's surface or internal components.

5.2 Battery Replacement

Replace batteries when the remote's response becomes inconsistent or stops working. Always replace both batteries at the same time with new 1.5V AAA Alkaline batteries. Remove batteries if the remote will not be used for an extended period to prevent leakage.

6. Troubleshooting

6.1 Remote Not Responding

- **Check Batteries:** Ensure batteries are correctly inserted with the proper polarity and are not depleted. Replace with new batteries if necessary.
- **Line of Sight:** Make sure there is a clear line of sight between the remote control and the sound bar's infrared receiver. Obstructions can block the signal.
- **Distance:** Operate the remote within the effective range of the sound bar.
- **Compatibility:** Verify that your Denon Sound Bar model is listed as compatible (DHT-S216, DHT-S216H, DHT-S517).

7. Specifications

Feature	Detail
Model	RC-1236
Compatibility	Denon Sound Bar DHT-S216, DHT-S216H, DHT-S517
Power Supply	2 x 1.5V AAA Alkaline Batteries
Dimensions (L x W x H)	5.9 x 1.57 x 0.55 inches (approximately)
Item Weight	1.41 ounces (approximately, without batteries)
Special Feature	Pre-programmed, no setup required

8. Warranty and Support

For any questions or support regarding your ZdalaMit RC-1236 Replacement Remote Control, please contact the seller or manufacturer directly. Specific warranty details may vary and are typically provided at the point of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C77C5WZX

More documents and user manuals: **https://manuals.plus/**