Oster TSSTTVFDMAF

Oster TSSTTVFDMAF Extra Large French Door Oven with Air Fryer User Manual

Model: TSSTTVFDMAF

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before operating this appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “OFF,” then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Oversized foods or metal utensils must not be inserted in a toaster oven as they may create a fire or risk of electric shock.
- A fire may occur if the oven is covered or touching flammable material, including curtains, drapes, walls, and the like, when in operation.
- Do not place any of the following materials in the oven: paper, cardboard, plastic, and the like.
- Do not store any materials, other than manufacturer’s recommended accessories, in this oven when not in use.

- Do not place cooking utensils or baking dishes on the glass door.
- Do not clean with metal scouring pads. Pieces can break off the pad and touch electrical parts, creating a risk of electric shock.
- Do not attempt to dislodge food when the oven is plugged into an electrical outlet.
- Do not operate without the crumb tray properly installed.

Product Overview

The Oster TSSTTVFDMAF Extra Large French Door Oven with Air Fryer is a versatile kitchen appliance designed for various cooking tasks, including air frying, baking, toasting, and broiling. It features a spacious interior and convenient French doors.



Front view of the Oster Extra Large French Door Oven with Air Fryer.

Key Features and Controls



This diagram highlights the main features: an interior light, adjustable temperature control up to 230°C, five pre-programmed cooking functions, convenient French doors, a non-stick interior coating for easy cleaning, and a 60-minute timer.

- **French Doors:** Open simultaneously for easy access to the oven interior.
- **Temperature Control Dial:** Adjusts cooking temperature up to 230°C (450°F).
- **Function Dial:** Selects cooking modes such as Toast, Bake, Broil, Air Fry, and Turbo Convection.
- **Timer Dial:** Sets cooking time up to 60 minutes with an audible signal. Includes a stay-on option.
- **Interior Light:** Illuminates the oven cavity for easy viewing of food.
- **Non-Stick Interior:** Facilitates easy cleaning after use.
- **Accessories:** Includes a baking pan, wire rack, and air fry basket.

Setup

Unpacking and Placement

1. Carefully remove the oven and all accessories from the packaging.

2. Remove any packing materials, stickers, or protective films from the oven and its accessories.
3. Place the oven on a flat, stable, heat-resistant surface, ensuring at least 15 cm (6 inches) of clearance on all sides and above the oven for proper ventilation.
4. Ensure the power cord is not obstructed or pinched.

Initial Cleaning and First Use

1. Before first use, wipe the interior of the oven with a damp cloth. Wash the baking pan, wire rack, and air fry basket in warm, soapy water. Rinse and dry thoroughly.
2. To eliminate any manufacturing odors, operate the oven empty for approximately 15 minutes on the "Bake" function at 200°C (400°F). A slight odor and smoke are normal during this initial use. Ensure the area is well-ventilated.
3. Allow the oven to cool completely before storing or using it for cooking.

Operating Instructions

This oven offers multiple cooking functions to prepare a variety of dishes. Always preheat the oven for optimal results, especially for baking and air frying.

General Operation

1. Place the wire rack or air fry basket in the desired position within the oven.
2. Place food on the appropriate accessory (baking pan, wire rack, or air fry basket).
3. Close the French doors securely.
4. Plug the oven into a standard electrical outlet.
5. Turn the **Function Dial** to select the desired cooking mode.
6. Turn the **Temperature Control Dial** to set the desired temperature.
7. Turn the **Timer Dial** to the desired cooking time. The oven will begin cooking. A bell will sound when the timer reaches zero.
8. To stop cooking before the timer expires, turn the Timer Dial to the "OFF" position.
9. Always use oven mitts when removing food or accessories from the hot oven.

Cooking Functions



The oven features five pre-programmed functions: Toast, Bake, Broil, Turbo Convection, and Air Fry.

- **Toast:** Ideal for bread, bagels, and frozen waffles. Place items directly on the wire rack. Adjust the temperature dial to the toast setting (usually indicated by a toast icon or specific temperature for toasting). Set the timer for desired browning.
- **Bake:** For cakes, cookies, casseroles, and other baked goods. Use the baking pan on the wire rack. Select the BAKE function, set the desired temperature, and set the timer according to your recipe.
- **Broil/Roast:** Perfect for meats, poultry, and vegetables that require direct top heat. Place food on the baking pan on the top rack position. Select the BROIL function and set the temperature. Monitor food closely to prevent burning.
- **Air Fry:** For crispy foods like fries, chicken wings, and vegetables with little to no oil. Use the air fry basket placed on the wire rack. Select the AIR FRY function, set the temperature (typically higher than baking), and set the timer. Shake or flip food halfway through cooking for even crisping.
- **Turbo Convection:** Utilizes a fan to circulate hot air, resulting in faster and more even cooking. This function can be used with BAKE or ROAST settings. Select the desired cooking function (e.g., BAKE), then select the TURBO CONVECTION option. Adjust temperature and time as needed, often reducing cooking time compared to conventional baking.

Care and Maintenance

Proper care and maintenance will ensure the longevity and optimal performance of your oven.

Cleaning Instructions



The non-stick interior coating allows for easy cleaning with a damp cloth.

1. Always unplug the oven from the electrical outlet and allow it to cool completely before cleaning.
2. **Exterior:** Wipe the exterior surfaces with a damp cloth and mild detergent. Do not use abrasive cleaners or scouring pads, as they may scratch the finish.
3. **Interior:** The non-stick interior can be wiped clean with a damp cloth and mild detergent. For stubborn stains, a non-abrasive sponge can be used. Avoid using metal scouring pads or harsh chemicals.
4. **Crumb Tray:** Pull out the crumb tray from the bottom front of the oven. Discard crumbs and wash the tray in warm, soapy water. Rinse and dry thoroughly before replacing.

5. **Accessories (Baking Pan, Wire Rack, Air Fry Basket):** Wash these accessories in warm, soapy water. They are generally not dishwasher safe unless specified. Rinse and dry thoroughly.
6. Do not immerse the oven body, cord, or plug in water or any other liquid.

Troubleshooting

If you encounter issues with your oven, refer to the following common problems and solutions:

- **Oven does not turn on:**
  - Ensure the oven is securely plugged into a working electrical outlet.
  - Check if the timer is set. The oven will not operate if the timer is at the "OFF" position.
  - Verify that the function and temperature dials are set correctly.
- **Food not cooking evenly:**
  - Preheat the oven for at least 5-10 minutes before placing food inside.
  - Ensure food is placed in the center of the rack and not overcrowded.
  - For air frying, shake or flip food halfway through cooking.
  - Consider using the Turbo Convection function for more even heat distribution.
- **Smoke or unusual odor during operation:**
  - A slight odor and smoke are normal during the first few uses. Ensure good ventilation.
  - Excessive smoke may indicate food residue or grease buildup. Unplug the oven, allow it to cool, and clean the interior and accessories thoroughly.
  - Ensure no packaging materials or foreign objects are inside the oven.
- **Doors not closing properly:**
  - Check for any obstructions preventing the doors from closing fully.
  - Ensure the oven is on a level surface.

If the problem persists after attempting these solutions, please contact Oster customer service for assistance.

Specifications

Detailed technical specifications for the Oster TSSTTVFDMAF Extra Large French Door Oven with Air Fryer.



Product dimensions: 60.5 cm (Width) x 51.2 cm (Depth) x 38.4 cm (Height).

Attribute	Value
Brand	Oster
Model Name	TSSTTVFDMAF
Model Number	2177237
Colour	Metallic Silver
Capacity	42 Liters
Power/Wattage	1500 watts
Product Dimensions (D x W x H)	51.2 cm x 60.5 cm x 38.4 cm
Item Weight	12 kg
Special Features	Timer, Air Fry, French Doors, Non-stick interior
Included Components	Oven, Baking Pan, Wire Rack, Air Fry Basket

Warranty and Support

This Oster appliance comes with a limited warranty. Please refer to the warranty card included with your product for specific terms and conditions, including the warranty period and coverage details.

For technical support, service, or to inquire about replacement parts, please visit the official Oster website or contact their customer service department. Contact information can typically be found in the product packaging or on the manufacturer's website.

Please have your model number (TSSTTVFDMAF or 2177237) and proof of purchase available when contacting customer service.

© 2026 Oster. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question