Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY CV-100004118-SH

ALLIMITY 100004118 Replacement Remote Control User Manual

Model: CV-100004118-SH

Introduction

This manual provides essential information for the proper use and maintenance of your ALLIMITY 100004118 Replacement Remote Control. This remote is designed as a direct replacement for the original remote control of the ONN 32 Inch 2.1 Soundbar & Wireless Subwoofer System (model 100004118). It offers easy operation without the need for complex setup or programming.



Image: The ALLIMITY 100004118 Replacement Remote Control shown in a typical home entertainment environment, demonstrating its intended use with a soundbar and television.

Setup

The ALLIMITY 100004118 Replacement Remote Control is designed for immediate use upon battery installation. No additional programming or pairing is required for operation with compatible ONN soundbar systems.

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or in the direction indicated by an arrow to open it.
3. Insert two AAA alkaline batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery cover by sliding it back into position until it clicks securely.





Image: The rear of the remote control with the battery cover removed, illustrating the correct orientation for battery insertion.

Operating Instructions

Point the remote control directly at the ONN soundbar system's infrared receiver. Ensure there are no obstructions between the remote and the soundbar.





Image: A direct overhead view of the remote control, highlighting the layout and labeling of its various function buttons.

Button Functions

Button	Function
Power ( )	Turns the soundbar system on or off.
VOL + / **-**	Adjusts the master volume level up or down.
TREB + / **-**	Increases or decreases the treble audio level.
BASS + / **-**	Increases or decreases the bass audio level.
Play/Pause ( )	Plays or pauses the current audio track.
Previous Track ( )	Skips to the beginning of the current track or the previous track.
Next Track ( )	Skips to the next audio track.
Mute ( )	Mutes or unmutes the soundbar audio output.
Bluetooth ( )	Switches the soundbar to Bluetooth input mode.

Button	Function
Source (↷)	Cycles through available input sources (e.g., HDMI, Optical, AUX).

Maintenance

Battery Replacement

Replace batteries when the remote's range decreases or buttons become unresponsive. Always replace both batteries simultaneously with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning

To clean the remote control, gently wipe the surface with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed immediately by a dry cloth. Do not use abrasive cleaners, solvents, or chemical sprays, as these can damage the remote's finish or internal components.

Storage

Store the remote control in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity. If the remote will not be used for an extended period, it is recommended to remove the batteries to prevent leakage and potential damage.

Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA alkaline batteries.
  - Ensure there are no obstructions between the remote control and the soundbar's infrared receiver.
  - Confirm you are within the effective operating range of the soundbar.
- **Specific buttons not working:**
  - Clean the remote's surface, especially around the unresponsive buttons, to remove any dirt or debris that might be preventing proper contact.
  - If only certain buttons are affected, and battery replacement does not resolve the issue, the remote may require replacement.

Specifications

- **Model:** CV-100004118-SH
- **Compatible Model:** ONN 32 Inch 2.1 Soundbar & Wireless Subwoofer System (100004118)
- **Brand:** ALLIMITY
- **Connectivity Technology:** Infrared (IR)
- **Power Source:** 2 x AAA Batteries (not included)
- **Product Dimensions:** 6.5 x 1.38 x 0.72 inches (16.51 x 3.51 x 1.83 cm)
- **Item Weight:** 1.44 ounces (40.82 grams)
- **Special Feature:** Ergonomic design

Warranty and Support

For any issues or inquiries regarding your ALLIMITY 100004118 Replacement Remote Control, please refer to the seller's return policy or contact the seller directly through the platform where the purchase was made. Specific warranty details may vary by retailer.

© 2024 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C7GPBG7B

More documents and user manuals: **https://manuals.plus/**