Belife OLED55C19LA, OLED55CX6LA, OLED55G16LA, OLED55G19LA, OLED55G1RLA, OLED65A19LA, OLED65B19LA

Belife Replacement Remote Control User Manual

Model: OLED55C19LA, OLED55CX6LA, OLED55G16LA, OLED55G19LA, OLED55G1RLA, OLED65A19LA, OLED65B19LA

1. Introduction

Thank you for purchasing the Belife Replacement Remote Control. This manual provides detailed instructions on how to set up, operate, and maintain your new remote control. Please read this manual carefully before use to ensure proper functionality and to extend the lifespan of your device.

2. Product Overview

2.1 Key Features

- Powerful Magic Remote Control with dots, click, and scroll functions.
- Voice control capability.
- Six dedicated hotkeys: NETFLIX, Prime Video, Disney+, Rakuten TV, Alexa, Google Assistant.
- Accurate control and fast response with upgraded smart chip.
- Over 30 feet transmission distance.
- Easy pairing process.

2.2 Remote Control Layout

Familiarize yourself with the buttons and their functions on your new remote control.



Figure 1: Front view of the Belife Replacement Remote Control, showing all buttons including number pad, volume/channel controls, navigation wheel, and hotkeys for streaming services and voice assistants.



Figure 2: Belife Remote Control with arrows pointing to the microphone button for voice control and the central navigation wheel for mouse control.



Figure 3: Side and front view of the Belife Remote Control, illustrating its ergonomic design and approximate dimensions (19cm length, 4cm width, 3cm thickness).

3. Setup

3.1 Battery Installation

The remote control requires 2 AA batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery cover.
3. Insert two AA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.

4. Close the battery cover securely.

3.2 Pairing the Remote Control with Your TV

Follow these steps to pair your new Belife remote control with your LG TV:

1. Ensure your LG TV is turned on.
2. Insert 2 AA batteries into the remote control as described in Section 3.1.
3. After approximately 20 seconds, point the remote control directly towards your TV.
4. Press the **Wheel (OK)** button located in the center of the navigation pad.
5. The remote control will automatically attempt to register with your TV. A pairing completion message should appear on your TV screen once successful.

Note: If the remote does not pair immediately, ensure there are no obstructions between the remote and the TV's infrared receiver. You may also try removing and reinserting the batteries, then repeating the pairing steps.

4. Operating Instructions

4.1 Basic Functions

- **Power Button** ( ): Turns the TV on or off.
- **Number Pad (0-9)**: Directly input channel numbers or other numerical data.
- **Volume Up/Down** (+ / -): Adjusts the TV volume.
- **Channel Up/Down** (⌃ / ⌄): Changes TV channels.
- **Mute Button** ( ): Mutes or unmutes the TV sound.
- **Home Button** ( ): Accesses the TV's home screen or smart hub.
- **Back Button** (↩): Returns to the previous screen or menu.
- **Settings Button** (⚙): Opens the TV's settings menu.

4.2 Magic Remote Functions (Pointer and Scroll)

The remote control features a "Magic Remote" functionality, allowing you to use a pointer on the screen and scroll through content.

- **Pointer Activation**: Simply shake the remote gently or press any button (except Power) to activate the on-screen pointer.
- **Moving the Pointer**: Move the remote control in the air to move the pointer on the TV screen.
- **Clicking/Selecting**: Press the **Wheel (OK)** button to select an item pointed to on the screen.
- **Scrolling**: Rotate the **Wheel (OK)** button to scroll through lists or web pages.

4.3 Voice Control

The remote control supports voice commands for easier navigation and content search.

1. Press and hold the **Microphone Button** ( ).
2. Speak your command clearly into the microphone at the top of the remote control.
3. Release the button when you are finished speaking.

Examples of commands: "Open Netflix", "Search for action movies", "What's the weather like?", "Change to channel 5".

4.4 Hotkeys

Quickly access popular streaming services and voice assistants using the dedicated hotkeys:

- **NETFLIX**: Launches the Netflix application.
- **Prime Video**: Launches the Amazon Prime Video application.
- **Disney+**: Launches the Disney+ application.
- **Rakuten TV**: Launches the Rakuten TV application.
- **Alexa**: Activates the Alexa voice assistant.
- **Google Assistant**: Activates the Google Assistant.

5. Maintenance

To ensure the longevity and optimal performance of your remote control, follow these maintenance guidelines:

- **Cleaning**: Wipe the remote control regularly with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals or abrasive materials.
- **Battery Replacement**: Replace batteries when the remote control's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new ones of the same type (AA).
- **Storage**: Store the remote control in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Drops**: Protect the remote control from physical shocks and drops, as this can damage internal components.

6. Troubleshooting

If you experience issues with your remote control, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Remote control not responding.	Dead or incorrectly inserted batteries.	Replace batteries with new AA batteries, ensuring correct polarity.
Remote control not pairing with TV.	Obstruction between remote and TV; TV not on; pairing process not followed correctly.	Ensure clear line of sight. Turn TV on. Re-attempt pairing as per Section 3.2.
Magic pointer not appearing or erratic.	Remote not activated; low batteries; interference.	Gently shake the remote or press a button to activate. Replace batteries. Minimize interference from other devices.
Voice control not working.	Microphone button not held; internet connection issue on TV; TV settings.	Ensure microphone button is held while speaking. Check TV's internet connection. Verify TV's voice recognition settings.
Hotkeys not launching apps.	App not installed on TV; TV not connected to internet.	Ensure the specific app is installed on your LG TV. Check TV's internet connection.

If the problem persists after trying these solutions, please contact customer support.

7. Specifications

Feature	Detail

Feature	Detail
Brand	Belife
Compatible Devices	LG TV models: OLED55C19LA, OLED55CX6LA, OLED55G16LA, OLED55G19LA, OLED55G1RLA, OLED65A19LA, OLED65B19LA
Connectivity Technology	Infrared
Controller Type	Voice Control, Magic Remote (Pointer, Scroll)
Maximum Range	10 Meters (approx. 30 feet)
Batteries Required	2 x AA (not included)
Dimensions (approx.)	19 cm (Length) x 4 cm (Width) x 3 cm (Thickness)
Weight (approx.)	80 g

8. Warranty and Support

Belife offers a 2-year guarantee on this product. For any questions, technical support, or warranty claims, please contact Belife customer service through the retailer where you purchased the product or refer to the contact information provided with your purchase.
Manufacturer: BELIFE

© 2024 Belife. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question