Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

EconoHome EconoHome Folding Bed (31 Inch Model)

EconoHome 31-Inch Folding Bed with 5-inch Memory Foam Mattress

INSTRUCTION MANUAL

1. Introduction

Thank you for choosing the EconoHome 31-Inch Folding Bed. This portable rollaway bed is designed to provide a comfortable sleeping solution for guests or for use in small spaces. Its foldable design and memory foam mattress offer convenience and support. Please read this manual thoroughly before assembly and use to ensure proper setup and safe operation.

2. Safety Information

WARNING: To prevent serious injury, always follow these safety guidelines.

- Ensure bed stability, adhere to the 300 lbs weight limit, and be cautious around the wheels to prevent tipping or tripping hazards.
- Do not allow children to play on or around the bed unsupervised.
- Ensure all locking mechanisms are engaged before use.
- Keep hands and fingers clear of moving parts during folding and unfolding.
- Do not use the bed if any parts are damaged or missing. Contact customer support for replacement parts.

3. Package Contents

Verify that all components are present before beginning assembly:

- Folding Bed Frame (1)
- 5-inch Memory Foam Mattress (1)
- Assembly Manual (1)
- Tools and Screws (as required for assembly)

4. Setup Instructions

The EconoHome Folding Bed is designed for quick and easy assembly, typically completed in 7 simple steps. We recommend two people for setup.

1. **Unpack Components:** Carefully remove all items from the packaging.
2. **Position the Folded Frame:** Place the folded bed frame in the desired location. The bed comes with 4 smooth-rolling wheels for easy transport.
3. **Unfold the Frame:** Gently pull the two halves of the bed frame apart until it is fully extended. Ensure the support legs automatically deploy and lock into place.
4. **Secure the Frame:** Verify that all frame connections are secure and stable. The full-steel wire lattice frame is designed for durability and to support up to 300 lbs.
5. **Place the Mattress:** Unroll and place the 5-inch memory foam mattress onto the unfolded bed frame. Allow the mattress to fully expand, which may take a few hours.
6. **Prepare for Use:** The bed is now ready for use.



Image: The EconoHome Folding Bed with its 5-inch memory foam mattress, fully unfolded and ready for use in a room setting.



Image: A visual representation highlighting the sturdy and durable material of the bed frame, along with its open and closed dimensions.



Image: A close-up view of the 5-inch memory foam mattress, emphasizing its soft and comfortable texture.

5. Operating Instructions (Folding and Unfolding)

The EconoHome Folding Bed is designed for easy storage and portability.

1. **To Fold:**
    - Remove any bedding from the mattress.
    - Locate the locking mechanisms on the side of the frame. Disengage them to allow the frame to fold.
    - Gently lift one end of the bed and push the two halves together. The frame will fold in half, and the support legs will retract.
    - Secure the folded bed with the integrated buckle or strap to prevent it from opening accidentally during storage or transport.
2. **To Unfold:**

- Release the securing buckle/strap.
- Gently pull the two halves of the bed frame apart. The support legs should automatically extend and lock into position.
- Ensure the frame is fully extended and stable before placing the mattress or using the bed.



Image: Visual guide detailing the steps to easily assemble and store the folding bed, including buckle and metal hook closing strap.



Image: The EconoHome Folding Bed with its mattress, compactly folded and standing upright on its wheels, ready for storage.

Official Product Video: Folding Bed Overview

Your browser does not support the video tag.

Video: This official product video demonstrates the ease of folding and unfolding the EconoHome bed, highlighting its portability, high-quality materials, sturdy construction, and soft memory foam mattress. It also shows the bed in various settings, emphasizing its compact comfort for every occasion.

6. Maintenance

- **Mattress Care:** The memory foam mattress cover is designed for dry cleaning only. Do not machine wash or tumble dry.
- **Frame Care:** Wipe the metal frame with a damp cloth and mild detergent as needed. Ensure it is completely dry

before folding for storage.

- **Regular Inspection:** Periodically check all screws and connections to ensure they are tight and secure.

7. Troubleshooting

- **Issue: The bottom part of the bed frame detaches or does not stay connected.**
  Solution: This issue can occur if the locking mechanisms on the support legs are not fully engaged or if the frame is not properly aligned during unfolding. Ensure that when unfolding the bed, the support legs click firmly into their locked position. If the issue persists, inspect the hinges and locking pins for any damage or obstruction. If damage is found, discontinue use and contact EconoHome customer support for assistance.
- **Issue: Wheels are not rolling smoothly.**
  Solution: Check for any debris or hair caught in the wheel casters. Clean them thoroughly. Ensure the wheel locks are disengaged when attempting to roll the bed.
- **Issue: Mattress is not expanding fully.**
  Solution: Allow up to 48-72 hours for the memory foam mattress to fully decompress after unpacking. Ensure it is laid flat in a well-ventilated area.

8. Specifications

Feature	Detail
Size	31 Inch
Special Feature	Durability, Foldable, Portable
Color	Black
Product Dimensions (Unfolded)	75"L x 38"W x 17"H
Brand	EconoHome
Included Components	Mattress
Finish Type	Powder Coated
Weight Limit	300 Pounds
Item Weight	40 Pounds
Age Range (Description)	Adult
Product Care Instructions	Dry Clean Only (for mattress cover)
Assembly Required	Yes
Form Factor	Foldable
Ground To Item Distance	12 Inches
Frame Material	Metal

9. Warranty and Support

The EconoHome Folding Bed comes with a limited warranty. For specific details regarding your warranty coverage, please refer to the documentation included with your purchase or visit the official EconoHome website.

If you encounter any issues, require replacement parts, or have questions not addressed in this manual, please contact EconoHome customer support for assistance. Contact information can typically be found on the product packaging or the brand's official website.

© 2025 EconoHome. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C7JG2J6K

More documents and user manuals: **https://manuals.plus/**