Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ECONTROLLY 100004118

User Manual

ECONTROLLY Replacement Remote Control for Onn Soundbar

Model: 100004118

1. Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your ECONTROLLY 100004118 Replacement Remote Control. This remote is specifically designed to work with Onn Soundbar model 100004118, offering a direct replacement without the need for programming.

2. Product Overview

The ECONTROLLY 100004118 remote control is an infrared device engineered for seamless compatibility with the specified Onn Soundbar. It features a standard layout for easy navigation and control of your sound system's functions.





Figure 2.1: Front view of the ECONTROLLY 100004118 Replacement Remote Control.

Key buttons and their functions:

- **Power Button** ( ): Turns the soundbar on or off.
- **VOL +** / **VOL -**: Increases or decreases the master volume.
- **TREB +** / **TREB -**: Adjusts the treble level.
- **BASS +** / **BASS -**: Adjusts the bass level.
- **Mute Button** ( ): Mutes or unmutes the sound.
- **Bluetooth Button** ( ): Activates Bluetooth pairing mode or switches to Bluetooth input.
- **Play/Pause Button** (▶‖): Plays or pauses media playback.
- **Previous Track Button** ( ): Skips to the previous track.

- **Next Track Button** ( ): Skips to the next track.
- **Input/Source Button** ( ): Cycles through available input sources.

3. Setup

The remote control requires two AAA ALKALINE batteries for operation. Rechargeable batteries are not recommended.



Figure 3.1: Angled view of the remote control, indicating the general area for battery compartment on the rear.

Battery Installation:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover downwards to open.
3. Insert two AAA ALKALINE batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.

Important: Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.

4. Operating Instructions

This remote control is pre-programmed and ready to use with your Onn 100004118 Soundbar immediately after battery installation. Point the remote directly at the soundbar's infrared receiver.

- **Power On/Off:** Press the button to turn the soundbar on or off.
- **Volume Control:** Use the **VOL +** and **VOL -** buttons to adjust the sound volume.
- **Treble/Bass Adjustment:** Use the **TREB +** / **TREB -** and **BASS +** / **BASS -** buttons to fine-tune the audio's treble and bass levels.
- **Mute Function:** Press the button to temporarily silence the sound. Press again to restore sound.
- **Input Selection:** Press the button to cycle through the available input sources (e.g., Optical, AUX, Bluetooth).
- **Bluetooth Pairing/Selection:** Press the button to switch to Bluetooth mode or initiate pairing if the soundbar is in pairing mode.
- **Playback Controls:** When in a media playback mode (e.g., Bluetooth), use ▶‖ for play/pause, for previous track, and for next track.

5. Maintenance

To ensure the longevity and optimal performance of your remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and damage.

6. Troubleshooting

If you experience issues with your remote control, refer to the table below for common problems and solutions:

Problem	Possible Cause	Solution
Remote not working	Dead or incorrectly inserted batteries.	Replace batteries with new AAA ALKALINE batteries, ensuring correct polarity.
Remote works intermittently	Low battery power; Obstruction between remote and soundbar.	Replace batteries. Ensure a clear line of sight to the soundbar's IR receiver.
Specific buttons not responding	Dirty contacts; Remote damage.	Clean the remote surface. If damage is suspected, consider replacement.
Remote does not control soundbar	Incorrect soundbar model; Soundbar IR receiver blocked or faulty.	Verify your soundbar is Onn model 100004118. Check soundbar's IR receiver for obstructions.

7. Specifications

Feature	Detail
Product Dimensions	3.94 x 1.57 x 0.59 inches

Feature	Detail
Item Weight	1.06 ounces
Compatible Model	Onn 100004118 Soundbar
Battery Type	2 x AAA ALKALINE batteries (not included)
Connectivity Technology	Infrared (IR)
Special Feature	Pre-programmed, no setup required

8. Warranty and Support

Specific warranty information for this product is not provided in the available documentation. For any questions, technical support, or issues not covered in this manual, please contact the seller or manufacturer directly through your purchase platform.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C7K6NWVH

More documents and user manuals: **https://manuals.plus/**