Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY QYSY-LED-55Z1UHD-SMART-QYSY

ALLIMITY Replacement Remote Control User Manual

Model: QYSY-LED-55Z1UHD-SMART-QYSY

1. Introduction

This manual provides instructions for the ALLIMITY Replacement Remote Control, designed to operate various SMART-TECH and ARIELLI television models. This remote control offers full functionality without the need for programming, ensuring a straightforward user experience.

2. Product Overview

2.1 Remote Control Layout

The ALLIMITY replacement remote control features a standard layout for easy navigation and control of your television. Familiarize yourself with the button functions as illustrated below.





Image 1: Front view of the ALLIMITY replacement remote control, showing all buttons including power, number pad, volume, channel, menu, and navigation keys.





Image 2: Back view of the ALLIMITY replacement remote control, showing the battery compartment cover.

2.2 Key Button Functions

- **Power Button (Red)**: Turns the television on or off.
- **Number Pad (0-9)**: Directly selects channels.
- **Volume Up/Down (+/-)**: Adjusts the audio volume.
- **Channel Up/Down (CH+/-)**: Changes the television channel.
- **MENU**: Accesses the television's main menu.
- **Navigation Arrows (Up, Down, Left, Right)**: Navigates through menus and options.
- **ENTER**: Confirms selections in menus.
- **SOURCE**: Selects input sources (e.g., HDMI, AV).
- **EXIT**: Exits the current menu or function.

3. Setup

3.1 Battery Installation

The remote control requires two AAA batteries (not included) for operation.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring that the positive (+) and negative (-) terminals match the indicators inside the compartment.
4. Slide the battery cover back into place until it clicks securely.

No programming is required. The remote control is ready for immediate use once the batteries are correctly installed.

4. Operating Instructions

4.1 Basic Operation

To operate your television, point the remote control directly at the infrared sensor on your TV. Ensure there are no obstructions between the remote and the TV.

- Press the **Power** button to turn the TV on or off.
- Use the **Volume Up/Down** buttons to adjust the sound level.
- Use the **Channel Up/Down** buttons to change channels sequentially.
- To access the TV menu, press the **MENU** button. Use the **Navigation Arrows** to move through options and **ENTER** to select.

4.2 Compatible Models

This ALLIMITY replacement remote control is compatible with the following SMART-TECH and ARIELLI television models:

- 24HN90N1
- CH-50P28EL
- LE-3219NTS
- SMT32N40HC3L1B1
- SMT32Z10HC1L1B1
- SMT32Z30HC1L1B1

- LED-2219T2
- LED-2288FHD
- LED-32D9HD
- LED-32F2T2
- LED-4028T2
- LED-55Z1UHD-SMART

5. Maintenance

5.1 Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. Avoid using liquid cleaners, solvents, or abrasive materials, as these can damage the surface or internal components.

5.2 Battery Replacement

Replace the batteries when the remote control's response becomes inconsistent, the range decreases, or it stops functioning. Always replace both batteries simultaneously with new AAA batteries of the same type. Do not mix old and new batteries or different battery types.

6. Troubleshooting

6.1 Remote Control Not Responding

- **Check Battery Polarity:** Ensure that the AAA batteries are inserted correctly, matching the positive (+) and negative (-) indicators within the compartment.
- **Replace Batteries:** Install fresh AAA batteries. Depleted batteries are a common cause of remote control malfunction.
- **Clear Line of Sight:** Ensure there are no objects blocking the path between the remote control's infrared emitter and the TV's infrared receiver.
- **Test with Another Device (if applicable):** If possible, test the remote control with another compatible TV to confirm its functionality.

6.2 Limited Functionality

Ensure your specific TV model is listed in the 'Compatible Models' section (Section 4.2). While this remote is designed for broad compatibility, some highly specific or advanced functions may vary or not be fully supported depending on the exact television model.

7. Specifications

- **Brand:** ALLIMITY
- **Model Number:** QYSY-LED-55Z1UHD-SMART-QYSY
- **Connectivity Technology:** Infrared
- **Color:** Black
- **Special Feature:** No programming required
- **Maximum Range:** 10 Meters
- **Number of Buttons:** 15 (Note: Actual button count may vary slightly based on specific production batch, but core functionality remains consistent.)

- **Compatible Devices:** SMART-TECH, ARIELLI, and specific models listed in Section 4.2.

8. Warranty and Support

For warranty information or technical support regarding your ALLIMITY Replacement Remote Control, please refer to the retailer where the product was purchased or consult the manufacturer's official website. It is recommended to retain your purchase receipt as proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C7QF5R3Y

More documents and user manuals: **https://manuals.plus/**