ALLIMITY QYSY-Q32-009SB-QYSY

ALLIMITY Replacement Remote Control User Manual

Model: QYSY-Q32-009SB-QYSY

Introduction

This user manual provides comprehensive instructions for the ALLIMITY Replacement Remote Control. This remote is designed to function as a direct replacement for original remote controls of various AKAI, E-STAR, and QILIVE television models. It requires no programming and is ready for use upon battery installation.

Product Overview

The ALLIMITY replacement remote control is an infrared device designed for ease of use and broad compatibility. It features a standard layout with dedicated buttons for common television functions.





Image 1: Front view of the ALLIMITY replacement remote control, showing all buttons including power, number pad, volume, channel, menu, and navigation controls.



Image 2: Angled view of the ALLIMITY replacement remote control, highlighting its ergonomic design.





Image 3: Back view of the ALLIMITY replacement remote control, showing the battery compartment cover.

Setup

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two new AAA alkaline batteries (not included), ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Replace the battery compartment cover, ensuring it clicks securely into place.

The remote control is now ready for immediate use with compatible television models. No additional programming is required.

Operating Instructions

This remote control functions identically to the original remote for compatible TV models. Point the remote directly

at the television's infrared receiver for optimal performance.

Basic Functions

- **Power ( )**: Turns the television on or off.
- **Number Buttons (0-9)**: Directly select channels.
- **Volume Up/Down (VOL +/-)**: Adjusts the audio volume.
- **Channel Up/Down (CH +/-)**: Changes the television channel sequentially.
- **Mute ( )**: Mutes or unmutes the television audio.

Advanced Functions

- **MENU**: Accesses the television's main menu.
- **SOURCE**: Selects input sources (e.g., HDMI, AV).
- **Navigation Buttons (Up, Down, Left, Right, ENTER)**: Navigate through menus and confirm selections.
- **EXIT**: Exits the current menu or function.
- **GUIDE**: Displays the electronic program guide (if supported by TV).
- **DTV/ATV**: Switches between digital and analog TV modes.
- **P.MODE**: Cycles through picture modes.
- **S.MODE**: Cycles through sound modes.
- **SLEEP**: Sets the sleep timer.
- **MTS**: Multi-channel Television Sound selection.
- **RECLIST**: Accesses recorded program list.
- **REC**: Initiates recording (if supported by TV).
- **FREEZE**: Freezes the current screen.
- **FAV/LIST**: Accesses favorite channels or channel list.
- **DISPLAY**: Shows current channel information.
- **TIMEShift**: Activates or controls timeshift function.
- **ASPECT**: Changes screen aspect ratio.
- **SUB.PG**: Sub-page function.
- **INDEX**: Index function.
- **TV/RADIO**: Switches between TV and Radio modes.
- **SUBTITLE**: Toggles subtitles on/off.
- **REVEAL**: Reveal hidden text in teletext.
- **SIZE**: Adjusts teletext display size.
- **HOLD**: Holds teletext page.
- **TEXT**: Activates teletext.

Compatible Models

This ALLIMITY replacement remote control is compatible with the following television models from AKAI, E-STAR, and QILIVE:

- Q32-009SB
- Q55-009SB
- AKTV2014T
- AKTV390T
- AKTV400

- AKTV390
- 19D1T1
- 22D1T1
- 22D4T2
- 24D1T1
- 24D3T2
- 24D4T2
- 29D1T1
- 32D1T1
- 32D3T2
- 32D4T2
- 32D5T2
- 40D4T2
- 40D5T2
- 50D3T2

Specifications

Feature	Detail
Brand	ALLIMITY
Model Number	QYSY-Q32-009SB-QYSY
Connectivity Technology	Infrared
Compatible Devices	AKAI, E-STAR, QILIVE TVs (listed models above)
Maximum Number of Supported Devices	18 (referring to the number of distinct TV models it can replace)
Number of Buttons	20
Maximum Range	10 Meters
Power Source	2 x AAA Batteries (not included)

Troubleshooting

- **Remote not responding:**
  - Ensure batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new AAA alkaline batteries.
  - Check for any obstructions between the remote control and the TV's infrared receiver.
  - Ensure you are within the maximum operating range (10 meters) and pointing the remote directly at the TV.
- **Specific buttons not working:**
  - This remote is a replacement and may not support all functions of every compatible TV model if the original remote had unique features not present on this standard replacement.
  - Clean the remote control buttons and surface with a soft, dry cloth.

- **TV not listed as compatible:**
  - This remote is designed for the specific models listed. If your TV model is not listed, full functionality cannot be guaranteed.

Warranty and Support

Information regarding specific warranty terms is not provided in the product details. For any issues or support inquiries, please refer to the retailer or manufacturer's customer service channels where the product was purchased.