ALLIMITY QYSY-ND40S3000-QYSY

ALLIMITY Replacement Remote Control User Manual

Model: QYSY-ND40S3000-QYSY

Introduction

Thank you for choosing the ALLIMITY Replacement Remote Control. This remote is designed to provide seamless control for various Nordmende TV models, offering a direct replacement experience without the need for complex programming. Simply insert batteries, and it's ready to use.

Setup

Battery Installation

The ALLIMITY Replacement Remote Control operates on standard alkaline batteries (not included). Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two new alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover by sliding it back into place until it clicks securely.





Figure 1: Rear view of the remote control with the battery compartment visible.

No programming or pairing is required. Once batteries are installed, the remote is ready for immediate use with compatible Nordmende TV models.

Operating Instructions

Basic Functions

This replacement remote control replicates the full functionality of your original Nordmende TV remote. Point the remote directly at your television's infrared receiver for optimal performance.





Figure 2: Front view of the ALLIMITY Replacement Remote Control.

Common buttons and their functions include:

- **Power Button:** Turns the TV on or off.
- **Number Buttons (0-9):** For direct channel selection.
- **Volume Up/Down:** Adjusts the TV volume.
- **Channel Up/Down:** Changes TV channels sequentially.
- **Menu Button:** Accesses the TV's main menu.
- **Navigation Buttons (Up, Down, Left, Right, Enter):** For navigating menus and confirming selections.
- **Source/Input Button:** Switches between different input sources (HDMI, AV, etc.).
- **Exit Button:** Exits current menu or function.
- **Color Buttons (Red, Green, Yellow, Blue):** For specific functions within smart TV applications or teletext.

Compatible Models

This remote control is compatible with the following Nordmende TV models:

- ND32S3100H
- ND40S3000H-SMART-FHD
- ND32S3400H-SMART
- ND43S3100H
- ND32S3900H-SMART
- ND32S3100H-SMART
- ND32S3800H-SMART
- ND24S3100H
- ND55KS4400H-UHD-SMART

If your TV model is not listed but closely matches, the remote may still be compatible. Refer to your TV's original manual for specific remote control requirements.

Maintenance

To ensure the longevity and optimal performance of your remote control, please follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the remote control. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type.

- **Storage:** Store the remote control in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Drops:** Protect the remote from physical impact. Dropping it can damage internal components.
- **Liquid Exposure:** Keep the remote away from liquids. Liquid damage can cause malfunction and is not covered under typical warranties.

Troubleshooting

If you encounter issues with your ALLIMITY Replacement Remote Control, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Remote is not working.	Dead or incorrectly installed batteries.	Replace batteries with new alkaline ones, ensuring correct polarity (+/-).
Remote has limited range or intermittent response.	Weak batteries; Obstruction between remote and TV; Remote not pointed directly at TV's IR sensor.	Replace batteries. Remove any obstructions. Ensure direct line of sight to the TV's IR sensor.
Certain buttons do not respond.	Button stuck or internal damage.	Gently press the button multiple times. If still unresponsive, the remote may be damaged.
Remote works for some functions but not others.	Compatibility issue with specific TV model functions.	Verify your TV model is listed in the compatible models section. Some advanced smart TV functions might require the original remote or a universal remote with programming capabilities.

Specifications

Feature	Detail
Brand	ALLIMITY
Model Number	QYSY-ND40S3000-QYSY
Product Dimensions	21.6 x 5 x 2 cm
Weight	80 g
Connectivity Technology	Infrared
Compatible Devices	Television (Nordmende TV models)
Number of Buttons	25
Controller Type	Button Control
Maximum Range	10 Meters
Battery Description	Alkaline (2x AAA, not included)
Special Features	Ergonomic

Warranty and Support

This ALLIMITY Replacement Remote Control is designed for reliable performance. While specific warranty details are not provided in this manual, please refer to your purchase documentation or the retailer's return policy for information regarding returns, exchanges, or warranty claims.
For further assistance or technical support, please contact the seller or the ALLIMITY customer service through the platform where the product was purchased. Ensure you have your order details and product model number ready when contacting support.

- **Return Policy:** Typically, products are eligible for return within 30 days of purchase, as per retailer policies.
- **Manufacturer:** ALLIMITYQYSY

© 2024 ALLIMITY. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question