Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HOUSBAY RS13D

HOUSBAY Digital Alarm Clock User Manual

Model: RS13D

Introduction

Thank you for choosing the HOUSBAY Digital Alarm Clock, Model RS13D. This manual provides detailed instructions for setting up, operating, and maintaining your new alarm clock. Please read this manual thoroughly before use to ensure proper function and to maximize your experience with its features, including the dynamic night light and customizable LED display.



Image: The HOUSBAY Digital Alarm Clock, showcasing its large, multi-color LED time display and the ambient dynamic night light on top.

Product Overview

Key Features

- **9-Color Dynamic Night Light:** Offers 7 solid colors and 2 dynamic color modes with 5 adjustable brightness levels.
- **Large 1.5-inch LED Display:** Clear and easy-to-read numbers with 10 customizable color display modes (6 solid, 3 mixed, 1 dynamic).
- **Adjustable Display Dimmer:** Brightness can be adjusted from 0% (completely off) to 100% (very bright).
- **Adjustable Alarm Volume:** Alarm sound level can be set from 30dB to 90dB.
- **Large Snooze Button:** Conveniently located on top for easy access.
- **Slide Dials:** Intuitive slide controls for adjusting volume and display dimmer.
- **True Battery Backup:** Requires 3 AAA batteries (not included) to maintain time, display, night light, and alarm functions during power outages.

Package Contents

- HOUSBAY Digital Alarm Clock (Model RS13D)
- Power Adapter
- User Manual

Setup

1. Power Connection

1. Connect the provided power adapter to the DC input port on the back of the alarm clock.
2. Plug the power adapter into a standard AC 110V 50Hz wall outlet. The display will illuminate.

2. Battery Backup Installation

For uninterrupted operation during power outages, install backup batteries.

1. Locate the battery compartment on the bottom of the alarm clock.
2. Open the battery compartment cover.
3. Insert 3 AAA batteries (not included), ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.



Image: Illustration of the alarm clock powered by an AC outlet and supported by AAA backup batteries, ensuring functionality during power interruptions.

Operating Instructions

1. Setting the Time

1. Press the **TIME SET** button (location may vary, typically on the back or side).
2. Use the **+/-** buttons or a dedicated dial to adjust the hour.
3. Press **TIME SET** again to confirm the hour and move to minute adjustment.
4. Adjust the minutes using the **+/-** buttons or dial.
5. Press **TIME SET** one more time to save the time.
6. To switch between 12-hour and 24-hour format, press the **12/24H** button (if available) or cycle through options during time setting.

2. Setting Alarms

This clock supports two independent alarms (Alarm 1 and Alarm 2).

1. Press the **ALARM 1 SET** button. The alarm hour will flash.
2. Adjust the hour using the **+/-** buttons or dial.
3. Press **ALARM 1 SET** again to confirm the hour and move to minute adjustment.
4. Adjust the minutes using the **+/-** buttons or dial.
5. Press **ALARM 1 SET** to save the alarm time.
6. Repeat the process for **ALARM 2 SET** if desired.
7. To activate or deactivate an alarm, press the corresponding **ALARM 1 ON/OFF** or **ALARM 2 ON/OFF** button. An indicator icon will appear on the display when an alarm is active.

3. Adjusting Alarm Volume

The alarm volume can be adjusted using the dedicated slide dial, typically located on the side or back of the unit. Slide the dial to increase or decrease the volume between 30dB and 90dB.

4. Snooze Function

When an alarm sounds, press the large **SNOOZE** button on the top of the clock. The alarm will pause for a set duration (e.g., 9 minutes) and then sound again. To cancel the snooze and turn off the alarm for the day, press any other button.



Image: A top-down view of the alarm clock, highlighting the easily accessible, large snooze button and the illuminated dynamic night light.

5. Night Light Operation

The clock features a night light with 9 color options and 5 brightness levels.

1. Press the **NIGHT LIGHT** button (or similar) to turn the night light on/off.
2. While the night light is on, press the **NIGHT LIGHT** button repeatedly to cycle through the 7 solid colors and 2 dynamic color modes.
3. Use the **BRIGHTNESS** button or a dedicated slide dial to adjust the night light's intensity through 5 levels.



Image: An illustration demonstrating the 9 available dynamic night light colors, showing the clock emitting various hues onto a bedside table.

6. Display Color Modes

The time display offers 10 different color modes.

1. Press the **DISPLAY COLOR** button (or similar) to cycle through the 6 solid colors, 3 mixed color patterns, and 1 dynamic color mode.



Image: A visual representation of the alarm clock's display, showcasing 10 distinct color modes for the digital time, including solid and dynamic options.

7. Adjusting Display Brightness

The display brightness can be adjusted from completely off to very bright.

1. Use the dedicated **DISPLAY DIMMER** slide dial (typically on the side or back) to adjust the brightness level from 0% to 100%.



Image: The alarm clock's display shown at different brightness settings, illustrating the range from fully dark to very bright.

Maintenance

Cleaning

To clean the alarm clock, gently wipe the surface with a soft, dry cloth. Avoid using abrasive cleaners, solvents, or chemical sprays, as these may damage the finish or electronic components.

Battery Replacement

If the clock's display or functions are intermittent during a power outage, the backup batteries may need replacement. Follow the battery backup installation steps in the Setup section to replace the 3 AAA batteries.

Troubleshooting

- **Clock not powering on or display is blank:**

Ensure the power adapter is securely plugged into both the clock and a working wall outlet. If using battery backup, check if the batteries are correctly installed and not depleted.

- **Alarm not sounding:**
  Verify that the alarm is activated (check for the alarm icon on the display). Ensure the alarm volume is not set to its lowest level.
- **Time or settings reset after power outage:**
  This indicates that the backup batteries are either not installed or are depleted. Install or replace the 3 AAA backup batteries.
- **Display or night light colors not changing:**
  Refer to the 'Operating Instructions' section for correct button presses to cycle through color modes and brightness levels.

Specifications

Brand	HOUSBAY
Model Number	RS13D
Display Type	Digital LED
Product Dimensions	2.36"W x 2.75"H
Power Source	Corded Electric
Battery Backup	3 x AAA batteries (not included)
Material	Acrylonitrile Butadiene Styrene
Item Weight	0.34 Kilograms (12 ounces)
Special Features	Adjustable Volume, Alarm, Snooze, 9-Color Night Light, 10-Color Display

Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or contact HOUSBAY customer service directly. Contact details can typically be found on the product packaging or the official HOUSBAY website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C7Z9ZVQS

More documents and user manuals: **https://manuals.plus/**