Blaupunkt BLP9980

Blaupunkt BLP9980 Soundbar User Manual

1. IMPORTANT SAFETY INSTRUCTIONS

Please read these instructions carefully before using the Blaupunkt BLP9980 Soundbar. Keep this manual for future reference.

- Do not expose this appliance to rain or moisture.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the appliance.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this appliance during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way.

2. PRODUCT OVERVIEW

The Blaupunkt BLP9980 is a versatile soundbar designed to enhance your audio experience. It features multiple connectivity options including Bluetooth, FM radio, USB, SD card, and AUX input.

Figure 2.1: Side view of the Blaupunkt BLP9980 Soundbar, highlighting the USB, AUX, and DC 5V power input ports, along with the TF (SD card) slot.

Figure 2.2: Top view of the Blaupunkt BLP9980 Soundbar, displaying the integrated control buttons for mode selection, volume adjustment, and playback.

3. PACKAGE CONTENTS

Please check that all items are present in the package:

- Blaupunkt BLP9980 Soundbar
- Remote Control
- Table and Floor Mount Accessories
- User Manual (this document)

4. SETUP

4.1 Placement

Position the soundbar on a stable, flat surface using the provided table mount accessories, or install it on the floor using the floor mount accessories. Ensure adequate ventilation around the unit.

4.2 Power Connection

Connect the soundbar to a DC 5V power source using a compatible power adapter (not always included, check packaging). The unit is also designed to operate on battery power.

4.3 Initial Power On

Press and hold the power button (usually marked with a power symbol) on the soundbar or remote control to turn the unit on. The display (if available) or indicator light will illuminate.

5. OPERATING INSTRUCTIONS

5.1 General Controls

The soundbar features touch controls on the top panel and a remote control for convenient operation.

- **Power Button:** Press and hold to turn on/off.
- **Mode (M) Button:** Press to cycle through input modes (Bluetooth, FM, USB, SD, AUX).
- **Volume - / + Buttons:** Press to decrease or increase the volume.
- **Play/Pause Button:** Controls playback in Bluetooth, USB, and SD modes.
- **Previous / Next Buttons:** Skips tracks in Bluetooth, USB, and SD modes, or tunes FM stations.

5.2 Bluetooth Mode

1. Press the **Mode (M)** button until 'Bluetooth' mode is selected. The soundbar will enter pairing mode, indicated by a flashing LED.
2. Enable Bluetooth on your mobile device (smartphone, tablet, laptop).
3. Search for available devices and select 'BLP9980' from the list.
4. Once paired, the LED indicator will stop flashing, and you can play audio from your device.

5.3 FM Radio Mode

1. Press the **Mode (M)** button until 'FM' mode is selected.
2. Press the **Play/Pause** button to automatically scan and save available FM stations.
3. Use the **Previous / Next** buttons to navigate through the saved stations.

5.4 USB/SD Card Mode

1. Insert a USB drive into the USB port or an SD card into the TF slot.
2. Press the **Mode (M)** button until 'USB' or 'SD' mode is selected. The soundbar will automatically begin playing audio files.
3. Use the **Play/Pause** and **Previous / Next** buttons to control playback.

5.5 AUX Mode

1. Connect an external audio device (e.g., MP3 player, TV) to the AUX port using a 3.5mm audio cable (not always included).
2. Press the **Mode (M)** button until 'AUX' mode is selected.
3. Control playback and volume from your connected device.

6. MAINTENANCE

To ensure the longevity and optimal performance of your soundbar, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the soundbar. Do not use liquid cleaners or abrasive materials.
- **Storage:** If storing the soundbar for an extended period, disconnect it from power and store it in a cool, dry place away from direct sunlight.
- **Avoid Obstructions:** Ensure that the speaker grilles are free from dust and debris to maintain sound quality.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cable not connected; Battery depleted	Ensure power cable is securely connected; Charge the soundbar battery.
No sound	Volume too low; Incorrect input mode; Device not connected properly	Increase volume; Select correct input mode (Bluetooth, AUX, etc.); Reconnect device.
Bluetooth not pairing	Soundbar not in pairing mode; Device too far; Bluetooth off on device	Ensure soundbar is in Bluetooth pairing mode; Move device closer; Enable Bluetooth on your device.
FM radio static	Weak signal; Interference	Reposition the soundbar; Try scanning for stations again.

8. SPECIFICATIONS

Feature	Detail
Model Number	BLP9980
Brand	Blaupunkt
Connectivity Technology	Bluetooth, AUX, USB
Wireless Communication Technology	Bluetooth
Power Source	Battery
Control Method	Touch, Remote Control
Audio Output Mode	Surround
Surround Sound Channel Configuration	5.1
Speaker Type	Soundbar, Surround Sound
Special Feature	Bluetooth
Recommended Uses For Product	Home
Compatible Devices	Laptop, Smartphone, Tablet
Included Components	Remote control, Table and Floor mount
Product Dimensions	10 x 10 x 10 cm

9. WARRANTY AND SUPPORT

Blaupunkt products are manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official Blaupunkt website. Keep your proof of purchase for warranty claims.

For further assistance, you may contact Blaupunkt customer service through their official channels.