Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Achaté 650W Spot Cleaner

Achaté Spot Cleaner User Manual

Model: 650W Spot Cleaner

1. Introduction

Thank you for choosing the Achaté Spot Cleaner. This powerful and versatile device is designed to effectively remove tough stains from various surfaces, including carpets, upholstery, and car interiors. Please read this manual carefully before using the appliance to ensure safe and optimal performance. Keep this manual for future reference.



The Achaté Spot Cleaner, a compact and powerful device for deep cleaning.

2. Important Safety Instructions

To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using an electrical appliance.

- Read all instructions before using the appliance.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not immerse the appliance in water or other liquids.
- Do not use with a damaged cord or plug. If the appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.

- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Keep cord away from heated surfaces.
- Unplug from outlet when not in use and before cleaning or servicing.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Use only cleaning products intended for use with this appliance.

3. Product Components and Overview

Your Achaté Spot Cleaner comes with all necessary components for effective cleaning. Familiarize yourself with the parts before operation.



The product packaging, manual, and the spot cleaner unit.

Main Parts:

- **Clean Water Tank:** Holds fresh water and cleaning solution. Capacity: 1.2 Liters.
- **Dirty Water Tank:** Collects dirty water and debris. Capacity: 1.4 Liters.
- **Flexible Hose:** Connects the main unit to the cleaning nozzle.
- **Cleaning Nozzle:** Features an integrated spray and suction head.
- **Detachable Brush:** For scrubbing stubborn stains.
- **Power Cord:** For electrical connection.



Overview of the clean water tank (1.2L) and dirty water tank (1.4L).



The detachable brush for enhanced cleaning action.

4. Setup

Follow these steps to prepare your Achaté Spot Cleaner for use:

1. **Unpack the Unit:** Carefully remove all components from the packaging. Ensure all parts listed in Section 3 are present.
2. **Fill the Clean Water Tank:** Remove the clean water tank from the main unit. Fill it with warm tap water (max 40°C) up to the indicated fill line. Add your preferred Achaté cleaning solution according to the solution's instructions. Do not overfill. Securely close the tank and place it back into the unit.
3. **Attach the Cleaning Nozzle:** Connect the flexible hose to the main unit and then attach the cleaning nozzle firmly to the end of the hose. Ensure it clicks into place.
4. **Plug In:** Insert the power cord into a grounded electrical outlet (220V).

5. Operating Instructions

The Achaté Spot Cleaner is designed for easy and effective stain removal.

1. **Pre-treat (Optional):** For heavily soiled areas, you may pre-treat the stain with a suitable cleaning spray, such as the Achaté Stain Remover spray. Allow it to sit for a few minutes as per the spray's instructions.
2. **Power On:** Press the power button on the main unit to turn on the cleaner.
3. **Spray Solution:** Position the cleaning nozzle directly over the stain. Press the spray trigger on the nozzle handle to release the cleaning solution onto the stained area.
4. **Scrub (Optional):** If your nozzle has a detachable brush, use it to gently scrub the stain while spraying. For integrated brushes, apply light pressure and move the nozzle back and forth.
5. **Suction:** Release the spray trigger and slowly pull the nozzle over the wet area, applying downward pressure. The powerful suction will extract the dirty solution and lift the stain. Repeat this step until the area appears clean and most of the moisture is removed.





The cleaning nozzle effectively sprays and suctions liquid stains.



Demonstration of the cleaner's effectiveness on a soiled carpet.



The compact design allows for comfortable use on various surfaces.



Achieve intensive and thorough cleaning on upholstered items.



The integrated spray ensures even distribution of cleaning solution.

Versatile Applications:

The Achaté Spot Cleaner is suitable for a wide range of surfaces:

- Carpets and Rugs
- Upholstered Furniture (Sofas, Chairs)
- Mattresses
- Car Interiors (Seats, Floor Mats)
- Stairs



The Achaté Spot Cleaner is ideal for carpets, furniture, beds, and car interiors.



Its flexible design allows for easy use in tight spaces like car seats.

6. Maintenance

Regular cleaning and maintenance will ensure the longevity and optimal performance of your Achaté Spot Cleaner.

1. **Empty Dirty Water Tank:** After each use, or when the dirty water tank reaches its maximum fill line, remove it from the unit and empty the dirty water. Rinse the tank thoroughly with clean water.
2. **Clean Clean Water Tank:** Empty any remaining solution from the clean water tank and rinse it thoroughly.
3. **Clean Nozzle and Hose:** Detach the cleaning nozzle and rinse it under running water. Ensure no debris is lodged in the spray or suction openings. Rinse the flexible hose by running clean water through it.
4. **Clean Detachable Brush:** If used, remove and rinse the brush thoroughly to remove any trapped hair or debris.
5. **Wipe Down Unit:** Wipe the exterior of the main unit with a damp cloth. Do not use harsh chemicals or abrasive cleaners.

6. **Dry and Store:** Allow all components to air dry completely before reassembling and storing the unit in a cool, dry place, away from direct sunlight and out of reach of children.

7. Troubleshooting

If you encounter any issues with your Achaté Spot Cleaner, refer to the table below for common problems and their solutions.

Problem	Possible Cause	Solution
No power	Unit not plugged in; Power outlet not working; Power button not pressed.	Ensure power cord is securely plugged into a working outlet. Press the power button firmly.
No spray	Clean water tank empty; Tank not seated correctly; Spray nozzle clogged.	Refill clean water tank. Ensure tank is securely in place. Clean spray nozzle.
No suction or weak suction	Dirty water tank full; Tank not seated correctly; Hose or nozzle clogged; Tank lid not sealed.	Empty dirty water tank. Ensure tank is securely in place. Clear any clogs in hose or nozzle. Ensure dirty water tank lid is properly sealed.
Poor cleaning performance	Incorrect cleaning solution; Too little solution applied; Too fast movement.	Use recommended cleaning solution. Ensure adequate solution is sprayed. Move nozzle slowly over the stain.

8. Technical Specifications

Brand	Achaté
Model	Spot Cleaner
Color	Grey/Blue
Power	650 Watts
Voltage	220 Volts
Clean Water Tank Capacity	1.2 Liters
Dirty Water Tank Capacity	1.4 Liters
Item Weight	5.7 Kilograms
Power Source	Corded Electric

9. Warranty and Support

Your Achaté Spot Cleaner comes with a **2-year warranty** from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.

For technical support, warranty inquiries, or replacement parts, please contact Achaté customer service through the

retailer where you purchased the product or visit our official website for contact information.

© 2024 Achaté. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C86C1LW6

More documents and user manuals: **https://manuals.plus/**