VTech VT680

VTech VT680 Cordless Phone User Manual

INTRODUCTION

Welcome to your VTech VT680 Cordless Phone. This manual provides essential information for setting up, operating, and maintaining your new phone. The VTech VT680 is a DECT 6.0 cordless phone designed for reliable fixed-line communication.

Key features include Caller ID, a log of the last 10 received calls, a reminder alarm, and a 20-contact phonebook.

Teléfono Inalámbrico Digital VT680

Image: VTech VT680 Cordless Phone handset and base unit positioned on a desk in a home office environment, alongside office supplies.

PACKAGE CONTENTS

Please verify that your package contains the following items:

- VTech VT680 Cordless Handset
- Charging Base
- Power Adapter
- Telephone Line Cord
- 2 AAA Rechargeable Batteries
- User Manual (this document)

SETUP

1. Battery Installation

Step 1: Locate the battery compartment on the back of the handset.

Step 2: Insert the two AAA rechargeable batteries, observing the correct polarity (+ and -) as indicated inside the compartment.

Step 3: Close the battery compartment cover securely.

Image: Rear view of the VTech VT680 cordless phone handset, showing the battery compartment area.

2. Base Unit Connection

Step 1: Connect one end of the telephone line cord to the TEL LINE jack on the back of the charging base.

Step 2: Connect the other end of the telephone line cord to your telephone wall jack.

Step 3: Connect the small end of the power adapter to the POWER jack on the back of the charging base.

Step 4: Plug the large end of the power adapter into a standard electrical outlet.

Image: Side profile of the VTech VT680 cordless phone handset docked in its charging base, illustrating its compact design.

3. Initial Charging

Place the handset on the charging base. The handset display will show a charging indicator. Allow the handset to charge for at least 12 hours before initial use to ensure optimal battery performance and

longevity.

Image: Front view of the VTech VT680 cordless phone handset docked in its charging base, displaying the screen and keypad.

OPERATING INSTRUCTIONS

Making a Call

1. Pick up the handset or press the **PHONE** button.
2. Dial the desired phone number using the keypad.
3. Press the **PHONE** button again to end the call.

Answering a Call

When the phone rings, pick up the handset or press the **PHONE** button.

Using Caller ID

When a call comes in, the caller's name and number will appear on the handset display (requires subscription to Caller ID service from your telephone provider).

To review the call log, press the **CALL LOG** button. Use the **UP** and **DOWN** arrow buttons to scroll through the last 10 received calls.

Phonebook

The phonebook can store up to 20 contacts.

Adding a Contact

1. Press the **MENU** button.
2. Navigate to "Phonebook" and select "Add New Entry".
3. Enter the contact's name and phone number using the keypad.
4. Press **SAVE** to store the entry.

Making a Call from Phonebook

1. Press the **PHONEBOOK** button.
2. Use the **UP** and **DOWN** arrow buttons to find the desired contact.
3. Press the **PHONE** button to dial the contact.

Setting a Reminder Alarm

1. Press the **MENU** button.
2. Navigate to "Alarm" or "Reminders" in the menu.
3. Set the desired time and activate the alarm function.

4. Press **SAVE** to confirm.

Image: A woman comfortably seated on a couch, engaged in a phone conversation using the VTech VT680 cordless phone.

MAINTENANCE

Cleaning

Wipe the handset and base unit with a soft, slightly damp cloth. Do not use harsh cleaning agents, abrasive materials, or excessive liquid, as these can damage the device.

Battery Care

Use only the specified AAA rechargeable batteries. Replace batteries when they no longer hold a charge effectively or if you notice a significant decrease in talk time.

TROUBLESHOOTING

If you encounter any issues with your VTech VT680 Cordless Phone, please refer to the table below for common problems and their solutions.

Problem	Solution
No dial tone	Ensure the telephone line cord is securely connected to both the base unit and the telephone wall jack. Verify the power adapter is properly connected to the base unit and a working electrical outlet.
Handset not charging	Ensure the handset is correctly seated in the charging cradle. Verify the power adapter is plugged in. Clean the charging contacts on both the handset and base unit with a dry cloth.

Problem	Solution
Poor call quality or static	Move closer to the base unit. Check for interference from other electronic devices (e.g., Wi-Fi routers, microwaves). Try relocating the base unit.
Caller ID not working	Ensure you are subscribed to Caller ID service from your telephone service provider. Contact your provider to confirm the service is active.

SPECIFICATIONS

Technical Specifications

Brand: VTech

Model: VT680

Phone Type: Cordless, DECT 6.0 Technology

Color: Black

Material: Plastic

Power Source: Battery operated (2 AAA rechargeable batteries included)

Dimensions (Handset on Base): Approximately 16.8 x 7.8 x 15.8 cm

Weight: Approximately 680 g

Features: Caller ID, 10-call log, Reminder Alarm, 20-contact Phonebook

Line Operation: Single-line operation

WARRANTY AND SUPPORT

For detailed warranty information, technical support, or to register your product, please visit the official VTech website or contact VTech customer service. Specific warranty terms and support options may vary by region.

Related Documents - VT680

VG 208 208-2 Scan the QR code to go and subscribe our tutorial channel · vtech · User's manual	[VTech VG208 / VG208-2 User Manual: Features, Safety, and Operation Guide](#) Comprehensive user manual for the VTech VG208 and VG208-2 DECT 6.0 cordless phones. Learn about installation, operation, features like answering machine, caller ID, call blocking, intercom, safety instructions, and technical specifications.

	[VTech VS122-16 Cordless Phone Quick Start Guide](#) A quick start guide for the VTech VS122-16 cordless phone, covering setup, features like Smart Call Blocker, Caller ID, Phonebook, Answering System, and Bluetooth connectivity.
	[VTech CS5209 DECT 6.0 Accessory Handset User Manual](#) User manual for the VTech CS5209 DECT 6.0 accessory handset, providing instructions on setup, registration, operation, and safety precautions. Learn how to install the battery, connect the charger, register new handsets, and understand display icons and features.
	[VTech CD1113 Cordless Phone User Manual](#) Comprehensive user manual for the VTech CD1113 cordless phone, detailing installation, operation, features such as Caller ID and speed dial, troubleshooting tips, safety instructions, and warranty information.
	[VTech CS2050/CS2051/CS2052/CS2053 Quick Start Guide](#) Comprehensive guide to setting up and using your VTech CS2050, CS2051, CS2052, or CS2053 cordless phone system, including safety instructions, product registration, warranty information, and feature setup.
	[VTech CS5229 Cordless Phone Quick Start Guide](#) This guide provides instructions for setting up and using the VTech CS5229 DECT 6.0 cordless telephone, including installation, basic operation, phonebook, caller ID, call blocking, and answering system features.

Documents - VTech – VT680

no relevant documents