Cane Creek BAH0071

Cane Creek Light + Camera Mount (Model BAH0071) Instruction Manual

Introduction

The Cane Creek Light + Camera Mount (Model BAH0071) is a versatile accessory designed to securely attach both a light and a camera to your bicycle. This mount provides a stable platform for essential accessories, enhancing visibility and enabling you to capture your rides with ease.



Figure 1: The Cane Creek Light + Camera Mount installed on a bicycle.

Setup Instructions

1. **Attach the Mount to the Handlebar Stem:** Use an appropriate Allen key to securely fasten the main mount to your bicycle's handlebar stem. Ensure the mount is centered and tightened to prevent movement during rides.
2. **Assemble the Computer Mount Adapter:** If using a cycling computer, assemble the specific adapter for your device. This typically involves attaching the adapter plate to the mount using small screws.
3. **Attach Computer Mount Adapter to Main Mount:** Secure the assembled computer mount adapter to the top of the main Cane Creek mount.
4. **Attach Light or Camera:** The bottom of the mount features a GoPro-style interface. Attach your compatible cycling light or action camera to this interface. Ensure it clicks securely into place.

Your browser does not support the video tag.

Video 1: Installation guide for the Panmout Mount for Garmin, demonstrating similar setup steps for the Cane Creek mount.

Operating Instructions

- **Cycling Computer Usage:** Once the computer mount adapter is installed, simply twist and lock your compatible cycling computer (e.g., Garmin) into the adapter.
- **Camera/Light Usage:** Attach your GoPro-style action camera or cycling light to the integrated mount beneath the computer platform. Ensure a firm connection before riding.
- **Compatibility:** This mount is compatible with Cane Creek Stem computer mounts (sold separately) and features a standard GoPro-style insert for cameras and lights.

Maintenance

Regularly inspect all bolts and connections for tightness, especially after initial installation and before each ride. Clean the mount with a damp cloth as needed. Avoid using harsh abrasive cleaners or chemicals that may damage the finish or materials.

Troubleshooting

- **Mount feels loose:** Re-tighten all bolts securing the mount to the handlebar stem and the computer/camera adapters. Do not overtighten.
- **Accessory not fitting:** Ensure your cycling computer and camera/light accessories are compatible with the specified mounting standards (Cane Creek Stem mount for computers, GoPro-style for cameras/lights).
- **Vibration during ride:** Check all connections for tightness. Ensure the mount is properly seated on the handlebar stem.

Specifications

Feature	Detail
Brand	Cane Creek
Model Name	Camera/Light Assembly for Computer Mount
Manufacturer Part Number	BAH0071
Color	One Color
Compatible Devices	Cycling Computers (with Cane Creek Stem mount), Action Cameras (GoPro-style)
Item Weight	0.05 Pounds
UPC	840226088174
Unit Count	1.0 Count

Warranty Information

The Cane Creek Light + Camera Mount is covered by a**Limited Lifetime Warranty**. Please refer to the official Cane Creek website or contact customer support for full warranty details and terms.

Customer Support

For further assistance, technical support, or inquiries regarding your Cane Creek Light + Camera Mount, please visit the official Cane Creek website or contact their customer service department.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question