Pure Enrichment PureRelief XL Express Vinyl Heating Pad

Pure Enrichment PureRelief XL Express Vinyl Heating Pad Instruction Manual

Introduction

This manual provides comprehensive instructions for the safe and effective use of your Pure Enrichment PureRelief XL Express Vinyl Heating Pad. Please read all instructions carefully before use and retain this manual for future reference.



A woman relaxing on a couch with the Pure Enrichment PureRelief XL Express Vinyl Heating Pad placed on her abdomen, demonstrating typical use for targeted heat comfort.

Important Safeguards

To reduce the risk of burns, electric shock, fire, and injury, this product must be used in accordance with the following instructions:

- Do not use in the bath or near water.
- Keep away from children.
- Always unplug when not in use.
- Do not leave unattended while in use.
- Do not use if damaged.
- Allow the pad to cool before storing.
- Always follow the manufacturer's instructions for use and care.
- Avoid prolonged use or falling asleep with the pad on.

Product Features

The Pure Enrichment PureRelief XL Express Vinyl Heating Pad offers several features designed for effective heat therapy:

- **Targeted Heat Comfort:** Delivers soothing warmth to areas such as the shoulders, arms, legs, and back.
- **3 Heat Settings:** A slider button controller allows selection between Level 1 (48.8° C), Level 2 (54.4° C), and Level 3 (60° C).
- **Removable & Washable Cover:** The polyester cover can be machine washed in cold water.
- **2.6-Meter Cable:** An extended power cord provides flexibility for use in various locations.
- **Vinyl Material:** The internal pad is made of vinyl.



This image highlights the key features of the heating pad, including its controller, heat settings, size, cord length, and warranty information.

Package Contents

Verify that all items are present in the package:

- Pure Enrichment PureRelief XL Express Vinyl Heating Pad

- Removable Polyester Cover
- Slider Button Controller with attached power cord

Setup and Operation

Connecting the Controller

1. Ensure the heating pad is unplugged from the electrical outlet.
2. Connect the controller cable securely to the heating pad's connector. Ensure it clicks into place.

Using the Heating Pad

1. Place the heating pad on the desired area of your body (back, shoulders, arms, or legs).
2. Plug the power cord into a 120V AC electrical outlet.
3. Slide the controller button to select your desired heat setting:
    - **Level 1:** Approximately 48.8° C (120° F)
    - **Level 2:** Approximately 54.4° C (130° F)
    - **Level 3:** Approximately 60° C (140° F)
4. The pad will begin to heat. Adjust the setting as needed for comfort.
5. To turn off the heating pad, slide the controller button to the 'OFF' position. Unplug the unit from the electrical outlet when not in use.

Care and Maintenance

Cleaning the Removable Cover

The polyester cover is machine washable to maintain hygiene and softness.

1. Ensure the heating pad is unplugged and completely cool.
2. Detach the controller from the heating pad.
3. Remove the polyester cover from the vinyl heating pad.
4. Machine wash the cover in cold water on a gentle cycle.
5. Tumble dry on low heat or air dry. Do not bleach or iron.
6. Ensure the cover is completely dry before reattaching it to the heating pad.

Storage

Allow the pad to cool completely before folding and storing. Store in a cool, dry place. Do not place heavy objects on the pad during storage.



This image demonstrates the machine-washable feature of the heating pad's cover, emphasizing ease of cleaning.

Troubleshooting

If you experience issues with your heating pad, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Heating pad does not turn on or heat up.	Not properly plugged in; controller not connected; power outage.	Ensure power cord is securely plugged into outlet. Check controller connection. Verify power supply.
Heating pad heats unevenly.	Pad is folded or bunched during use.	Ensure the heating pad is laid flat and not folded or creased during operation.
Controller light is off.	Unit is off or unplugged.	Check if the controller is set to an 'ON' position and if the unit is plugged into a working outlet.

Specifications

Key technical details for the Pure Enrichment PureRelief XL Express Vinyl Heating Pad:

- **Model:** W-PECAHP24-G
- **Dimensions:** 30.5 cm x 61 cm (12 in x 24 in)
- **Material:** Vinyl (pad), Polyester (cover)
- **Heat Settings:** 3 (48.8° C, 54.4° C, 60° C)
- **Cord Length:** 2.6 meters (8.5 feet)
- **Power:** AC 120V
- **Manufacturer:** Pure Enrichment
- **UPC:** 817387029162



This diagram provides the exact measurements of the heating pad and its power cord for reference.

Warranty and Customer Support

5-Year Warranty

The Pure Enrichment PureRelief XL Express Vinyl Heating Pad is backed by Pure Enrichment's industry-leading 5-Year

Warranty. This warranty covers defects in materials and workmanship under normal use.

Customer Support

For warranty claims, troubleshooting assistance, or any questions regarding your product, please contact Pure Enrichment customer support. Refer to the product packaging or the official Pure Enrichment website for current contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question