FMOUSE 213

FMOUSE Tri-Mode Wireless Mouse Instruction Manual

Model: 213

Product Overview

The FMOUSE Tri-Mode Wireless Mouse is designed for efficiency and versatility, offering seamless connectivity across multiple devices and operating systems. Its ergonomic design ensures comfortable use, while silent clicks minimize disturbance in quiet environments. This mouse features advanced optical tracking and adjustable DPI settings for precise control.



Image: The FMOUSE Tri-Mode Wireless Mouse in Pale Grey, showcasing its ergonomic shape and the included USB receiver.

Key Features:

- **Tri-Mode Connectivity:** Supports dual Bluetooth 5.1 and 2.4G wireless technology, allowing connection to three devices simultaneously.
- **Multifunctional Side Keys:** Includes forward and backward buttons for enhanced productivity.
- **Adjustable DPI:** Four sensitivity levels (800/1200/1600/2400 DPI) for precise cursor control.
- **USB-C Rechargeable:** Built-in 400mAh lithium battery, easily charged via USB-C.
- **Silent Clicks:** Designed for quiet operation, suitable for various environments.
- **Wide Compatibility:** Compatible with Windows, macOS, iPadOS, ChromeOS, and Linux.
- **Ergonomic Design:** Lightweight and comfortable for extended use.

Package Contents

Please verify that all items are present in the package:

- 1x FMOUSE FIT 3 Mouse
- 1x USB charging cable
- 1x USB receiver
- 1x Instruction manual (this document)

Setup Guide

1. Charging the Mouse

Before first use, it is recommended to fully charge the mouse. Connect the included USB charging cable to the USB-C port on the front of the mouse and the other end to a USB power source (e.g., computer USB port, USB wall adapter). The DPI indicator light will flash red during charging and turn off when fully charged.

2. Connecting the Mouse

The FMOUSE Tri-Mode Wireless Mouse offers three connection modes: 2.4GHz wireless via USB receiver, Bluetooth 1, and Bluetooth 2. Use the mode switch located on the bottom of the mouse to select your desired connection.



Image: The FMOUSE Tri-Mode Wireless Mouse demonstrating its ability to connect to multiple devices, including laptops, desktops, and tablets, using both 2.4GHz and Bluetooth connections.

2.1. 2.4GHz Wireless Connection (USB Receiver)

1. Locate the USB receiver stored in the compartment on the bottom of the mouse.
2. Plug the USB receiver into an available USB port on your computer.
3. Slide the mode switch on the bottom of the mouse to the "2.4G" position (indicated by a small icon or label).
4. The mouse should automatically connect to your device.

2.2. Bluetooth Connection (BT1 / BT2)

1. Slide the mode switch on the bottom of the mouse to either the "BT1" or "BT2" position.
2. Press and hold the DPI adjustment button (located behind the scroll wheel) for 3-5 seconds until the indicator light starts flashing rapidly. This indicates the mouse is in pairing mode.
3. On your device (laptop, iPad, etc.), go to Bluetooth settings and search for new devices.
4. Select "FMOUSE FIT 3" or a similar name from the list of available devices to pair.
5. Once paired, the indicator light on the mouse will stop flashing and remain solid for a few seconds before turning off.

Note: You can pair two different devices using BT1 and BT2 modes, allowing for quick switching between them.

Operating Instructions

1. Button Functions



Image: A diagram illustrating the six main buttons of the FMOUSE Tri-Mode Wireless Mouse, including the Left Key, Right Key, Mouse Wheel, DPI Adjustment Key, Backward, and Forward buttons.

- **Left Key:** Standard left-click function.
- **Right Key:** Standard right-click function.
- **Mouse Wheel:** Scroll up/down for navigation. Can also be pressed for middle-click functionality.
- **DPI Adjustment Key:** Press to cycle through DPI settings. Press and hold for 3-5 seconds to enter Bluetooth pairing mode.
- **Forward Key (Side):** Navigates forward in web browsers or file explorers.
- **Backward Key (Side):** Navigates backward in web browsers or file explorers.

2. Adjusting DPI Sensitivity

The mouse features four adjustable DPI (Dots Per Inch) levels to suit different tasks and preferences. Press the DPI adjustment button (located behind the scroll wheel) to cycle through the settings:

- 800 DPI (Lowest sensitivity, precise control)

- 1200 DPI
- 1600 DPI
- 2400 DPI (Highest sensitivity, faster cursor movement)



Image: A visual representation of the four adjustable DPI settings (800, 1200, 1600, 2400) available on the FMOUSE Tri-Mode Wireless Mouse, indicating varying levels of cursor sensitivity.

3. Switching Between Connected Devices

If you have connected the mouse to multiple devices (e.g., one via 2.4GHz, one via BT1, and another via BT2), simply slide the mode switch on the bottom of the mouse to the corresponding position (2.4G, BT1, or BT2) to instantly switch control to that device.

4. Silent Click Feature

The FMOUSE Tri-Mode Wireless Mouse is designed with silent click buttons, significantly reducing clicking noise. This feature is ideal for quiet environments such as libraries, offices, or late-night work sessions, allowing you to focus without disturbing others.



Image: A user operating the FMOUSE Tri-Mode Wireless Mouse in a quiet setting, highlighting its silent click functionality.

Maintenance

Cleaning

To maintain optimal performance and appearance, clean your mouse regularly. Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution. Avoid using harsh chemicals, abrasives, or solvents. Do not immerse the mouse in water or any liquid.

Storage

When not in use for extended periods, store the mouse in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the USB receiver is securely stored in its compartment on the mouse to prevent loss.

Troubleshooting

Problem	Possible Cause	Solution
Mouse not responding / Cursor not moving.	Low battery; Incorrect connection mode; USB receiver not plugged in (2.4G); Bluetooth not paired or disconnected.	Charge the mouse. Ensure the mode switch is set correctly (2.4G, BT1, or BT2). For 2.4G, ensure the USB receiver is securely plugged in. For Bluetooth, re-pair the mouse if necessary. Try a different USB port or restart your device.
Bluetooth pairing fails.	Mouse not in pairing mode; Device's Bluetooth is off; Interference.	Ensure the mouse is in BT1 or BT2 mode and you are holding the DPI button for 3-5 seconds until the light flashes rapidly. Check if Bluetooth is enabled on your device. Move closer to your device and away from other wireless devices.
Mouse movement is erratic or jumpy.	Dirty optical sensor; Unsuitable surface; Low battery.	Clean the optical sensor on the bottom of the mouse with a soft cloth. Use the mouse on a clean, non-reflective, opaque surface. Charge the mouse.
Side keys (Forward/Backward) not working.	Application does not support these functions; Driver issue.	Ensure the application you are using supports these navigation functions. Try updating your computer's mouse drivers if available.

Specifications

Feature	Detail
Model	213 (FIT 3 Mouse)
Connectivity	2.4GHz Wireless, Bluetooth 5.1 (BT1, BT2)
DPI Levels	800 / 1200 / 1600 / 2400
Battery Type	Built-in Rechargeable Lithium Ion (400mAh)
Charging Port	USB-C
Product Dimensions	100 x 65 x 34 mm (3.94 x 2.56 x 1.34 inches)
Item Weight	66g ± 5g (2.33 ounces)
Operating Systems	Windows, macOS, iPadOS, ChromeOS, Linux
Special Features	Silent Clicks, Ergonomic Design, Forward/Backward Side Keys

Warranty and Support

Specific warranty details and direct customer support contact information are not provided within this manual. For warranty claims, technical assistance, or further inquiries, please refer to the product packaging or visit the official FMOUSE website. You may also contact the retailer from whom you purchased the product for support.

© 2024 FMOUSE. All rights reserved.