Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

FMOUSE cd2 -963

FMOUSE Tri-Mode Wireless Mouse User Manual

Model: cd2 -963

Introduction

Thank you for choosing the FMOUSE Tri-Mode Wireless Mouse. This advanced mouse offers versatile connectivity options, including dual Bluetooth 5.1 and 2.4G wireless technology, allowing seamless switching between up to three devices. Designed for efficiency and comfort, it features adjustable DPI settings, silent clicks, and an ergonomic form factor suitable for extended use. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your new mouse.



Figure 1: FMOUSE Tri-Mode Wireless Mouse with its USB receiver.

Setup Guide

Package Contents:

- 1x FMOUSE FIT 3 Mouse
- 1x USB charging cable
- 1x USB receiver
- 1x Instruction manual

Connecting Your Mouse:

Your FMOUSE Tri-Mode Wireless Mouse offers three connection modes: 2.4G Wireless (via USB receiver) and two Bluetooth 5.1 channels (BT1, BT2). You can easily switch between these modes using the mode switch button

located on the bottom of the mouse.



Figure 2: Tri-Mode connectivity with 2.4G wireless and dual Bluetooth channels.

2.4G Wireless Mode:

1. Locate the USB receiver stored in the compartment on the bottom of the mouse.
2. Plug the USB receiver into an available USB port on your computer.
3. Slide the mode switch on the bottom of the mouse to the '2.4G' position. The mouse will automatically connect to your device.

Bluetooth Mode (BT1 / BT2):

1. Slide the mode switch on the bottom of the mouse to either 'BT1' or 'BT2' position.
2. Press and hold the mode switch button for 3-5 seconds until the indicator light on the mouse starts flashing rapidly, indicating it's in pairing mode.
3. On your device (laptop, iPad, Mac, etc.), go to Bluetooth settings and search for new devices.
4. Select 'FMOUSE' or 'FIT 3 Mouse' from the list of available devices to pair.
5. Once connected, the indicator light on the mouse will stop flashing.

Operating Instructions

DPI Adjustment:

The mouse features 4 adjustable DPI (Dots Per Inch) levels, allowing you to customize cursor sensitivity for different tasks. The default DPI settings are 800, 1200, 1600, and 2400.

- Press the DPI adjustment button (located behind the scroll wheel) to cycle through the DPI settings.
- Each press will change the sensitivity, indicated by a brief flash of the DPI indicator light.



Figure 3: Adjustable DPI settings for precise control.

Multifunctional Side Keys:

The mouse is equipped with two side buttons (Forward and Backward) that enhance productivity, especially for web browsing or navigating documents.

- The **Forward** button typically navigates to the next page in a browser or document.
- The **Backward** button typically navigates to the previous page in a browser or document.



Figure 4: Overview of the mouse's 6-button design and system compatibility.

Silent Click Feature:

The mouse features silent buttons, designed to minimize clicking noise. This makes it ideal for use in quiet environments such as libraries, dormitories, or offices, ensuring you can work without disturbing others.



Figure 5: The silent click feature allows for quiet operation.

Charging the Mouse:

The mouse has a built-in 400mAh rechargeable lithium battery. When the DPI indicator light flashes red, it signifies that the battery is low and needs charging.

- Connect the included USB charging cable to the USB-C port on the front of the mouse.
- Plug the other end of the cable into a USB power source (e.g., computer USB port, USB wall adapter).
- The indicator light will show charging status (specific color/behavior may vary, refer to quick start guide for details).
- Once fully charged, the indicator light will change or turn off.

Ergonomic Design:

The mouse is designed for comfort and ease of use, with an ergonomic shape that fits various hand sizes and grip styles. Its lightweight construction (only 68g ± 5g) helps reduce fatigue during long periods of use.



Figure 6: Ergonomic design supports various grip types.

Precise Optical Tracking:

The mouse utilizes precise optical tracking technology, allowing it to glide smoothly and accurately on most common surfaces, including wood, paper, cloth, leather, metal, and PVC.



Figure 7: Optical sensor performance on diverse surfaces.

Maintenance

To ensure the longevity and optimal performance of your FMOUSE Tri-Mode Wireless Mouse, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the mouse. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid using harsh chemicals or abrasive materials.
- **Sensor Care:** Keep the optical sensor on the bottom of the mouse clean and free from dust or debris to ensure accurate tracking.
- **Storage:** When not in use for extended periods, store the mouse in a cool, dry place. If transporting, consider using a protective pouch to prevent scratches or damage.
- **Battery:** Avoid fully depleting the battery frequently. Charge the mouse when the low battery indicator appears.
- **Avoid Extreme Conditions:** Do not expose the mouse to extreme temperatures, direct sunlight, or high humidity.

Troubleshooting

If you encounter issues with your FMOUSE Tri-Mode Wireless Mouse, please refer to the following common solutions:

Problem	Possible Cause	Solution
Mouse not responding	Low battery	Charge the mouse using the provided USB-C cable.
Mouse not responding	Incorrect mode selected	Ensure the mode switch on the bottom of the mouse is set to the correct connection mode (2.4G, BT1, or BT2) for your device.
Mouse not responding (2.4G)	USB receiver not connected or faulty	Ensure the USB receiver is securely plugged into a working USB port. Try a different USB port.
Mouse not responding (Bluetooth)	Not paired or out of range	Ensure Bluetooth is enabled on your device. Re-enter pairing mode on the mouse (hold mode switch button) and re-pair with your device. Ensure mouse is within 10 meters of the device.
Cursor erratic or jumpy	Dirty optical sensor or unsuitable surface	Clean the optical sensor on the bottom of the mouse. Use the mouse on a clean, non-reflective, and uniform surface.
Side keys not working	Application specific or driver issue	Ensure the application supports forward/backward navigation. For advanced customization, check your operating system's mouse settings or any available manufacturer software (if applicable).

If the problem persists after trying these solutions, please contact customer support for further assistance.

Specifications

Feature	Detail
Brand	FMOUSE
Model Number	cd2 -963
Connectivity Technology	Bluetooth 5.1 (Dual), 2.4G Wireless (USB)
Movement Detection Technology	Optical
Adjustable DPI	800 / 1200 / 1600 / 2400
Special Features	Wireless, Bluetooth, Silent Click, Rechargeable, Ergonomic
Battery Type	1 Lithium Ion battery (included)
Battery Capacity	400mAh

Feature	Detail
Charging Port	USB-C
Product Dimensions	3.94 x 2.56 x 0.1 inches (100x65x34mm)
Item Weight	2.33 ounces (68g ± 5g)
Color	Black
Compatibility	Windows, MacOS, iPadOS, ChromeOS, Linux

Warranty and Support

FMOUSE products are manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or customer service, please refer to the contact details provided on the product packaging or visit the official FMOUSE website. Please retain your proof of purchase for warranty claims.

© 2024 FMOUSE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C95XGB71

More documents and user manuals: **https://manuals.plus/**