Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MObyat 623268

MObyat 8L Multi-functional Air Fryer User Manual

Model: 623268
Brand: MObyat

Introduction

Thank you for purchasing the MObyat 8L Multi-functional Air Fryer. This appliance is designed to provide a healthy and convenient way to cook a variety of dishes, from frying to baking, with minimal oil. Please read this manual thoroughly before first use to ensure safe and optimal operation.

Important Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Read all instructions before use.
- Do not immerse the cord, plug, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- Do not block any ventilation openings.

Product Overview

Familiarize yourself with the components of your MObyat 8L Multi-functional Air Fryer.



Figure 1: Top view of the MObyat 8L Multi-functional Air Fryer, showcasing its digital control panel and transparent lid.



Figure 2: Side view of the MObyat 8L Multi-functional Air Fryer, highlighting the integrated handle for easy lifting of the lid.

Main Components:

- **Main Unit:** Houses the heating element and fan.
- **Cooking Pot:** Large capacity pot for food.
- **Transparent Lid:** Allows for visible cooking progress.
- **Digital Control Panel:** Touch screen interface for setting time, temperature, and cooking modes.
- **Handle:** Ergonomic handle for safe handling of the lid.

Setup

1. **Unpacking:** Carefully remove all packaging materials from the air fryer.
2. **Cleaning:** Before first use, clean the cooking pot and lid with warm soapy water. Wipe the main unit with a damp cloth. Ensure all parts are completely dry before assembly.

3. **Placement:** Place the air fryer on a stable, flat, heat-resistant surface, away from walls and other appliances to allow for proper air circulation. Ensure there is at least 10 cm (4 inches) of clear space on all sides.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

Operating Instructions

Basic Operation:

1. **Prepare Food:** Place your ingredients into the cooking pot. Do not overfill the pot; ensure there is enough space for air to circulate.
2. **Close Lid:** Securely close the transparent lid.
3. **Power On:** Press the power button on the digital control panel.
4. **Set Temperature and Time:** Use the touch controls to adjust the desired cooking temperature and time. The display will show the current settings.
5. **Start Cooking:** Press the start button to begin the cooking cycle. The air fryer will preheat if necessary, then begin cooking.
6. **Monitor Progress:** The transparent lid allows you to visually monitor the cooking process.
7. **Shake/Flip (Optional):** For even cooking, especially with items like fries or chicken wings, you may pause the cooking cycle to shake or flip the food. Use heat-resistant tongs or gloves.
8. **Cooking Complete:** The air fryer will beep when the cooking time is complete. Carefully open the lid and remove the food.
9. **Power Off:** Press the power button to turn off the appliance and unplug it from the outlet.

Pre-set Functions:

The air fryer features several pre-set cooking functions for common dishes. Refer to the icons on the control panel for specific programs. Simply select the desired program, and the air fryer will automatically set the optimal temperature and time.



Figure 3: Digital control panel and features, including 24-hour reservation, no oil/smoke operation, smart power-off memory, 8 smart menus, non-stick inner pot, 360-degree even heating, 270-degree panoramic window, and high borosilicate explosion-proof glass.



Figure 4: The 270-degree panoramic viewing window allows for easy monitoring of food during cooking without opening the lid.

Maintenance and Cleaning

Regular cleaning will ensure the longevity and optimal performance of your air fryer.

1. **Unplug and Cool:** Always unplug the appliance and allow it to cool completely before cleaning.
2. **Cleaning the Cooking Pot and Lid:** The cooking pot and transparent lid are non-stick and can be washed with warm soapy water. Use a soft sponge or cloth to avoid damaging the non-stick coating. Rinse thoroughly and dry completely.
3. **Cleaning the Main Unit:** Wipe the exterior of the main unit with a damp cloth. Do not use abrasive cleaners or immerse the main unit in water.
4. **Storage:** Store the air fryer in a cool, dry place when not in use.

Troubleshooting

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; power outlet malfunction; appliance malfunction.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker. If problem persists, contact customer support.
Food is not cooked evenly.	Overcrowding the basket; insufficient shaking/flipping; incorrect temperature/time.	Do not overcrowd the cooking pot. Shake or flip food halfway through cooking. Adjust temperature and time as needed for specific recipes.
White smoke coming from the appliance.	Grease residue from previous use; high-fat food being cooked.	Clean the cooking pot thoroughly after each use. For high-fat foods, drain excess fat during cooking.
Appliance smells during first use.	Normal for new appliances.	This is normal and will dissipate after a few uses. Ensure good ventilation.

Specifications

Brand: MObyat

Model Number: 623268

Capacity: 8 Liters

Color: Touch Screen Green

Item Weight: 5 kg (5000 Grams)

Recommended Uses: Bake, Fry, Roast, Skewer

Control Type: Digital Touch Screen

Special Features: Visible cooking, Lampblack-free, Smart power-off memory, 360° uniform heating, 270° panoramic viewing window, High borosilicate explosion-proof glass.

Warranty and Support

This MObyat product comes with a standard manufacturer's warranty against defects in materials and workmanship under normal use. Please refer to your purchase documentation for specific warranty terms and duration.
For technical support, troubleshooting assistance, or warranty claims, please contact your retailer or the MObyat customer service department. Keep your proof of purchase for warranty validation.
Note: Accidental damage and extended warranty plans may be available for purchase separately. Please check with your retailer for details.

© 2024 MObyat. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C96SN6TZ

More documents and user manuals: **https://manuals.plus/**