Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

T4TREAM 60-inch 4-Drawer Dresser

T4TREAM 60-inch Farmhouse Dresser Instruction Manual

Model: 60-inch 4-Drawer Dresser (Antique White)

T4TREAM: Creating pleasant living atmospheres.

1. Introduction

Thank you for choosing the T4TREAM 60-inch Farmhouse Dresser. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.

This dresser combines farmhouse aesthetics with practical storage, featuring four central drawers and two side cabinets with sliding barn doors and adjustable shelving. It is designed for versatile use in various living spaces.



Image 1.1: The T4TREAM 60-inch Farmhouse Dresser in an antique white finish, showcasing its design and functionality in a bedroom setting.

2. Safety Information

Your safety is paramount. Please adhere to the following guidelines:

- **Tip-Over Prevention:** Furniture tip-overs can cause serious or fatal injuries. Always secure this unit to a wall using the provided anti-tip hardware. Ensure the wall anchor is properly installed into a sturdy wall stud or appropriate wall material.
- **Weight Limits:** The thickened top surface can support up to 150 lbs (68 kg). Each drawer holds up to 25 lbs (11.3 kg). Do not exceed these weight limits. Distribute weight evenly.
- **Assembly Safety:** Assemble the unit on a soft, clean surface to prevent scratches. Keep small parts away from children. Two people are recommended for assembly.
- **Material Safety:** This dresser is made from FSC-Certified wood and premium P2 manufactured wood. It is designed to be scratch-resistant and has no strong odor.

- **Stability:** Ensure the dresser is placed on a level surface. If the unit appears unlevel after assembly, check the placement of the included metal feet. Adjust as necessary to ensure stability.

3. Package Contents

Before assembly, verify that all components and hardware are present. Each part and accessory is identified with numbered stickers for easy recognition. A pack of spare parts is included in case of loss during assembly.

Refer to the detailed installation instructions provided in the box for a complete list of parts and hardware. If any parts are missing or damaged, please contact customer service immediately.

4. Assembly Instructions

Follow the detailed installation instructions included with your product. These instructions contain step-by-step diagrams and guidance for proper assembly.

1. **Preparation:** Clear a spacious area for assembly. Lay out all parts and hardware. Use a screwdriver for assembly; power tools may overtighten and damage components.
2. **Frame Assembly:** Construct the main frame of the dresser according to the diagrams. Ensure all connections are secure.
3. **Drawer Installation:** Assemble the four drawers. Ensure the drawer slides are correctly oriented and operate smoothly.
4. **Sliding Barn Doors:** Install the metal track and attach the barn doors. Test the smooth-glide mechanism.
5. **Adjustable Shelves:** Insert the adjustable shelves into the side cabinets at your desired height.
6. **Final Touches:** Apply the wood grain looking stickers over exposed screws for a finished appearance. Install the anti-tip hardware to a wall stud.

Note on Drawer Knobs and Barn Doors: In some cases, the original drawer knobs may interfere with the sliding barn doors, preventing them from opening fully. If this occurs, consider replacing the knobs with flatter ones to ensure proper clearance and functionality of the sliding doors.



Image 4.1: Detailed dimensions of the dresser, including overall measurements (W60" x D15.75" x H31.2") and individual drawer dimensions (16.2"W x 12"D x 4.1"H).

5. Operating Instructions

Your T4TREAM dresser is designed for ease of use and versatile storage.

- **Drawers:** The four central drawers feature smooth-glide mechanisms for easy opening and closing. Use them to store smaller items like socks, t-shirts, or personal accessories.
- **Sliding Barn Doors:** The two side cabinets are accessed via space-saving sliding barn doors. Gently slide the doors along the metal track to reveal or conceal the storage compartments.
- **Adjustable Shelves:** Each side cabinet contains two adjustable shelves. These shelves can be set at three different heights or removed entirely to accommodate items of various sizes, such as linens, throw blankets, or kitchenware.



Image 5.1: Close-up view of the smooth-glide sliding barn door mechanism.



Image 5.2: Illustration of the adjustable shelf feature within the side cabinet.

Versatile Use

This dresser is designed to function as a multi-purpose storage organizer. It can be used in:

- **Bedroom:** For clothing, linens, and personal items.
- **Living Room:** As a TV stand or for storing media, blankets, and decorative items.
- **Kitchen/Dining Room:** For dishes, pantry items, or serving accessories.



Image 5.3: Examples of the dresser's versatile application in a bedroom, living room (as a TV stand), and kitchen/dining room.

6. Maintenance

To ensure the longevity and appearance of your dresser, follow these maintenance tips:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the distressed finish.
- **Spills:** Clean spills immediately to prevent staining.
- **Stability Check:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the finish.

7. Troubleshooting

If you encounter any issues with your dresser, refer to the following common problems and solutions:

- **Problem:** Sliding barn doors do not open fully or get stuck.
  Solution: Check if the drawer knobs are obstructing the path of the sliding doors. If so, consider replacing the knobs with flatter alternatives or adjusting their position if possible. Ensure the metal track is clean and free of debris.
- **Problem:** The dresser feels unstable or unlevel.
  Solution: Verify that the dresser is placed on a flat, even surface. Check the installation of the metal feet; ensure they are correctly positioned. If necessary, use shims under the back legs to level the unit. Confirm the anti-tip hardware is securely installed.
- **Problem:** Missing or damaged parts during assembly.
  Solution: Refer to the parts list in your assembly instructions. If parts are missing or defective, do not proceed with assembly. Contact T4TREAM customer service for assistance.
- **Problem:** Drawers do not slide smoothly.
  Solution: Ensure the drawer slides are correctly installed and aligned. Check for any obstructions in the tracks. Apply a silicone-based lubricant if necessary.

8. Specifications

Feature	Detail
Brand	T4TREAM
Model	60-inch 4-Drawer Dresser
Color	Antique White
Product Dimensions (D x W x H)	15.75" x 60" x 31.25"
Drawer Dimensions (W x D x H)	16.2" x 12" x 4.1"
Material	Engineered Wood (FSC-Certified P2 manufactured wood)
Top Surface Weight Capacity	Up to 150 lbs (68 kg)
Drawer Weight Capacity	Up to 25 lbs (11.3 kg) per drawer
Number of Drawers	4
Number of Adjustable Shelves	2 (3 height adjustable positions)
Assembly Required	Yes

9. Warranty and Support

T4TREAM is committed to providing high-quality products and excellent customer service. This product comes with a manufacturer's warranty covering defects in materials and workmanship. Please refer to the warranty information provided with your purchase for specific terms and conditions.

If you encounter any problems with your product, require replacement parts, or have questions regarding assembly or operation, please do not hesitate to contact T4TREAM customer support. Our team is ready to assist you.

Contact Information: Please refer to the contact details provided on your purchase receipt or the T4TREAM official website for the most up-to-date customer service information.

© 2025 T4TREAM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C973HYP6

More documents and user manuals: **https://manuals.plus/**