T4TREAM B0C973RJ6T

T4TREAM Farmhouse Dresser with Sliding Barn Doors - Instruction Manual

Model: B0C973RJ6T
Brand: T4TREAM

Introduction

Thank you for choosing the T4TREAM Farmhouse Dresser with Sliding Barn Doors. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure safe and efficient use of your new furniture. This 48-inch wide chest of drawers combines farmhouse aesthetics with practical storage, featuring four drawers and versatile sliding barn doors.



Figure 1: T4TREAM Farmhouse Dresser with Sliding Barn Doors, Antique White.

Important Safety Information

Please read and understand all instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Assemble furniture carefully, ensuring stability.
- Keep the dresser away from children when drawers are open to avoid tip-over risks. Always use the included anti-tip kit to secure the dresser to a wall.
- Do not overload drawers or shelves. Each drawer holds up to 25 lbs, and the top surface supports up to 100 lbs.
- Ensure all connections are tight before use. Periodically check and re-tighten fasteners as needed.

Components and Hardware

Before beginning assembly, verify that all parts and hardware are present and undamaged. Refer to the included parts list and hardware pack for identification.

- 1 x Chest Frame
- 4 x Drawers (2 large, 2 small)
- 2 x Sliding Barn Doors
- 1 x Step-by-Step Instruction Manual
- 1 x Hardware Pack (includes screws, dowels, drawer slides, barn door track, handles, and anti-tip kit)
- Adjustable/Removable Shelves for the barn door compartments



Figure 2: Product dimensions and internal structure, showing drawers and shelves.

Assembly Instructions

Assembly is required. It is recommended to have two people for assembly. Follow the detailed step-by-step instructions

provided in the included manual. All parts and accessories are labeled with numbers for accurate and faster installation.

1. **Prepare the Area:** Clear a spacious, clean, and flat area for assembly. Lay out all components and hardware, matching them to the labels in the instruction manual.
2. **Assemble the Main Frame:** Connect the side panels, back panel, and base using the designated hardware. Ensure all connections are secure.
3. **Install Drawer Slides:** Attach the drawer slides to the interior of the dresser frame according to the manual's diagrams.
4. **Assemble Drawers:** Construct the four drawers. Pay close attention to the orientation of the drawer sides and bottoms. Install the drawer pulls.
5. **Insert Drawers:** Carefully slide the assembled drawers onto their respective slides. Ensure they glide smoothly.
6. **Install Barn Door Track:** Secure the metal barn door track to the top front of the dresser frame.
7. **Attach Barn Doors:** Hang the two barn doors onto the track. Ensure they slide freely.
8. **Install Interior Shelves:** Place the adjustable shelves within the barn door compartments. Adjust height as desired.
9. **Final Checks:** Verify all screws and fasteners are tightened. Attach the anti-tip kit to the dresser and secure it to a wall for safety.



Figure 3: Illustration of the sliding barn doors, adjustable shelves, and smooth-gliding drawers.

Operating Instructions

Your T4TREAM dresser is designed for versatile storage and easy access.

- **Drawers:** The dresser features four smooth-gliding drawers in two sizes (two 12"W x 12"D x 5.7"H and two 19.4"W x 12"D x 5.7"H). Pull the handles gently to open and push to close. Avoid forcing drawers.
- **Sliding Barn Doors:** The two barn doors slide smoothly on a metal track. You can position them to cover the central drawers or reveal the shelved compartments on either side. This allows for flexible storage and display options.
- **Adjustable Shelves:** The shelves within the barn door compartments are adjustable to three different heights and are removable. To adjust, carefully lift the shelf, remove the support pins, reposition the pins to the desired height, and then place the shelf back on the pins.
- **Top Surface:** The thickened tabletop surface can support up to 100 lbs, suitable for decorative items, lamps, or a television.



Figure 4: Flexible and spacious storage options of the dresser.

Maintenance

Proper care will extend the life and appearance of your dresser.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as they may damage the finish.
- **Dusting:** Regularly dust with a dry, soft cloth.
- **Spills:** Blot spills immediately with a clean, dry cloth.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration.
- **Temperature and Humidity:** Maintain a stable room temperature and humidity to prevent wood warping or cracking.
- **Hardware:** Periodically check and tighten all screws and fasteners to ensure stability.

Troubleshooting

Problem	Possible Cause	Solution
Drawers do not slide smoothly.	Misaligned drawer slides or loose hardware.	Check that drawer slides are correctly aligned and all screws are tightened. Ensure drawers are not overloaded.
Sliding barn doors stick or do not move freely.	Track obstruction, misaligned doors, or loose track hardware.	Inspect the track for debris. Ensure the doors are properly seated on the track. Verify all track hardware is securely fastened. (Note: Some users have reported issues with screws on glides obstructing movement; ensure flat screws are used if this occurs).
Dresser feels unstable or wobbly.	Loose assembly hardware or uneven floor.	Re-tighten all assembly screws. Ensure the dresser is on a level surface. Use the anti-tip kit to secure it to a wall.
Missing parts or damaged components.	Shipping damage or packaging error.	Contact T4TREAM customer service with your purchase details for replacement parts.

Specifications

Brand: T4TREAM

Model: B0C973RJ6T

Color: Antique White

Product Dimensions: 15.75"D x 48"W x 31.25"H

Special Feature: Adjustable Shelf

Mounting Type: Freestanding

Room Type: Laundry Room, Bedroom, Living Room, Kid's Room, Nursery

Finish Type: Rustic

Number of Pieces: 1

Base Type: Legs

Assembly Required: Yes

Material: FSC-Certified wood, premium P2 manufactured wood

Drawer Weight Capacity: Up to 25 lbs per drawer

Top Surface Weight Capacity: Up to 100 lbs

Warranty and Support

T4TREAM is committed to providing high-quality products. For any questions, missing parts, or assistance with assembly or operation, please contact T4TREAM customer service. Refer to your purchase documentation for specific warranty details and contact information.
Additional protection plans may be available for purchase through your retailer to extend coverage beyond the standard warranty.
Visit the official T4TREAM Store for more products and information:T4TREAM Furniture Store

© 2025 T4TREAM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question