Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

T4TREAM 15.8"D x 31.3"W x 48"H (5 Drawers) Dark Rustic Oak

T4TREAM 5-Drawer Dresser Instruction Manual

Model: 15.8"D x 31.3"W x 48"H (5 Drawers) Dark Rustic Oak
Brand: T4TREAM

1. Safety Information

For your safety and to prevent damage to the product, please read and follow all instructions carefully.

WARNING: Keep heavy or breakable items on lower drawers to reduce the risk of the dresser tipping.
Always ensure the dresser is placed on a flat, stable surface. Use anti-tip hardware if provided, and secure the unit to a wall according to the instructions.

2. Product Overview

The T4TREAM 5-Drawer Dresser with Sliding Barn Door is a versatile storage solution designed with a farmhouse aesthetic. It combines the utility of drawers with adjustable shelving behind a unique sliding barn door.

- **Dimensions:** 31.25"W x 15.57"D x 48"H
- **Storage:** Features 5 drawers and a space-saving sliding barn door with 2 adjustable shelves.
- **Material:** Constructed from durable engineered wood with a rustic finish.
- **Weight Capacity:** Each drawer holds up to 25 lbs, and the top surface supports up to 100 lbs.



Figure 2.1: Front view of the T4TREAM 5-Drawer Dresser in Dark Rustic Oak.



Figure 2.2: Detailed dimensions of the dresser and its drawers.

3. Setup and Assembly

This dresser requires assembly. Please ensure you have sufficient space and the necessary tools before beginning. It is recommended to have two people for assembly.

3.1 Unpacking and Inventory

1. Carefully unpack all components from the packaging.
2. Verify all parts and accessories are present by comparing them with the included parts list in your detailed instruction manual. All parts are labeled with numbers for easy identification.
3. Inspect all pieces for any damage. Contact customer support immediately if any parts are missing or damaged.

3.2 Assembly Steps

Follow the step-by-step instructions provided in the separate detailed assembly manual. Precise holes are pre-drilled to ensure accurate and faster installation. Ensure all screws and fasteners are tightened securely, but do not overtighten.

Important: Attach the anti-tip hardware to the dresser and wall as instructed to prevent accidental tipping, especially in households with children or pets.

4. Operating Instructions

The T4TREAM dresser is designed for ease of use and flexible storage.

4.1 Sliding Barn Door Operation

The barn door slides smoothly along a metal track, allowing you to conceal or reveal the adjustable shelf space. To open or close, gently grasp the handle and slide the door horizontally along the track.

4.2 Adjustable Shelves

The two shelves behind the barn door are adjustable to 3 different heights. They can also be removed entirely to accommodate larger items. To adjust or remove a shelf:

1. Empty the shelf of all contents.
2. Carefully lift the shelf and pull it out from its supports.
3. Reinsert the shelf into the desired height by aligning it with the pre-drilled holes and pushing it firmly onto the shelf pins.

4.3 Drawer Usage

The five drawers are designed for smooth gliding. Pull the drawer handles to open and push to close. Ensure drawers are fully closed to maintain a tidy appearance and prevent accidental opening.



Figure 4.1: Features including the sliding barn door mechanism, adjustable shelves, and smooth-gliding drawers.

5. Maintenance and Care

Proper care will help maintain the appearance and longevity of your T4TREAM dresser.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- **Spills:** Blot spills immediately with a clean, dry cloth.

- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration.
- **Heat and Moisture:** Keep the dresser away from direct heat sources and excessive moisture. Use coasters under beverages to prevent water rings.
- **Hardware:** Periodically check and tighten all screws and fasteners to ensure stability.

6. Troubleshooting

Problem	Possible Cause	Solution
Sliding barn door does not move smoothly or gets stuck.	Obstruction on the track. Track or rollers are dirty. Screws attaching glides to the door are protruding too far and catching on internal components (as noted by some users).	Clear any debris from the track. Clean the track and rollers with a soft, dry cloth. Inspect the screws on the bottom of the sliding door that attach to the glides. If they protrude, consider replacing them with flat-head screws of appropriate length to prevent interference with internal structures.
Drawers do not slide smoothly.	Drawer glides are dirty or obstructed. Drawer is overloaded. Hardware is loose.	Clean drawer glides. Reduce the weight in the drawer. Check and tighten all drawer hardware.
Dresser feels wobbly or unstable.	Not all fasteners are tightened. Dresser is not on a level surface. Anti-tip hardware not installed or secured.	Ensure all assembly fasteners are fully tightened. Adjust the dresser's position or use shims to level it. Install and properly secure the anti-tip hardware to a wall stud.

7. Specifications

Brand	T4TREAM
Model	15.8"D x 31.3"W x 48"H (5 Drawers)
Color	Dark Rustic Oak
Product Dimensions	15.75"D x 31.25"W x 48"H
Room Type	Bedroom, Hallway, Kid's Room, Living Room
Material	Engineered Wood
Assembly Required	Yes
Drawer Capacity (each)	Up to 25 lbs

Top Surface Capacity	Up to 100 lbs

8. Warranty and Support

T4TREAM is committed to providing high-quality products and customer satisfaction.

8.1 Customer Support

If you have any questions about your product, assembly, or require assistance, please do not hesitate to contact our customer service team. We aim to provide a satisfactory answer within 24 hours.

For support, please refer to the contact information provided in your product packaging or visit the official T4TREAM store on Amazon: T4TREAM Store.

8.2 Protection Plans

Extended protection plans may be available for your product. Please check the product listing on Amazon for details on available 2-Year, 3-Year, or Complete Protect plans.

© 2025 T4TREAM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C974QY4B

More documents and user manuals: **https://manuals.plus/**