Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LG MFG63099101

LG Washing Machine Door Latch Installation Guide

Part Number: **MFG63099101**

1. Introduction

This document provides instructions for the safe and correct installation of the LG Washing Machine Door Latch, part number MFG63099101. This component is essential for securing the washing machine door during operation, ensuring proper function and safety.





Figure 1: Front view of the LG Washing Machine Door Latch (MFG63099101).

2. Safety Information

Before beginning any repair or installation, please observe the following safety precautions:

- **Disconnect Power:** Always unplug the washing machine from the electrical outlet before performing any service or maintenance.
- **Wear Protective Gear:** It is recommended to wear work gloves to protect your hands from sharp edges or components.
- **Follow Instructions:** Read all instructions carefully before proceeding.
- **Professional Assistance:** If you are unsure about any step, consult a qualified technician.

3. Tools Required

The following tools may be necessary for the installation of the door latch:

- Phillips head screwdriver
- Flathead screwdriver (optional, for prying if needed)

4. Installation (Setup)

Follow these steps to replace the washing machine door latch:

1. **Disconnect Power:** Ensure the washing machine is unplugged from the wall outlet.
2. **Open Washer Door:** Fully open the washing machine door to access the latch mechanism.
3. **Locate Existing Latch:** Identify the current door latch, typically located on the inner frame of the washing machine door opening.
4. **Remove Fasteners:** Using a Phillips head screwdriver, carefully remove any screws or fasteners securing the old door latch in place. There may be one or two screws.
5. **Detach Old Latch:** Gently pull the old latch away from its mounting position. Note its orientation for installing the new part.
6. **Position New Latch:** Align the new LG Door Latch (MFG63099101) into the mounting slot, ensuring it is oriented correctly.
7. **Secure New Latch:** Insert and tighten the screws or fasteners removed in step 4 to secure the new latch firmly. Do not overtighten.
8. **Close and Test Door:** Gently close the washing machine door to ensure the latch engages properly. The door should close securely without excessive force.
9. **Reconnect Power:** Once the latch is securely installed and the door closes correctly, plug the washing machine back into the electrical outlet.



Figure 2: Side view of the door latch, illustrating the mounting point.

5. Operating (Post-Installation Check)

After installation, perform the following checks:

- **Door Closure:** Ensure the washing machine door closes completely and latches securely with a gentle push.
- **Cycle Start:** Start a short wash cycle (e.g., rinse and spin) to confirm that the machine recognizes the door is closed and begins operation without displaying a door error code.

6. Maintenance

To ensure the longevity and proper function of your door latch:

- **Avoid Force:** Do not slam the washing machine door. Close it gently.

- **Keep Clean:** Periodically wipe the latch area clean to prevent buildup of detergent residue or lint, which could interfere with its operation.

7. Troubleshooting

If you encounter issues after replacing the door latch, consider the following:

- **Door Not Latching:** Check if the latch is correctly aligned and securely fastened. Ensure no obstructions are preventing the door from closing fully.
- **Door Error Code (e.g., "dE"):** If the washing machine displays a door error code, verify that the latch is properly installed and that the door is fully closed. If the issue persists, there may be an issue with the door lock switch (a separate component) or wiring, which may require professional service.
- **Door Difficult to Open/Close:** Ensure the latch is not bent or obstructed. Recheck installation for proper alignment.

8. Specifications

Part Number	MFG63099101
Brand	LG
Dimensions	Approximately 9.9 x 6.4 x 2.5 cm (3.9 x 2.5 x 1.0 inches)
Weight	Approximately 20 g (0.7 oz)

Compatible Models:

This door latch is compatible with a range of LG washing machine models. Please verify your specific model number against the list below. If your model is not listed, consult your appliance's service manual or contact LG support.

- WD10SB6.AESELAT, WD10WB6.ABWELAT, WD12SB6.AESELAT, WD12SB6D.AESELAT, WD12VVC3S6C.ASSELAT, WD12VVC4S6S.ASSELAT, WD12WVC4S6.ABWELAT, WD16SG2S6.AESELAT, WD16WG2S6.ABWELAT, WD20VV2S6.ASSELAT, WD20WV2S6.ABWELAT, WD22BV2S6.ABLELAT, WD22RV2S6.ACRELAT, WD22VV2S6.ASSELAT, WD22WV2S6.ABWELAT, WM12WVC4S6.ABWELAT, WM20VVS6.ASSELAT, WM20VVS6.ASSELAT
- WM20WV26.ABWELAT, WM20WV26.ABWELAT, WM20WV26W.ABWELAT, WM20WV6.ABWELAT, WM20WV6.ABWELAT, WM22RV2S6.ACRELAT, WM22RV2S6.ACRELAT, WM22VV2S6.ASSELAT, WM22VV2S6B.ASSELAT, WM22VVS6.ASSELAT, WM22VVS6.ASSELAT, WM22WV26.ABWELAT, WM22WV26.ABWELAT, WM22WV6.ABWELAT, WM22WV6.ABWELAT, WM3570HVA.ASSELAT, WM3570HVA.ASSELAT, WM3770HVA.ASSEVUS, WM3770HVA.ASSEVUS, WM4270HVA.ASSELAT, WM4270HVA.ASSELAT

9. Warranty Information

This LG replacement part is typically covered by LG's standard manufacturer warranty. For specific details regarding warranty coverage, duration, and terms, please refer to the documentation that came with your original appliance or visit the official LG website. Keep your purchase receipt as proof of purchase.

10. Customer Support

If you require further assistance, have questions about installation, or need to troubleshoot issues not covered in this guide, please contact LG Customer Service. You can find contact information on the official LG website or in your appliance's user manual.
LG Official Website: www.lg.com

© 2023 LG Electronics. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C9C6SLVP

More documents and user manuals: **https://manuals.plus/**