**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**Acer VG271U M3bmiipx**

# Acer VG271U M3bmiipx 27-inch WQHD IPS Gaming Monitor User Manual

Model: VG271U M3bmiipx

## 1. Introduction

This manual provides essential information for the safe and efficient use of your Acer VG271U M3bmiipx 27-inch WQHD IPS Gaming Monitor. Please read it thoroughly before operating the device and retain it for future reference. This monitor is designed to deliver a high-quality visual experience for gaming and general computing tasks.

## 2. Safety Information

Observe the following safety precautions to prevent damage to the monitor and ensure user safety:

- Always place the monitor on a stable, level surface.
- Do not block ventilation openings.
- Use only the power adapter and cables supplied by Acer.
- Avoid exposing the monitor to extreme temperatures, humidity, or direct sunlight.
- Do not attempt to service the monitor yourself. Refer all servicing to qualified personnel.
- Disconnect the power cord from the outlet before cleaning.

## 3. Package Contents

Verify that all items are present in the package:

- Acer VG271U M3bmiipx Monitor
- Monitor Stand (Base and Neck)
- Power Cord
- HDMI Cable
- DisplayPort Cable
- User Manual (this document)

## 4. Setup

### 4.1 Assembling the Monitor Stand

1. Carefully remove the monitor from its packaging, keeping the screen protected.
2. Attach the stand neck to the monitor panel. Ensure it clicks securely into place or is fastened with screws if provided.
3. Attach the stand base to the stand neck. Tighten the thumb screw or screws from the bottom of the base.
4. Place the assembled monitor on a stable, flat surface.

### 4.2 Connecting the Monitor

Connect the monitor to your computer and power source using the provided cables.

- **Power Connection:** Connect the power cord to the monitor's power input and then to a wall outlet.
- **Video Connection:** Connect either the HDMI cable or the DisplayPort cable from your computer's graphics card to the corresponding input port on the monitor. For optimal performance, DisplayPort is recommended for 180Hz refresh rates.




Front view of the Acer VG271U M3bmiipx monitor, showcasing its slim bezels and the distinctive blue and black stand.

## 5. Operating the Monitor

### 5.1 Power On/Off

Press the power button, usually located on the bottom right or rear of the monitor, to turn the monitor on or off. The power indicator light will illuminate when the monitor is on.

### 5.2 On-Screen Display (OSD) Menu

The OSD menu allows you to adjust various monitor settings. Access it by pressing one of the control buttons, typically located on the bottom or rear of the monitor. Navigate through the menu using the directional buttons and confirm selections with the appropriate button.
Common OSD settings include:

- **Picture:** Brightness, Contrast, Color Temperature, Gamma.
- **Color:** Color modes, sRGB, User Defined.
- **Audio:** Volume control (if speakers or headphone jack are present).
- **Gaming:** Overdrive, FreeSync/G-Sync compatibility settings, Refresh Rate display.
- **Input:** Select between HDMI and DisplayPort inputs.
- **System:** Language, OSD Timeout, Reset to Factory Defaults.

### 5.3 Key Features

- **WQHD Resolution (2560 x 1440):** Provides sharp and detailed images.
- **180Hz Refresh Rate:** Offers smoother motion for gaming and fast-paced content.
- **IPS Panel:** Delivers wide viewing angles and accurate color reproduction.

## 6. Maintenance

### 6.1 Cleaning the Monitor

To clean the monitor, first disconnect the power cord. Use a soft, lint-free cloth lightly dampened with water or a non-abrasive screen cleaner. Do not spray cleaner directly onto the screen. Avoid using harsh chemicals or abrasive materials.

## 7. Troubleshooting

If you encounter issues with your monitor, refer to the following common problems and solutions:

- **No Power:** Ensure the power cord is securely connected to both the monitor and the power outlet. Check if the power outlet is functional.
- **No Image:** Verify that the video cable (HDMI or DisplayPort) is correctly connected to both the monitor and the computer. Ensure the correct input source is selected in the OSD menu. Check if the computer is powered on and not in sleep mode.
- **Flickering or Distorted Image:** Check the video cable for damage or loose connections. Try a different video cable or port. Ensure your graphics card drivers are up to date.
- **Incorrect Resolution/Refresh Rate:** Adjust the display settings in your computer's operating system. For Windows, right-click on the desktop, select 'Display settings' > 'Advanced display settings' > 'Display adapter properties' to set resolution and refresh rate.
- **OSD Menu Not Appearing:** Ensure the monitor is powered on. Try pressing different control buttons to activate the OSD.

## 8. Specifications

| Feature | Specification |
|---|---|
| Model Number | VG271U M3bmiipx |
| Screen Size | 27 Inches |

| | |
|---|---|
| Panel Type | IPS |
| Resolution | 2560 x 1440 (WQHD) |
| Aspect Ratio | 16:9 |
| Refresh Rate | 180Hz |
| Screen Surface | Glossy |
| Video Inputs | HDMI, DisplayPort |

## 9. Warranty and Support

Your Acer VG271U M3bmiipx monitor comes with a limited warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty duration and coverage details. For technical support, driver downloads, or service inquiries, please visit the official Acer support website or contact Acer customer service in your region.

**Acer Support Website:** www.acer.com/support


## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

**Open the live page**

**https://manuals.plus/asin/B0C9F6X9NJ**

More documents and user manuals: **https://manuals.plus/**