Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Butterfly 2-Liter

Butterfly Peerless 3-Stone Wet Grinder User Manual

Model: 2-Liter, 110V

For USA & Canada

1. Introduction

Thank you for choosing the Butterfly Peerless 3-Stone Wet Grinder. This appliance is designed for efficient wet grinding of various ingredients, and comes with an Atta Kneader and Coconut Scraper for added versatility. Please read this manual carefully before operating the grinder to ensure safe and optimal performance.

Important Safety Instructions

- Always ensure the grinder is placed on a stable, flat surface.
- Do not immerse the motor unit in water or any other liquid.
- Keep hands and utensils away from moving parts during operation.
- Unplug the appliance from the power outlet when not in use, before assembling or disassembling parts, and before cleaning.
- This appliance is for household use only.
- Ensure the voltage rating of the appliance matches your local power supply (110V for USA & Canada).

2. Setup and Assembly

2.1 Unpacking and Initial Inspection

1. Carefully remove all components from the packaging.
2. Check for any damage during transit. If any damage is found, do not operate the appliance and contact customer support.
3. Verify all included components are present: Grinder unit, Stainless Steel Drum, 3 Conical Grinding Stones, Atta Kneader, Coconut Scraper, Transparent Lid, and User Manual.

2.2 Assembling the Grinder

1. Place the main motor unit on a stable, dry surface.
2. Insert the stainless steel drum into the designated slot on the motor unit. Ensure it is seated firmly.
3. Place the grinding stone assembly into the drum, ensuring the central shaft aligns with the motor coupling.
4. Cover the drum with the transparent polycarbonate lid.



Figure 1: Assembled Butterfly Peerless Wet Grinder with Coconut Scraper.

2.3 Initial Cleaning

Before first use, wash the stainless steel drum, grinding stones, atta kneader, coconut scraper, and lid with mild soap and water. Rinse thoroughly and dry completely.

2.4 Power Connection

Plug the power cord into a grounded 110V AC power outlet. Ensure the power switch on the unit is in the 'OFF' position before plugging in.

3. Operating Instructions

3.1 Wet Grinding

1. Ensure the grinding stone assembly is correctly placed inside the drum.
2. Add pre-soaked and drained ingredients (e.g., rice, lentils) into the drum. Do not overload the drum beyond its 2-liter capacity.
3. Pour a small amount of water into the drum. Add water gradually as needed during grinding to achieve the desired consistency.
4. Secure the transparent lid onto the drum.
5. Press the power button to start the grinder. The 3 conical stones will rotate, grinding the ingredients uniformly.
6. Allow the grinder to operate until the desired texture is achieved. Grinding times vary based on ingredients and desired fineness.
7. Once grinding is complete, press the power button to turn off the grinder.
8. Carefully remove the lid, then lift out the grinding stone assembly. Scrape off any remaining batter from the stones and drum.



Figure 2: Patented 3 conical grinding stones inside the drum.



Figure 3: Removing the grinding stone assembly.

3.2 Using the Atta Kneader

1. Ensure the grinder is unplugged. Remove the grinding stone assembly from the drum.
2. Attach the Atta Kneader accessory to the central shaft in the drum. Ensure it is securely fitted.
3. Add flour and water in appropriate proportions to the drum.
4. Secure the transparent lid.

5. Plug in the grinder and press the power button to start kneading.
6. Allow the kneader to operate until the dough reaches the desired consistency.
7. Turn off and unplug the grinder. Remove the kneader and dough.



Figure 4: Atta Kneader attachment for dough preparation.

3.3 Using the Coconut Scraper

1. Ensure the grinder is unplugged. Remove the grinding stone assembly or atta kneader.
2. Attach the Coconut Scraper accessory to the central shaft in the drum. Ensure it is securely fitted.
3. Secure the transparent lid.
4. Plug in the grinder and press the power button to start the scraper.
5. Hold a half coconut shell firmly against the rotating scraper blade to remove the coconut flesh. Exercise caution to avoid injury.
6. Turn off and unplug the grinder once scraping is complete.



Figure 5: Coconut Scraper attachment in use.

4. Maintenance and Cleaning

4.1 Cleaning After Use

1. Always unplug the grinder before cleaning.
2. Remove the drum, grinding stones, and any attachments.
3. Wash the drum, stones, atta kneader, coconut scraper, and lid with warm water and mild dish soap. Use a brush to remove any stubborn residue.
4. Rinse all parts thoroughly and dry them completely to prevent water spots or corrosion.
5. Wipe the main motor unit with a damp cloth. Do not use abrasive cleaners or immerse the motor unit in water.

4.2 Storage

Store the grinder and its accessories in a clean, dry place away from direct sunlight and extreme temperatures. Ensure all

parts are dry before storage.

5. Troubleshooting

Problem	Possible Cause	Solution
Grinder does not start.	Not plugged in; power switch off; power outage.	Check power cord connection; ensure switch is ON; check circuit breaker.
Motor is noisy or heats up quickly.	Overloading; insufficient water; prolonged operation.	Reduce load; add more water; allow motor to cool down between uses.
Cylinder wobbles during operation.	Drum or stone assembly not seated correctly; uneven surface.	Ensure drum and stone assembly are properly aligned and seated; place grinder on a flat, stable surface.
Grinding is not uniform or takes too long.	Insufficient water; ingredients not pre-soaked; overloading.	Adjust water quantity; ensure ingredients are properly pre-soaked; reduce batch size.

6. Specifications

Brand: Butterfly

Model: Peerless

Capacity: 2-Liters

Voltage: 110V (for USA & Canada)

Body Material: Shock proof ABS body

Drum Material: Easy detachable stainless steel drum

Grinding Stone: Patented 3 conical stones

Lid: Polycarbonate transparent lid

Included Accessories: Atta Kneader, Coconut Scraper

Item Weight: Approximately 13 kg (28.6 lbs)

Dimensions (L x W x H): 17" x 12" x 14"

7. Warranty and Support

7.1 Motor Warranty

This Butterfly Peerless Wet Grinder comes with a**5 Years Motor Warranty** from the date of purchase. This warranty covers manufacturing defects in the motor under normal household use. Please retain your purchase receipt as proof of purchase for warranty claims.

The warranty does not cover damage caused by misuse, neglect, unauthorized repairs, commercial use, or normal wear and tear of non-motor components.

7.2 Customer Support

For any questions, technical assistance, or warranty claims, please contact Butterfly customer support. Refer to the contact information provided with your purchase documentation or visit the official Butterfly website for the most up-to-date support details.

© 2026 Butterfly. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C9GGJ76S

More documents and user manuals: **https://manuals.plus/**