ALLIMITY RC5116

ALLIMITY RC5116 Remote Control User Manual

Replacement Remote Control for QILIVE TVs

Introduction

Thank you for choosing the ALLIMITY RC5116 Replacement Remote Control. This remote is designed to function as a direct replacement for your original QILIVE TV remote, offering full functionality without the need for complex programming. Simply insert batteries, and it's ready to use.
This manual provides instructions on how to set up, operate, and maintain your new remote control, along with troubleshooting tips and product specifications.

Product Overview





Figure 1: ALLIMITY RC5116 Remote Control. This image displays the full layout of the remote control, including power button, number pad, navigation buttons, volume and channel controls, and various function keys.



Figure 2: ALLIMITY RC5116 Remote Control Packaging. This image shows the remote control sealed in its clear plastic packaging from various angles, indicating how the product is typically shipped.

Setup

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch to open it.
3. Insert two AAA alkaline batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover by sliding it back into place until it clicks securely.

Note: This remote control does not require any programming. Once batteries are installed, it is ready for immediate use with compatible QILIVE TV models.

Operating Instructions

The ALLIMITY RC5116 remote control replicates the functions of your original QILIVE TV remote. Point the remote directly at your television's infrared receiver for optimal performance.

Key Functions

- **Power Button (●)**: Turns the TV on or off.
- **Number Buttons (0-9)**: Directly select channels.
- **Volume Up/Down (V+/V-)**: Adjusts the volume level.
- **Channel Up/Down (P+/P-)**: Changes the TV channel.
- **Mute**: Mutes or unmutes the TV sound.
- **Menu**: Accesses the TV's main menu.
- **Navigation Buttons (Up, Down, Left, Right, OK)**: Navigate through menus and confirm selections.
- **Back/Exit**: Returns to the previous screen or exits the current menu.
- **Source/Input**: Selects the input source (HDMI, AV, etc.).
- **Color Buttons (Red, Green, Yellow, Blue)**: Used for specific functions within certain TV menus or applications.

Maintenance

Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Do not use abrasive cleaners, alcohol, or chemical solvents, as these may damage the remote's surface or internal components.

Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA alkaline). Dispose of old batteries responsibly according to local regulations.

Caution: Do not mix old and new batteries, or different types of batteries, as this may cause leakage or explosion.

Troubleshooting

Problem	Possible Cause	Solution
Remote control not working.	Batteries are dead or incorrectly inserted.	Replace batteries with new ones, ensuring correct polarity (+/-).
Remote control has limited range or intermittent response.	Low battery power; Obstruction between remote and TV; Remote not pointed directly at TV sensor.	Replace batteries; Remove any obstructions; Ensure direct line of sight to TV's IR sensor.
Certain buttons do not function.	Button malfunction; TV model incompatibility for specific advanced functions.	Ensure the remote is compatible with your specific TV model. If basic functions also fail, the remote may be faulty.

Specifications

Brand: ALLIMITY

Model: RC5116

Connectivity Technology: Infrared (IR)

Compatible Devices: Televisions (QILIVE models)

Power Source: 2 x AAA Alkaline Batteries (not included)

Special Feature: No Programming Required

Maximum Supported Devices: 18 (This remote is a direct replacement for one TV.)

Compatible QILIVE TV Models

This ALLIMITY RC5116 remote control is compatible with the following QILIVE TV models:

- 32168
- Q.1096
- Q.1475
- Q.1578
- Q.1903
- RC-5116
- Q.1209
- Q.1508
- Q.1638
- L28H275U3
- Q.1008
- Q.1259
- Q.1527
- Q.1649

If your QILIVE TV model is not listed, please verify compatibility with the seller before purchase.

Warranty and Support

For warranty information or technical support, please refer to the seller's policy or contact the seller directly through the platform where the product was purchased. Keep your purchase receipt as proof of purchase.
This product is designed for ease of use and reliability. Should you encounter any issues not covered in this manual, please reach out to customer support for assistance.

© 2023 ALLIMITY. All rights reserved.
Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question