Invicta 44746

Invicta Hydromax Quartz Gold Dial Men's Watch 44746 Instruction Manual

1. Product Overview

The Invicta Hydromax Quartz Gold Dial Men's Watch, Model 44746, is a robust timepiece designed for durability and precision. It features a gold-tone dial with blue hands, housed within a silver-tone and gold stainless steel case. The watch is powered by a reliable quartz movement and offers significant water resistance, making it suitable for various activities.

- **Dial:** Gold-tone, enhanced by blue hands.
- **Case:** Silver-tone and Gold stainless steel, 52 mm x 26.8 mm.
- **Crystal:** Scratch Resistant Mineral.
- **Band:** Silver-tone stainless steel, 24 mm x 8.25 inches long, with a fold over safety clasp.
- **Movement:** Quartz.
- **Water Resistance:** 1000 meters / 3300 feet.
- **Bezel:** Uni-directional Rotating.
- **Crown:** Screw Down.
- **Caseback:** Solid.


INVICTA
28
HYDROMAX
1000 MT - 3300 FT

Figure 1: Front view of the Invicta Hydromax Quartz Gold Dial Men's Watch 44746.

2. Setup and Initial Use

2.1 Setting the Time and Date

1. **Unscrew the Crown:** Locate the screw-down crown on the side of the watch case. Rotate the crown counter-clockwise until it is released from its threaded position.
2. **Pull to Position 1 (Date Setting):** Gently pull the crown out to the first click position. Rotate the crown either clockwise or counter-clockwise (depending on the movement) to set the date. Avoid setting the date between 9:00 PM and 3:00 AM, as this can damage the movement.
3. **Pull to Position 2 (Time Setting):** Pull the crown out further to the second click position. Rotate the crown to set the hour and minute hands. Ensure the AM/PM is correctly set by observing the date change (the date will change at midnight).
4. **Screw Down the Crown:** Once the time and date are set, push the crown back into its normal position. While applying slight pressure, rotate the crown clockwise to screw it back down tightly against the case. This ensures the watch's water resistance.



Figure 2: Close-up view of the screw-down crown.

2.2 Adjusting the Stainless Steel Band

The stainless steel band features a fold over safety clasp. For initial sizing or adjustments, it is recommended to consult a professional jeweler or watch repair service. They can safely add or remove links to ensure a comfortable and secure fit without damaging the band or clasp.



Figure 3: Detail of the watch band and fold over safety clasp.

3. Operating Your Watch

3.1 Water Resistance

Your Invicta Hydromax watch is water resistant to 1000 meters (3300 feet). This high level of water resistance makes it suitable for professional marine activity and serious surface water sports, but not for saturation diving. Always ensure the screw-down crown is fully tightened before exposing the watch to water.

3.2 Uni-directional Rotating Bezel

The watch features a uni-directional rotating bezel. This bezel is typically used by divers to measure elapsed time underwater. To use, align the bezel's zero marker with the minute hand at the start of an activity. The bezel rotates only counter-clockwise to prevent accidental increases in elapsed time, which could be critical for diving safety.

4. Care and Maintenance

4.1 Cleaning

To maintain the appearance of your watch, regularly wipe the case and band with a soft, dry cloth. For stainless steel components, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals or abrasive materials, as these can damage the finish.

4.2 Battery Replacement

This watch is powered by a quartz movement, which requires a nonstandard battery. When the watch stops running, it indicates that the battery needs to be replaced. Battery replacement should be performed by a qualified watch technician to ensure the proper sealing and water resistance of the watch are maintained.

4.3 Crystal Care

The watch is equipped with a scratch-resistant mineral crystal. While durable, it is not entirely impervious to scratches. Avoid contact with abrasive surfaces and store the watch in a protective case when not in use to prevent damage.

5. Troubleshooting

5.1 Watch Not Running

If your quartz watch stops running, the most common cause is a depleted battery. Refer to section 4.2 for battery replacement information. If the watch still does not function after a battery change, it may require professional inspection.

5.2 Condensation Inside the Crystal

The presence of condensation inside the watch crystal may indicate a loss of water resistance. This can occur if the crown was not properly screwed down or if the watch has sustained an impact. Immediately take the watch to a qualified technician for inspection and repair to prevent further damage to the movement.

6. Specifications

Feature	Detail
Item Model Number	44746
Department	Mens
Movement	Quartz
Water Resistance	1000 meters / 3300 feet
Case Size	52 mm x 26.8 mm
Band Width	24 mm
Band Length	8.25 inches
Crystal Type	Scratch Resistant Mineral
Clasp Type	Fold over safety
Crown Type	Screw Down
Bezel Type	Uni-directional Rotating
Batteries	1 Nonstandard Battery (included)

Manufacturer	Invicta

7. Warranty and Support

For detailed warranty information and customer support, please refer to the official Invicta website or the warranty card included with your purchase. Invicta offers various protection plans for their products. For specific inquiries or service requests, contact Invicta customer service directly.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question