Wolmund CS-B-2306

Wolmund Toy Learning Play Cell Phone User Manual

Model: CS-B-2306

1. Introduction

This manual provides instructions for the safe and proper use of your Wolmund Toy Learning Play Cell Phone, Model CS-B-2306. This interactive toy is designed for toddlers and babies, offering various modes to engage and educate through play. Please read this manual thoroughly before use and retain it for future reference.

2. Safety Information

- **Adult Supervision:** Always ensure adult supervision when children are playing with the toy.
- **Choking Hazard:** This toy contains small parts that may pose a choking hazard for young children. Keep away from infants who still put objects in their mouths.
- **Battery Safety:** The toy uses a rechargeable battery. Do not attempt to replace the battery. Use only the provided USB cable for charging. Do not expose the toy to extreme temperatures or open flames.
- **Cleaning:** Clean the toy with a soft, damp cloth. Do not immerse in water.
- **Damage:** If the toy becomes damaged, discontinue use immediately to prevent injury.



The toy features a round and smooth design for safe handling by children. The image shows a baby holding the toy phone while sitting with an adult, highlighting its child-friendly construction.

3. Package Contents

The package includes the following items:

- 1 x Wolmund Toy Learning Play Cell Phone (Model CS-B-2306)
- 1 x USB Charging Cable

4. Setup

4.1 Charging the Toy Phone

Before first use, fully charge the toy phone. A full charge provides approximately 8 hours of play time.

1. Locate the charging port on the side of the toy phone.

2. Connect the small end of the provided USB charging cable to the toy phone's charging port.
3. Connect the larger end of the USB cable to a standard USB power adapter (not included) or a computer's USB port.
4. The toy phone will indicate charging status (e.g., a light indicator).
5. Once fully charged, disconnect the USB cable.



This image illustrates the location of the charging port and the power switch button on the side of the toy phone. A USB cable is shown connected to the charging port.

4.2 Powering On/Off

To power on the toy phone, slide the switch button located next to the charging port. To power off, slide the switch button back to its original position.

5. Operating Instructions

The Wolmund Toy Learning Play Cell Phone features 8 interactive modes, accessible via the touch screen. Each mode offers unique sounds, lights, and learning activities.



This diagram visually represents the 8 distinct play modes available on the toy phone: Mobile, Piano, Color, Fruit, Drum, Game, Maths, and Question Mode.

5.1 Mode Selection

To switch between the 8 modes, locate the 'Mode Switch' button on the screen (often represented by a gear or settings icon). Tap this button to cycle through the available modes.

5.2 Interactive Functions by Mode

Each mode utilizes the 0-9 number buttons and a special 'Question' or 'Music' button for different interactive experiences.

Function Introduction by Mode

Mode	0-9 Button Function	Question or Music Button Function
Mobile Mode	10 Dial Sound Effects	3 Mobile Ringtones
Piano Mode	10 Piano Pieces	Switch Piano Piece

Mode	0-9 Button Function	Question or Music Button Function
Color Mode	10 Color Words	Question Mode
Fruit Mode	10 Fruit Words	Question Mode
Drum Mode	10 Drum Sound Effects	1 Drum Piece
Game Mode	10 Game Sound Effects	5 Songs
Math Mode	10 Number Words	Question Mode



The toy phone features dazzling LED lights that illuminate the edges in various colors, enhancing the visual experience for children. The image shows the phone glowing with red and blue lights.

5.3 Volume Adjustment

The toy phone includes adjustable volume settings. Refer to the on-screen interface or dedicated buttons (if present) to increase

or decrease the sound level to a comfortable listening volume.

6. Maintenance

6.1 Cleaning

To clean the toy phone, use a soft, slightly damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure the charging port is dry before charging.

6.2 Storage

Store the toy phone in a cool, dry place away from direct sunlight and extreme temperatures when not in use. Keep it out of reach of pets and very young children to prevent accidental damage.

7. Troubleshooting

- **Toy does not turn on:** Ensure the toy is fully charged. Check the power switch to confirm it is in the 'On' position.
- **No sound:** Check the volume setting. Ensure it is not set to the lowest level or muted.
- **Lights not working:** Ensure the toy is powered on and fully charged. If lights are still not functioning, contact customer support.
- **Unresponsive screen:** Power off the toy, then power it back on. If the issue persists, ensure the screen is clean and free of debris.

8. Specifications

Feature	Detail
Model Number	CS-B-2306
Dimensions (L x W x H)	4.9 x 2.3 x 0.3 inches (12.4 x 5.8 x 0.8 cm)
Weight	1.4 oz (40 g)
Material	ABS Plastic
Color	Black
Power Source	Rechargeable Battery (USB charging)
Play Modes	8 (Mobile, Piano, Color, Fruit, Drum, Game, Maths, Question)
Recommended Age	Toddler (up to 36 months)
Educational Objective	Logical Thinking

9. Warranty and Support

For warranty information or customer support, please refer to the contact details provided with your purchase or visit the official Wolmund website. Keep your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question