REWARD RD81100M

REWARD Men's Quartz Chronograph Watch RD81100M Instruction Manual

Model: **RD81100M** | Brand: **REWARD**

Introduction Setup Operation Maintenance Warranty & Support Troubleshooting Specifications

1. Introduction

Thank you for choosing the REWARD Men's Quartz Chronograph Watch, model RD81100M. This timepiece combines a classic big square face design with practical chronograph functions and a date display. Crafted with a durable stainless steel band and case, and featuring 3ATM water resistance, this watch is designed for everyday business and fashion wear. Please read this manual carefully to understand how to properly set up, operate, and maintain your watch.



Image 1.1: The REWARD Men's Quartz Chronograph Watch RD81100M, showcasing its design.

2. Initial Setup

2.1 Setting the Time

1. Pull the crown (middle button on the right side) out to position 2.
2. Turn the crown to adjust the hour and minute hands to the correct time.
3. Push the crown back to position 0 to start the watch.

2.2 Setting the Date

1. Pull the crown out to position 1.
2. Turn the crown clockwise or counter-clockwise (depending on the movement) to set the correct date.
3. Once the date is set, push the crown back to position 0.

Note: *Avoid setting the date between 9 PM and 3 AM, as this may interfere with the automatic date change mechanism.*

2.3 Adjusting the Band

The watch comes with an interlaced stainless steel band. If the band is too loose or too tight, it can be adjusted by removing or adding links. A band adjusting tool is typically included with your watch for this purpose. If you are unsure, it is recommended to seek professional assistance for band adjustment to prevent damage.



Image 2.1: Illustration of watch controls for time and date adjustment. The top button is for Start/Pause, the middle crown adjusts the calendar and time, and the bottom button is for Restart.

3. Operating the Chronograph

Your REWARD watch features a chronograph function for measuring elapsed time. The watch face includes three sub-dials: a 1/10 seconds dial, a minute dial, and a seconds dial.



Image 3.1: Detailed features of the watch, highlighting the luminous hands for visibility in low light, the gold embossed REWARD logo, the interlaced steel band, and the oversized square case design.

3.1 Chronograph Functions

- **Start/Pause:** Press the top button (A) to start the chronograph. Press it again to pause.
- **Reset:** While the chronograph is paused, press the bottom button (B) to reset all chronograph hands to zero.

The sub-dials will display the elapsed time: the 1/10 seconds dial measures fractions of a second, the minute dial tracks elapsed minutes, and the seconds dial tracks elapsed seconds.

Your browser does not support the video tag.

Video 3.1: Official product video demonstrating the REWARD Square Face Fashion Men's Watch RD81100M, highlighting its design and features.

4. Maintenance

4.1 Water Resistance (3ATM)

Your REWARD watch is rated for 3ATM (30 meters) water resistance. This means it is suitable for daily use and can withstand splashes, rain, and brief immersion in water, such as during hand washing or light rain. It is **not** suitable for showering, swimming, diving, or any activities involving prolonged water exposure or high-pressure water.



Image 4.1: Water resistance guidelines for the watch, indicating it is suitable for everyday activities like hand washing and exposure to rain.

4.2 Cleaning Your Watch

To maintain the appearance of your watch, wipe it regularly with a soft, dry cloth. For the stainless steel band, a slightly damp cloth can be used, followed by a dry cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the watch's finish.

4.3 Battery Replacement

The watch is powered by a quartz movement, which requires a battery. When the watch stops running, the battery may need to be replaced. It is recommended to have the battery replaced by a qualified watch technician to ensure the water resistance seal is properly maintained.

5. Troubleshooting

- **Watch not running:** Check if the crown is fully pushed in (position 0). If it is, the battery may need replacement.
- **Time is incorrect:** Follow the steps in Section 2.1 to reset the time. Ensure the crown is fully pushed in after setting.
- **Date is incorrect:** Follow the steps in Section 2.2 to reset the date. Avoid setting the date between 9 PM and 3 AM.
- **Chronograph hands not resetting to zero:** If the chronograph hands do not reset to the 12 o'clock position, consult a watch technician for adjustment.
- **Condensation inside the watch:** This may indicate a breach in the water resistance. Avoid further water exposure and seek professional repair immediately.

6. Specifications

Feature	Detail
Model Number	RD81100M
Movement	Quartz
Case Material	Alloy
Band Material	Stainless Steel
Water Resistance	3ATM (30 meters)
Crystal Material	Mineral glass
Plating	Environmental Vacuum Plating
Case Size	40 x 47 mm
Case Thickness	14 mm
Band Length	240 mm
Band Width	26 x 20 mm
Watch Weight	130 g
Clasp Type	Foldover Clasp With Push Button



Image 6.1: Visual representation of the watch's key dimensions and weight.

7. Warranty & Support

For warranty information, product support, or service inquiries, please refer to the warranty card included with your purchase or contact REWARD customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question