JAMFLY 28-Inch Propane Fire Pit Table

JAMFLY 28-Inch 50,000 BTU Propane Fire Pit Table

Instruction Manual

Safety Information | Setup | Operation | Maintenance | Troubleshooting | Specifications | Warranty & Support

1. Safety Information

WARNING: Failure to follow these instructions could result in fire, explosion, or carbon monoxide poisoning, which could cause property damage, personal injury, or death.

- Always maintain a safe distance from combustible materials.
- Use only approved fuel types (Liquefied Petroleum Gas) and ensure proper ventilation.
- Follow all local regulations for fire pit usage.
- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- Never leave the fire pit unattended while in operation.
- Keep children and pets away from the fire pit.
- Ensure the fire pit is on a level, non-combustible surface.
- Do not use the fire pit in an enclosed space.

2. Setup

2.1 Unpacking and Assembly

Carefully remove all components from the packaging. Inspect for any damage. Assembly is required. Refer to the included assembly guide for detailed step-by-step instructions. Ensure all bolts and connections are securely tightened before use.

2.2 Propane Tank Installation

The JAMFLY fire pit table is designed to conceal a standard propane tank within its base. Open the access door on the side of the fire pit table. Place the propane tank inside the designated compartment. Connect the gas hose from the fire pit to the propane tank valve, ensuring a tight seal. Close the access door.



Figure 2.2.1: The propane tank is stored securely within the fire pit table's base, accessible via a side door.

2.3 Lava Rock Placement

Distribute the provided lava rocks evenly over the burner area. Ensure that the igniter and burner holes are not completely covered to allow for proper ignition and flame distribution.



Figure 2.3.1: Lava rocks distributed in the fire pit burner area.

3. Operation

3.1 Lighting Instructions

1. Ensure the propane tank valve is fully open.
2. Locate the control knob on the side of the fire pit table.
3. Push the control knob in and turn it counter-clockwise to the "LOW" position.
4. While holding the knob in, press the igniter button repeatedly until the burner ignites.
5. Once ignited, continue to hold the control knob in for 10-15 seconds to allow the thermocouple to heat up. Release the knob. If the flame extinguishes, repeat the process.
6. Adjust the flame height by turning the control knob between "LOW" and "HIGH" settings.

3.2 Shutting Down

To turn off the fire pit, turn the control knob clockwise to the "OFF" position. Close the valve on the propane tank when the fire pit is not in use.

3.3 Multi-purpose Use

When not in use as a fire pit, the included lid can be placed over the burner area, transforming the unit into a functional outdoor dining table, coffee table, or bar table.



Figure 3.3.1: The fire pit table can be used as a fire pit or a table with the lid in place.

4. Maintenance

4.1 Cleaning

Allow the fire pit to cool completely before cleaning. Wipe exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or harsh chemicals. Periodically check the burner and igniter for debris and clean as necessary.

4.2 Storage and Protection

When the fire pit is not in use, especially during inclement weather or off-season, cover it with the provided waterproof cover to protect it from the elements and extend its lifespan.



Figure 4.2.1: The fire pit table protected by its waterproof cover.

5. Troubleshooting

Problem	Possible Cause	Solution
Burner does not ignite.	Propane tank valve closed. Low propane level. Igniter not sparking. Air in gas line.	Ensure propane tank valve is fully open. Check propane tank level; replace if empty. Check igniter electrode for proper gap and cleanliness. Purge air from the gas line by repeating ignition steps several times.

Problem	Possible Cause	Solution
Low flame or inconsistent flame.	Low propane level. Gas line kinked or obstructed. Burner ports clogged.	Check propane tank level; replace if empty. Inspect gas hose for kinks or damage. Clean burner ports with a soft brush.
Fire pit produces smoke.	Debris in burner. Improper fuel type.	Clean burner and lava rocks. Ensure only Liquefied Petroleum Gas (LP) is used.

6. Specifications

- **Model:** 28-Inch Propane Fire Pit Table
- **Brand:** JAMFLY
- **Material:** Alloy Steel
- **Product Dimensions:** 28"D x 28"W x 25"H
- **Fuel Type:** Liquefied Petroleum Gas (LP)
- **Heat Output:** 50,000 BTU
- **Color:** Black
- **Included Accessories:** Lava Rocks, Lid, Waterproof Cover



Figure 6.1.1: Product dimensions and included accessories.

7. Warranty & Support

For any questions regarding product quality, assembly, or other concerns, please feel free to contact JAMFLY customer service. We are committed to responding to your inquiries within 24 hours.
Please refer to your purchase documentation for specific warranty details and contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question