Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

REWARD RD81100M

REWARD RD81100M Quartz Chronograph Watch User Manual

Model: RD81100M

Introduction Components Setup Operating Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

This manual provides instructions for the REWARD RD81100M Quartz Chronograph Watch. Please read this manual carefully to ensure proper use and maintenance of your watch. This watch features a precise quartz movement, chronograph functions, luminous hands for visibility in low light, and water resistance suitable for daily use.



Image 1.1: Front view of the REWARD RD81100M Quartz Chronograph Watch.

2. Watch Components

Familiarize yourself with the various parts of your REWARD RD81100M watch:



Image 2.1: Detailed features of the watch, highlighting the luminous hands, embossed logo, interlaced steel band, and oversized square case.

- **Crown:** Used for setting time and date.
- **Pushers:** Buttons for operating the chronograph functions.
- **Hour, Minute, Second Hands:** Indicate the current time.
- **Sub-dials:** Display chronograph measurements (1/10 seconds, minutes, seconds).
- **Date Window:** Displays the current date.
- **Luminous Markings:** Glow in the dark for visibility.
- **Case:** The main body of the watch, made of copper.
- **Band:** Stainless steel bracelet for wearing the watch.
- **Clasp:** Foldover clasp with push button for secure fastening.

3. Setup

3.1 Setting the Time and Date

1. Pull the crown out to position 2 (first click) to set the date. Turn the crown clockwise or counter-clockwise until the desired date is displayed.
2. Pull the crown out to position 3 (second click) to set the time. Turn the crown to move the hour and minute hands to the correct time. Ensure the AM/PM is correctly set if the watch has a 24-hour indicator or if you observe the date change at midnight.
3. Once the time and date are set, push the crown back into position 1 (normal position) to start the watch.

3.2 Adjusting the Watch Band

The stainless steel band can be adjusted by removing or adding links. A band adjustment tool is typically included with the watch for this purpose. If you are unsure, it is recommended to have a professional jeweler adjust the band to prevent damage.



Image 3.1: Example of a watch box and a band link removal tool.

4. Operating Instructions

4.1 Basic Timekeeping

Your REWARD RD81100M watch continuously displays the current time (hours, minutes, seconds) and date once set correctly.

4.2 Chronograph Function

The chronograph allows you to measure elapsed time. Refer to the diagram below for button identification:



Image 4.1: Watch controls diagram, indicating the functions of the crown and pushers.

1. **Start/Pause:** Press the top pusher (often labeled '1' or 'A') to start the chronograph. Press it again to pause the timing.
2. **Resume:** To continue timing after a pause, press the top pusher again.
3. **Reset:** While the chronograph is stopped (paused), press the bottom pusher (often labeled '2' or 'B') to reset all chronograph hands to their zero positions.

4.3 Luminous Hands

The watch hands and hour markers are treated with a luminous material. After exposure to light, they will glow in the dark, providing visibility in low-light conditions. The intensity and duration of the glow depend on the exposure time and intensity of light.

Video 4.1: Official product video demonstrating the REWARD Square Face Fashion Men's Watch RD81100M, including its design and luminous features.

5. Maintenance

5.1 Cleaning

To maintain the appearance of your watch, wipe the case and band regularly with a soft, dry cloth. For stainless steel bands, a slightly damp cloth can be used, followed by a dry cloth. Avoid using harsh chemicals or abrasive materials.

5.2 Water Resistance

This watch is water resistant to 30 meters (3ATM). This means it is suitable for daily use, such as splashes, rain, and hand washing. It is **not** suitable for showering, swimming, diving, or any activities involving prolonged water immersion or high-pressure water exposure.



Image 5.1: Illustration of the watch's 30-meter water resistance, suitable for everyday splashes.

Always ensure the crown is fully pushed in before any contact with water.

5.3 Battery Replacement

The watch is powered by a quartz battery. When the watch stops or the second hand moves erratically, the battery may need replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and maintain water resistance.

5.4 Storage

When not wearing your watch, store it in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields. The original watch box can be used for storage.

6. Troubleshooting

If you encounter any issues with your watch, please refer to the following common problems and solutions:

- **Watch is not running:**
  Possible Cause: The crown is pulled out, or the battery is depleted.
  Solution: Push the crown fully back into position 1. If the watch still does not run, the battery may need replacement.
- **Time is incorrect:**
  Possible Cause: The time was not set correctly, or the crown was accidentally pulled out.
  Solution: Reset the time according to the instructions in Section 3.1. Ensure the crown is fully pushed in.
- **Chronograph hands do not reset to zero:**
  Possible Cause: The chronograph may need calibration.
  Solution: Consult a professional watch repair service for calibration.
- **Date changes at noon instead of midnight:**
  Possible Cause: The time was set incorrectly for AM/PM.
  Solution: Advance the time by 12 hours.

For issues not covered here, please contact customer support.

7. Specifications

Key technical specifications for the REWARD RD81100M Quartz Chronograph Watch:



Image 7.1: Features of the mineral glass, highlighting its durability and clarity.

Feature	Detail
Brand	REWARD
Model Number	RD81100M
Movement Type	Quartz
Display Type	Analog
Case Material	Copper
Band Material	Stainless Steel
Crystal Type	Hardlex
Case Diameter	40 Millimeters

Case Thickness	10 Millimeters
Band Width	26 Millimeters
Band Length	240 Millimeters
Water Resistance Depth	30 Meters (3ATM)
Clasp Type	Foldover Clasp With Push Button
Additional Features	Chronograph, Second Hand, Timer, Luminous, Stop-watch
Power Source	Battery Powered
Product Dimensions	5.91 x 2.36 x 1.18 inches
Item Weight	0.18 Kilograms (6.38 ounces)

8. Warranty & Support

8.1 Warranty Information

For specific warranty details regarding your REWARD RD81100M watch, please refer to the documentation included with your purchase or contact the REWARD Watch Store directly. Warranty terms typically cover manufacturing defects.

8.2 Returns and Replacements

This product is eligible for a 30-day refund or replacement policy from the date of purchase. Please refer to your retailer's return policy for detailed instructions.

8.3 Customer Support

For further assistance, technical support, or inquiries, please contact the REWARD Watch Store. You can typically find their contact information on the product packaging or through the retailer where the watch was purchased.

© 2023 REWARD. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C9MJV5HV

More documents and user manuals: **https://manuals.plus/**