Nokia Nokia 2660 Flip (TA-1469 / HP03324)

Nokia 2660 Flip User Manual

Model: TA-1469 / HP03324

1. Introduction

This manual provides essential information for the safe and efficient use of your Nokia 2660 Flip mobile phone. Please read this manual carefully before using the device.
The Nokia 2660 Flip is a classic clamshell mobile phone designed for ease of use, featuring a large display, big buttons, and long battery life. It supports 4G connectivity for clear calls and basic internet functions.

2. What's in the Box

- Nokia 2660 Flip Phone
- Removable Battery
- USB Cable
- User Guide (this manual)

3. Device Overview



Figure 3.1: Nokia 2660 Flip (Open View)

This image displays the Nokia 2660 Flip phone in its open position, highlighting both the main internal display and the smaller external display. The internal screen shows the date, time, and network operator status, while the external screen provides a quick glance at the time and date when the phone is closed.



Figure 3.2: Nokia 2660 Flip (Closed Front View)

This image shows the Nokia 2660 Flip phone in its closed state, viewed from the front. The external display is prominent, showing the current time and date. Above the screen, the rear camera lens and its accompanying flash are clearly visible, along with the Nokia branding below the screen.



Figure 3.3: Nokia 2660 Flip (Closed Back View)

This image presents the Nokia 2660 Flip phone from its rear side when closed. The back panel is a solid lush green color, featuring the Nokia logo vertically centered. This view emphasizes the phone's compact and sleek design when folded.

Key Components:

- **Main Display:** Internal screen for navigation, calls, and messages.
- **External Display:** Shows time, date, and notifications when closed.
- **Keypad:** Large, easy-to-use buttons for dialing and text input.
- **Navigation Key:** Central button for menu navigation.
- **Camera:** Rear-facing camera for photos.
- **Speaker:** For call audio and ringtones.
- **Microphone:** For voice input during calls.
- **Charging Port:** USB port for charging the device.
- **3.5mm Audio Jack:** For connecting headphones.

4. Setup

4.1. Installing the Battery and SIM Card

1. **Remove the back cover:** Gently pry open the back cover from the notch located at the bottom edge of the phone.
2. **Insert the SIM card(s):** Locate the SIM card slot(s). Insert the SIM card(s) with the gold contacts facing down and the cut corner aligned as shown in the diagram (refer to device for specific orientation). The Nokia 2660 Flip supports Dual SIM (DS).
3. **Insert the microSD card (optional):** If using an external memory card, insert it into the dedicated microSD card slot.

4. **Insert the battery:** Align the battery contacts with the phone's contacts and gently press the battery into place.
5. **Replace the back cover:** Press the back cover firmly until it clicks into place.

4.2. Charging the Battery

Before first use, fully charge the battery. Use only Nokia-approved chargers and cables.

1. Connect the USB cable to the phone's charging port.
2. Connect the other end of the USB cable to a power adapter and plug it into a wall outlet.
3. The battery indicator on the screen will show charging progress.
4. Once fully charged, disconnect the charger.

5. Operating the Device

5.1. Powering On/Off

- **To Power On:** Open the flip and press and hold the Power/End Call key until the phone vibrates and the screen lights up.
- **To Power Off:** Press and hold the Power/End Call key, then select "Power off" from the options.

5.2. Making and Receiving Calls

- **Making a Call:** Enter the phone number using the keypad and press the Call key (green button).
- **Answering a Call:** Open the flip or press the Call key when the phone rings.
- **Ending a Call:** Close the flip or press the End Call key (red button).

5.3. Sending and Receiving Messages

- Navigate to *Menu* > *Messages* > *Create message*.
- Type your message using the keypad.
- Enter the recipient's number or select from contacts.
- Press *Send*.

5.4. Camera Functions

The Nokia 2660 Flip features a basic camera for capturing moments.

- Navigate to *Menu* > *Camera*.
- Frame your shot using the display.
- Press the central navigation key to take a photo.
- Photos are saved to the Gallery.

5.5. Radio and Music Playback

The device supports FM radio and MP3 playback.

- **FM Radio:** Connect headphones (acting as antenna) and navigate to *Menu* > *Radio*.
- **Music Player:** Transfer MP3 files to a microSD card (if installed) or phone memory. Navigate to *Menu* > *Music* to play.

6. Maintenance and Care

- **Cleaning:** Use a soft, dry cloth to clean the phone's surface. Avoid liquid cleaners.
- **Battery Care:** Do not expose the battery to extreme temperatures. Do not puncture or disassemble the battery.
- **Storage:** Store the phone in a cool, dry place away from direct sunlight and moisture.
- **Avoid Drops:** Protect the phone from physical shocks and drops.

7. Troubleshooting

Problem	Possible Cause	Solution
Phone does not power on	Low battery; Battery not inserted correctly	Charge the battery; Re-insert battery correctly
Cannot make/receive calls	No network signal; SIM card not inserted or faulty	Move to an area with better signal; Check SIM card insertion; Contact your network provider
Poor audio quality during calls	Weak signal; Speaker/microphone obstruction	Move to an area with better signal; Ensure speaker/microphone are not covered
Battery drains quickly	Excessive usage; Old battery	Reduce screen brightness; Close unused applications; Consider replacing battery if old

8. Specifications

- **Model:** Nokia 2660 Flip (TA-1469 / HP03324)
- **Dimensions:** 7.44 x 2.17 x 0.74 inches (folded)
- **Weight:** 4.3 ounces (123 Grams)
- **Operating System:** S30+
- **Main Display Size:** 2.8 Inches
- **Main Display Resolution:** 320 x 240 pixels
- **Connectivity:** 4G LTE, Bluetooth, Wi-Fi
- **Audio Jack:** 3.5 mm
- **Battery:** 1450 mAh (Removable)
- **Talk Time:** Up to 6 Hours
- **Storage:** Expandable via microSD (not specified max, but common for S30+ phones)
- **Camera:** Yes (resolution not specified, but typically low for feature phones)

9. Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Nokia support website. Keep your proof of purchase for warranty claims.
Online Support: www.nokia.com/phones/en_us/support

© 2025 Nokia. All rights reserved.