ALLIMITY QYSY-ZH-LT-01

ALLIMITY Remote Control User Manual

For Akai Chigo AC Air Conditioners (Models: AK-9000-RC, AK-12000-RC, AK-18000-RC, ZHF/LT-01)

Introduction

This manual provides detailed instructions for the ALLIMITY replacement remote control, designed for use with specific Akai and Chigo air conditioner models. Please read this manual thoroughly before using the remote control to ensure proper operation and longevity.





Image 1: Front view of the ALLIMITY remote control. This image displays the remote control's front face, showing the LCD screen, power button, temperature adjustment buttons, and various function buttons such as MODE, SWING, AIR FLOW, FAN SPEED, TIMER, SLEEP, TURBO, HOLD, and LAMP.

Setup

1. Battery Installation

The remote control requires two AAA alkaline batteries (not included). Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover downwards to open it.
3. Insert two new AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Slide the battery cover back into place until it clicks securely.





Image 2: Back view of the ALLIMITY remote control. This image shows the rear of the remote control, highlighting the battery compartment cover, which needs to be opened for battery insertion.

2. Initial Use

This remote control is pre-programmed and does not require any additional setup or pairing. Once batteries are installed, it is ready for immediate use with compatible Akai and Chigo air conditioner models.

Operating Instructions

Point the remote control directly at the air conditioner's receiver. The maximum effective range is approximately 10 meters (33 feet). Ensure there are no obstructions between the remote and the air conditioner.

Button Functions:

- **ON/OFF:** Powers the air conditioner on or off.
- **Temperature Up/Down (▲ / ▼):** Adjusts the desired temperature setting.
- **MODE:** Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **SWING:** Activates or adjusts the louver swing function.
- **AIR FLOW:** Adjusts the direction or intensity of the airflow.
- **FAN SPEED:** Changes the fan speed (e.g., Low, Medium, High, Auto).
- **TIMER:** Sets a timer for the air conditioner to turn on or off.
- **SLEEP:** Activates the sleep mode for comfortable nighttime operation.
- **TURBO:** Engages maximum cooling or heating for rapid temperature change.
- **HOLD:** May pause or hold current settings (functionality may vary by AC model).
- **LAMP:** Controls the display light on the air conditioner unit.
- **RST (Reset):** Resets the remote control to default settings. Use a pointed object to press this button if needed.

Maintenance

Battery Replacement:

Replace batteries when the remote control's performance diminishes or the display becomes dim. Always replace both batteries simultaneously with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning:

To clean the remote control, wipe it gently with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or

chemical solvents, as these can damage the remote's surface or internal components.

Storage:

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage.

Troubleshooting

- **Remote control not working:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new AAA alkaline batteries.
  - Ensure there are no obstructions between the remote control and the air conditioner's receiver.
  - Make sure you are within the effective operating range (approximately 10 meters).
- **Air conditioner not responding to specific buttons:**
  - Some functions may not be supported by all compatible air conditioner models. Refer to your air conditioner's original manual for specific feature compatibility.
  - Try pressing the RST button on the remote control (using a pointed object) to reset it.

Specifications

Brand	ALLIMITY
Model Number	QYSY-ZH-LT-01
Compatible Devices	Akai Chigo AC Air Conditioners (AK-9000-RC, AK-12000-RC, AK-18000-RC, ZHF/LT-01, ZHF-LT-01)
Connectivity Technology	Infrared
Maximum Range	10 meters (33 feet)
Battery Type	AAA Alkaline (2 required, not included)
Product Dimensions	4 x 12 x 0.3 cm (approximately 1.6 x 4.7 x 0.1 inches)
Item Weight	50 grams (approximately 1.8 ounces)
Number of Buttons	10 (excluding temperature up/down)

Warranty Information

Specific warranty details for this product are not provided in the available information. For warranty-related inquiries, please contact the seller directly through your purchase platform.

Customer Support

If you encounter any issues or have questions regarding the ALLIMITY remote control, please refer to the troubleshooting section first. If the problem persists, contact the seller, CNGSPOOJIANGQ, via the platform where

you purchased the product for assistance.

© 2023 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question