Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Grunkel FRYEROVEN

Grunkel 12L Digital Airfryer Oven Instruction Manual

Model: FRYEROVEN

1. Introduction

This manual provides essential information for the safe and efficient operation of your Grunkel 12L Digital Airfryer Oven, Model FRYEROVEN. Please read these instructions carefully before first use and retain them for future reference.



Figure 1.1: Grunkel 12L Digital Airfryer Oven. This image shows the appliance from an angled front view, highlighting its sleek black design, digital control panel, and transparent viewing window.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury.

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance body in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been

damaged in any manner.

- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface, away from walls or other appliances to allow for proper ventilation.

3. Product Components and Features

The Grunkel 12L Digital Airfryer Oven is designed for versatile cooking with its 12-liter capacity and digital controls.

- **Digital Control Panel:** Intuitive interface for selecting programs, adjusting temperature, and setting the timer.
- **Viewing Window:** A transparent, illuminated window allows monitoring of the cooking process without opening the door.
- **12 Preset Programs:** Optimized settings for various dishes.
- **Adjustable Timer:** Up to 60 minutes for precise cooking control.
- **Temperature Control:** Allows precise temperature adjustments for different recipes.
- **Removable Components:** Designed for easy cleaning.



Figure 3.1: Key features of the Grunkel Airfryer Oven. This image illustrates the large viewing window, the timer function, and the internal lighting (referred to as "explosion-proof lamps" in the original description, which is likely a mistranslation for durable/safe internal lighting).

4. Setup and First Use

1. **Unpacking:** Carefully remove the airfryer oven and all accessories from the packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, wipe the exterior of the appliance with a damp cloth. Wash all removable accessories (e.g., racks, drip tray) in warm, soapy water, rinse thoroughly, and dry completely.
3. **Placement:** Place the airfryer oven on a stable, level, and heat-resistant surface. Ensure there is adequate space (at least 10-15 cm) around the appliance for proper air circulation. Do not place it directly against a wall or under cabinets.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet. Ensure the voltage matches the specifications of your appliance.
5. **Initial Burn-off (Optional but Recommended):** For the first use, it is recommended to run the airfryer empty for

about 10-15 minutes at 180°C (350°F) to eliminate any manufacturing odors. A slight smell or smoke may occur, which is normal. Ensure good ventilation during this process.

5. Operating Instructions

5.1. Digital Control Panel Overview

The digital control panel allows you to easily select cooking functions, adjust time and temperature, and start/stop the cooking process.

5.2. Basic Operation

1. **Prepare Food:** Place your food on the appropriate accessory (e.g., rack, basket) and insert it into the airfryer oven.
2. **Power On:** Press the power button () to turn on the appliance. The display will illuminate.
3. **Select Program:** Choose one of the 12 preset cooking programs by pressing the program selection button (often represented by an 'M' or menu icon) and cycling through the options. Each program has a default time and temperature.
4. **Adjust Time/Temperature (Optional):** If desired, you can manually adjust the cooking time and temperature using the dedicated +/- buttons. The timer can be set up to 60 minutes.
5. **Start Cooking:** Press the start/pause button (often represented by a play/pause icon) to begin the cooking process.
6. **Monitor Progress:** Use the illuminated viewing window to monitor your food without opening the door.
7. **Finish Cooking:** The airfryer will beep when the cooking cycle is complete. Carefully remove the food using heat-resistant gloves.
8. **Power Off:** Press the power button () to turn off the appliance. Unplug when not in use.

5.3. Cooking Guidelines

The following table provides general guidelines for various food items. Actual cooking times and temperatures may vary based on food quantity, size, and desired crispness.



Figure 5.1: Example cooking parameters. This image displays suggested cooking times and temperatures for items such as steak (10 min, 200°C), bacon (12 min, 180°C), mixed vegetables (15 min, 180°C), cake (20 min, 160°C), fried chicken (25 min, 200°C), and french fries (20 min, 180°C).

Table 5.1: General Cooking Guidelines

Food Item	Temperature	Time	Notes
Steak	200°C (390°F)	10 min	Adjust for desired doneness.
Bacon	180°C (355°F)	12 min	Flip halfway through.
Mixed Vegetables	180°C (355°F)	15 min	Toss halfway through.
Cake	160°C (320°F)	20 min	Use appropriate bakeware.
Fried Chicken	200°C (390°F)	25 min	Ensure internal temperature is safe.
French Fries	180°C (355°F)	20 min	Shake basket halfway through.

6. Cleaning and Maintenance

Regular cleaning and maintenance will ensure the longevity and optimal performance of your Grunkel Airfryer Oven.

1. **Before Cleaning:** Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.
2. **Exterior:** Wipe the exterior of the airfryer oven with a damp cloth. Do not use abrasive cleaners or scouring pads, as they may damage the surface.
3. **Interior:** Wipe the interior walls with a damp cloth and mild detergent. For stubborn food residue, a non-abrasive sponge can be used. Ensure the interior is dry before next use.
4. **Removable Accessories:** Wash racks, drip trays, and other removable accessories in warm, soapy water. They may also be dishwasher safe (refer to specific accessory instructions if provided). Rinse thoroughly and dry completely.
5. **Heating Element:** Gently clean the heating element with a soft brush to remove any food particles. Do not use water or liquid cleaners directly on the heating element.
6. **Storage:** Store the cleaned and dried airfryer oven in a cool, dry place.

7. Troubleshooting

If you encounter any issues with your Grunkel Airfryer Oven, refer to the following common problems and solutions.

Table 7.1: Troubleshooting Guide

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; appliance fault.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker. If the issue persists, contact customer support.
Food is not cooked evenly.	Overcrowding; incorrect temperature/time; food not shaken/flipped.	Do not overcrowd the cooking area. Ensure food is arranged in a single layer. Adjust temperature and time as needed. Shake or flip food halfway through cooking.
White smoke coming from the appliance.	Grease/oil residue; fatty food cooking.	Clean the appliance thoroughly, especially the drip tray and heating element. For fatty foods, ensure excess fat is drained. This is usually harmless.
Food is not crispy.	Too much moisture; not enough oil (for certain foods); low temperature.	Pat food dry before cooking. Lightly brush or spray with oil if desired. Increase temperature or cooking time slightly.

8. Technical Specifications

- **Brand:** Grunkel
- **Model Number:** FRYEROVEN
- **Color:** Black
- **Product Dimensions:** 37.2 x 31 x 35.8 cm (Depth x Width x Height)
- **Weight:** 6.45 kg
- **Capacity:** 12 Liters
- **Power/Wattage:** 1500 Watts
- **Material:** Plastic exterior, non-stick interior

- **Timer:** Up to 60 minutes
- **Special Features:** 12 cooking programs, internal viewing window, temperature control.



Figure 8.1: Grunkel Airfryer Oven dimensions. This image shows the appliance with its width (31cm), depth (37.2cm), and height (35.8cm) clearly indicated.

9. Warranty and Support

Grunkel products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official Grunkel website.

If you require technical assistance, have questions about operation, or need to report a fault, please contact Grunkel customer support. Contact details can typically be found on the product packaging, the official Grunkel website, or your purchase documentation.

Please have your model number (FRYEROVEN) and proof of purchase ready when contacting support.

© 2024 Grunkel. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CB88WJ7G

More documents and user manuals: **https://manuals.plus/**