Coleman 2000020276

Coleman Pack-Away Portable Camp Kitchen

User Manual

Product Overview

The Coleman Pack-Away Portable Camp Kitchen is designed to provide a convenient and stable cooking and food preparation area for outdoor activities such as camping, tailgating, and backyard barbecues. Its innovative folding design allows for compact storage and easy transport.

- Features a spacious 31.5 x 21.3-inch food prep area.
- Includes a 27.8 x 20.5-inch side table, compatible with most Coleman stoves and coolers.
- Equipped with handy utensil hooks and a mesh shelf for additional storage.
- Folds into a compact case for effortless carrying and storage.
- Offers a stable cooking surface and ample storage space for your outdoor culinary needs.



Figure 1: The Coleman Pack-Away Portable Camp Kitchen in its fully assembled state, ready for use.

Safety Information

Always ensure the table is stable and properly assembled before use. Keep heavy items away from the edges to prevent tipping. Do not leave the table unattended while in use.

Setup Instructions

Setting up your Coleman Pack-Away Portable Camp Kitchen is a straightforward process designed for quick deployment.

1. **Unfold the Main Table:** Begin by unlatching the main table unit. Gently unfold the table, extending its legs until they are fully locked into place. Ensure all four legs are securely extended and the table is stable.
2. **Extend Table Legs (if applicable):** If your model includes leg extensions for increased height, insert them into the bottom of each main table leg until they snap securely.
3. **Attach the Side Table:** The side table unit folds out like an accordion. Extend its frame and attach it to the main table using the designated connection points. Ensure the side table is firmly secured to the main unit.
4. **Install Crossbars:** Insert the crossbars into the side table frame. These bars provide support for your stove or cooler and allow for width adjustment to fit various appliances.
5. **Set Up Utensil Hooks and Lantern Pole:** On the back edge of the main table, locate the slots for the utensil hook assembly and the lantern pole. Assemble the utensil hooks and slide them into their designated slots. For the lantern pole, connect the sections and insert the base into its slot, securing it with the provided strap.



Figure 2: The camp kitchen folds compactly into a case for easy transport and storage.



Figure 3: The camp kitchen fully set up, demonstrating the side table for a stove and the lantern pole.

Operating Instructions

The Coleman Pack-Away Portable Camp Kitchen provides a versatile workspace for your outdoor cooking needs.

- **Food Preparation:** Utilize the main table's 31.5 x 21.3-inch surface for chopping ingredients, mixing, and general food preparation. Its sturdy design ensures a reliable workspace.

- **Cooking Area:** Place your Coleman stove or cooler on the 27.8 x 20.5-inch side table. The adjustable crossbars allow for a secure fit for various sizes. Ensure your cooking appliance is stable before operation.
- **Storage and Organization:** Hang cooking utensils, towels, or other small items on the integrated utensil hooks. The mesh shelf beneath the main table offers additional space for storing non-perishable items or lightweight gear, keeping your workspace tidy.
- **Lighting:** Attach a lantern to the top of the lantern pole to illuminate your cooking area during evening hours.



Figure 4: The camp kitchen in action, providing a dedicated space for cooking and food preparation.



Figure 5: The portable kitchen offers ample space for multiple users to prepare and cook meals outdoors.

Maintenance

Proper maintenance will extend the life of your camp kitchen.

- **Cleaning:** After each use, wipe down all surfaces with a damp cloth and mild soap. Rinse thoroughly and dry completely before folding and storing to prevent corrosion and mildew.
- **Storage:** Store the camp kitchen in a dry, cool place away from direct sunlight. Ensure it is completely dry to prevent damage to the materials.
- **Inspection:** Periodically inspect all joints, hinges, and fasteners for any signs of wear or damage. Tighten any loose screws.

Troubleshooting

Issue	Possible Cause	Solution

Issue	Possible Cause	Solution
Table feels flimsy or unstable.	Legs not fully extended or locked; uneven ground.	Ensure all legs are fully extended and the locking mechanisms are engaged. If on uneven ground, try to find a flatter surface or use shims under the legs for stability.
Difficulty folding/unfolding.	Hinges or joints may be stiff or obstructed.	Check for any obstructions. Apply a small amount of silicone lubricant to hinges if they are stiff.
Damage during transport.	Improper packing or heavy items placed on top.	Always ensure the unit is securely packed and avoid placing excessively heavy or sharp objects on top of the folded kitchen during transport. Consider a protective bag if available.

Specifications

Brand: Coleman

Model Name: 2000020276

Product Dimensions: 11"D x 31.5"W x 4"H (folded)

Item Weight: 6.08 Kilograms

Frame Material Type: Metal (Aluminum)

Top Material Type: Aluminum, Medium-density fiberboard

Base Type: Folding

Is Foldable: Yes

Included Components: KITCHEN PACK-AWAY OUTDOOR C002

Indoor Outdoor Usage: Outdoor

Warranty & Support

The Coleman Pack-Away Portable Camp Kitchen comes with a manufacturer warranty. For specific details regarding your warranty coverage, please refer to the documentation included with your product or visit the official Coleman website. Additionally, protection plans are available for extended coverage:

- 2-Year Protection Plan
- 3-Year Protection Plan
- Complete Protect (monthly renewal option)

For further assistance, product support, or to inquire about replacement parts, please contact Coleman customer service.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question