Paulmann 71076

Paulmann 71076 Selection Bathroom Luena Wall Lamp Instruction Manual

Model: 71076

1. INTRODUCTION

Thank you for choosing the Paulmann 71076 Selection Bathroom Luena Wall Lamp. This manual provides important information regarding the installation, operation, and maintenance of your new wall lamp. Please read these instructions carefully before installation and keep them for future reference. This product is designed for indoor use, specifically in bathrooms and other damp areas, thanks to its IP44 splash water protection rating.

2. SAFETY INSTRUCTIONS

- **Electrical Safety:** Installation must be carried out by a qualified electrician in accordance with local wiring regulations. Ensure the main power supply is switched off before commencing any installation or maintenance work.

- **Voltage:** This lamp operates on 230V AC.

- **Bulb Type:** Use only E14 bulbs with a maximum wattage of 20W. Do not exceed the specified wattage.

- **IP44 Rating:** This product is splash-proof (IP44) and suitable for use in bathroom zones 2 and 3. Do not install in zone 1 (inside the shower or bath).

- **Handling:** Handle glass components with care to prevent breakage.

- **Cleaning:** Disconnect power before cleaning. Use a soft, dry cloth. Do not use abrasive cleaners or solvents.

Figure 2.1: IP Protection Zones in a Bathroom. The Paulmann 71076 lamp is suitable for IP44 zones.

3. Package Contents

Please check that all components are present and undamaged before installation:

- Paulmann 71076 Selection Bathroom Luena Wall Lamp fixture
- Mounting instructions
- Mounting hardware (screws, wall plugs)

Note: The light bulb (E14, max. 20W) is not included and must be purchased separately.

4. Setup and Installation

Follow these steps for proper installation:

1. **Prepare the Installation Site:** Ensure the power supply to the installation area is switched off at the main circuit breaker.
2. **Mark Drilling Points:** Hold the lamp's mounting plate against the wall at the desired installation height and mark the drilling points.
3. **Drill Holes:** Drill holes at the marked points and insert appropriate wall plugs.
4. **Connect Wiring:** Connect the lamp's wires to the 230V wall outlet wiring. Ensure correct polarity (Live, Neutral, Earth). Secure connections properly.
5. **Mount the Fixture:** Attach the lamp's mounting plate to the wall using the provided screws.
6. **Install the Bulb:** Carefully screw an E14 bulb (max. 20W) into the lamp holder.
7. **Attach Glass Shade:** The bayonet glass shade can be attached and removed without tools. Align the glass shade with the fixture and twist to secure it.

8. **Restore Power:** Once installation is complete and all components are securely in place, restore power at the main circuit breaker.

Figure 4.1: Close-up of the lamp's chrome base and glass shade, showing mounting points.

Figure 4.2: Product dimensions for installation planning.

5. Operating Instructions

Once installed and powered, the Paulmann 71076 wall lamp operates via your standard wall switch. If a dimmable E14 bulb is used and connected to a compatible dimmer switch, the light intensity can be adjusted. The lamp provides decorative light effects, enhancing the ambiance of your bathroom.

Luena Wandleuchte
Leuchtmittel frei wählbar

E14-Fassung

Je nach Wahl dimmbar

Figure 5.1: The E14 bulb socket, ready for bulb insertion.

Figure 5.2: The Paulmann Luena Wall Lamp in an installed setting.

6. MAINTENANCE

To ensure the longevity and appearance of your Paulmann wall lamp, follow these maintenance guidelines:

- **Cleaning:** Always switch off the power supply before cleaning. Use a soft, dry, or slightly damp cloth to wipe the chrome finish and glass shade. Avoid harsh chemicals, abrasive cleaners, or scouring pads, as these can damage the surfaces.

- **Bulb Replacement:** Ensure the power is off and the bulb has cooled down before attempting to replace it. The bayonet glass shade can be easily removed without tools to access the E14 bulb.

- **Inspection:** Periodically check the lamp for any signs of damage or loose connections. If any issues are found, disconnect power and consult a qualified electrician.

Figure 6.1: The bayonet glass shade can be removed without tools for easy bulb replacement and cleaning.

7. TROUBLESHOOTING

If you encounter issues with your Paulmann 71076 wall lamp, consider the following:

- **Lamp does not light up:**

  - Check if the power supply is switched on at the wall switch and the main circuit breaker.
  - Ensure the bulb is correctly screwed in and not faulty. Try replacing the bulb with a new one.
  - Verify that the wiring connections are secure. If unsure, consult a qualified electrician.

- **Light flickers:**
  - Ensure the bulb is fully tightened.
  - If using a dimmable bulb, ensure it is compatible with your dimmer switch.
  - Check for loose wiring connections.
- **Glass shade is loose:**
  - Ensure the bayonet glass shade is properly aligned and twisted into its locked position.

If problems persist, contact Paulmann customer support or a qualified electrician.

8. SPECIFICATIONS

Feature	Specification
Model Number	71076
Brand	Paulmann
Product Dimensions	12.5 cm (L) x 10 cm (W) x 22 cm (H)
Item Weight	850 Grams
Material	Glass, Chrome
Color	Chrome, Glass
Finish	Chrome
Style	Modern/Minimalist
Room Type	Bathroom
Specific Use	Bathroom
Indoor/Outdoor Use	Indoor
Power Source	AC
Voltage	230V
Bulb Type	E14 (not included)
Max. Wattage	20W
Dimmable	Yes (with compatible bulb and dimmer)
IP Rating	IP44 (Splash-proof)
Certifications	CE
Batteries Required	No

9. WARRANTY AND SUPPORT

Paulmann products are manufactured to high-quality standards and come with a manufacturer's warranty.

For specific warranty terms and conditions, please refer to the documentation provided with your purchase or visit the official Paulmann website. For technical support, spare parts, or any questions not covered in this manual, please contact Paulmann customer service directly.