TOKIT TFB014

TOKIT Rice Cooker Pro 1.5L Instruction Manual

Model: TFB014

1. Product Overview

The TOKIT Rice Cooker Pro 1.5L is a compact and versatile appliance designed for efficient cooking of rice and other dishes. Its touch-sensitive operation and ceramic non-stick inner pot simplify meal preparation and cleaning. This rice cooker is suitable for 1 to 3 persons.

Key Features:

- **Touch-Sensitive Operation:** Start cooking by gently pressing the lid.
- **1.5L Capacity:** Cooks up to 3 cups of rice, ideal for 1-3 servings.
- **Ceramic Non-Stick Inner Pot:** Ensures easy cleaning and prevents food from sticking.
- **Multi-functional:** Capable of cooking rice, porridge, soups, steaming, and keeping food warm.
- **Compact Design:** Space-saving for any kitchen countertop.



Image 1.1: TOKIT Rice Cooker Pro 1.5L in Avocado Green.

2. Safety Instructions

Please read all safety instructions carefully before using the appliance to prevent injury or damage.

- Always ensure the voltage of your power outlet matches the rating label on the appliance.
- Do not immerse the main unit, power cord, or plug in water or any other liquid.
- Keep the appliance out of reach of children.
- Do not operate the appliance if the power cord or plug is damaged, or if the appliance malfunctions or has been damaged in any way.
- Place the rice cooker on a stable, heat-resistant surface, away from direct heat sources or flammable materials.
- Ensure proper ventilation around the appliance during operation. Do not block steam vents.
- Use only the inner pot provided with the appliance.
- Avoid touching hot surfaces during and immediately after operation. Use oven mitts if necessary.

- Unplug the appliance from the power outlet when not in use and before cleaning.

3. Setup

3.1 Unpacking

Carefully remove all packaging materials and check for any damage. Retain packaging for future transport or storage if needed.

3.2 Initial Cleaning

Before first use, wash the inner pot, rice paddle, and measuring cup with warm, soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the rice cooker with a damp cloth.

3.3 Placement

Place the rice cooker on a flat, stable, and dry surface. Ensure there is adequate space around the unit for ventilation, especially above the steam vent.

3.4 Connecting Power

Plug the power cord into the designated port on the rice cooker, then into a suitable electrical outlet. The display will illuminate.



Image 3.1: Connecting the power cord to the rice cooker.

4. Operating Instructions

4.1 Basic Rice Cooking

1. **Measure Rice:** Use the provided measuring cup to measure the desired amount of rice. Rinse the rice thoroughly under cold water until the water runs clear.
2. **Add Water:** Place the rinsed rice into the inner pot. Add the appropriate amount of water according to the rice type and desired consistency. A common ratio is 1 cup of rice to 1.5 cups of water, but refer to specific rice package instructions.
3. **Insert Inner Pot:** Place the inner pot securely into the main unit of the rice cooker.
4. **Close Lid:** Close the lid firmly.
5. **Start Cooking:** After plugging in the unit, wait approximately 7 seconds for the system to initialize. Then, gently press the center of the lid to begin the cooking cycle. The display will show the selected cooking mode and remaining time. If you press the lid within 7 seconds of plugging in, the lid may open automatically.



Image 4.1: One-tap cooking process illustration.

4.2 Cooking Modes and Functions

The TOKIT Rice Cooker offers various cooking modes accessible via the touch display:

- **Regular Rice:** Standard cooking mode for fluffy rice (approx. 60 minutes for 2-3 cups).
- **Quick Rice:** Faster cooking for smaller quantities (recommended for 1 cup of rice, approx. 28 minutes). For 2-3 cups, the program may adjust time multiple times to ensure proper cooking.
- **Brown Rice:** Optimized for cooking brown rice.
- **Congee:** For preparing congee or rice porridge.
- **Soup:** For cooking various soups.
- **Hotpot:** For hotpot dishes.
- **Steam:** For steaming vegetables or other foods.
- **Warm:** Keeps cooked food warm for an extended period (up to 12 hours).
- **Timer:** Allows you to set a delayed start time for cooking.

Use the 'SELECT/CANCEL' button to cycle through modes and the 'TIMER' button to set a delayed start.



Image 4.2: Digital display showing available cooking modes.



Image 4.3: Quick vs. Regular Rice Cooking times and results.

5. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your rice cooker.

5.1 Cleaning the Inner Pot and Lid

The ceramic non-stick inner pot and the removable top lid should be cleaned after each use. Hand washing is recommended for the inner pot to preserve its non-stick coating, as indicated in the product specifications. However, some product images suggest dishwasher compatibility for the inner pot and lid. For best results and longevity, hand wash with warm, soapy water and a soft sponge. Rinse thoroughly and dry completely before storing.



Image 5.1: Inner pot and lid in a dishwasher rack, illustrating ease of cleaning.

5.2 Cleaning the Exterior

Wipe the exterior of the rice cooker with a damp cloth. Do not use abrasive cleaners or scourers, as these can damage the surface. Ensure no water enters the electrical components.

5.3 Storage

Store the rice cooker in a dry place when not in use. Ensure all parts are clean and dry before storage.

6. Troubleshooting

- **Appliance does not start:** Ensure the power cord is securely plugged into both the rice cooker and the wall outlet. Remember to wait approximately 7 seconds after plugging in before pressing the lid to start cooking.
- **Cooking time adjusts during Quick Cook mode:** This is normal behavior when cooking 2 or 3 cups of rice in Quick Cook mode. The rice cooker automatically adjusts the time to ensure proper cooking. For best results with

larger quantities, use the Regular Rice mode.

- **Liquid overflows from the lid:** This can occur if too much water is added, or if the rice is not rinsed sufficiently, leading to excess starch. Ensure you follow recommended water-to-rice ratios and rinse rice thoroughly.
- **Rice sticks to the inner pot:** Although the inner pot has a non-stick ceramic coating, ensure you are using the correct water-to-rice ratio. Avoid using metal utensils that could scratch the coating.
- **Rice is undercooked or overcooked:** Adjust the water-to-rice ratio. Different types of rice may require slightly different amounts of water. Ensure the lid is properly closed during cooking.

If you encounter issues not listed here or if problems persist, please contact TOKIT customer support.

7. Specifications

Feature	Specification
Model Number	TFB014
Capacity	1.5 Liters (up to 3 cups of rice)
Power	350 Watts
Voltage	220 Volts
Dimensions (L x W x H)	20P x 20l x 20H cm
Inner Pot Material	Ceramic (non-stick coating)
Lid Material	Stainless Steel
Special Feature	Touch-sensitive start
Care Instructions	Hand wash
Included Components	Measuring cup, Rice paddle
Country of Origin	China

8. Warranty and Support

For warranty information, please refer to the warranty card included with your product or visit the official TOKIT website. If you require technical assistance, have questions about product operation, or need to report a defect, please contact TOKIT customer support through their official channels.

Keep your purchase receipt as proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question