COSYLUX 5 rings floorlamp

COSYLUX 5-Ring LED Dimmable Floor Lamp User Manual

Model: 5 rings floorlamp

1. Introduction

Thank you for choosing the COSYLUX 5-Ring LED Dimmable Floor Lamp. This modern and versatile lighting solution is designed to enhance your living space with its unique aesthetic and functional features. This manual provides essential information for safe assembly, operation, and maintenance of your new lamp.



Image 1.1: COSYLUX 5-Ring LED Dimmable Floor Lamp

The lamp features five interconnected LED rings, offering 3-way dimmable brightness and a 2-in-1 design that allows it to function as both a floor lamp and a tall table lamp. Its energy-efficient LED technology provides bright, diffused light suitable for various rooms.

2. Safety Instructions

- Read all instructions before assembly and use.
- Do not connect the lamp to power until fully assembled.
- Ensure the power cord is not pinched or damaged during assembly or placement.
- This lamp is for indoor use only. Do not expose to water or high humidity.
- Do not attempt to modify or repair the lamp. Contact customer support for assistance.
- Keep the lamp away from flammable materials.
- The LED light source is integrated and not replaceable.

3. Package Contents

Please check that all components are present and undamaged:

- Lamp Base (1)
- Lower Lamp Section (3 rings) (1)
- Upper Lamp Section (2 rings) (1)
- Power Adapter with Foot Switch (1)
- Assembly Screws (pre-attached or in a small bag)



Image 3.1: Lamp Components Overview

4. Assembly Instructions

Follow these steps to assemble your COSYLUX 5-Ring LED Dimmable Floor Lamp:

1. **Attach the Lamp Base:** Carefully align the Lamp Base with the bottom of the Lower Lamp Section. Secure it using the provided screws. Ensure it is tightened firmly to prevent wobbling.
2. **Connect Lamp Sections:** Take the Upper Lamp Section and align its detachable pin connector with the corresponding slot on the top of the Lower Lamp Section. Gently push and twist to secure the connection. Ensure the electrical connection is firm to prevent flickering.
3. **Connect Power Adapter:** Plug the power adapter into the lamp's power input port, usually located near the base.

4. **Position the Lamp:** Place the assembled lamp in your desired location, ensuring the power cord is not obstructed.
5. **Plug into Outlet:** Plug the power adapter into a standard electrical outlet.

Converting to a Tall Table Lamp (2-in-1 Feature)

The top two rings of the lamp are detachable, allowing you to use the lower three rings as a tall table lamp:

1. **Disconnect Power:** Unplug the lamp from the electrical outlet before making any changes.
2. **Detach Upper Section:** Gently twist and pull the Upper Lamp Section (2 rings) from the Lower Lamp Section (3 rings) at the detachable pin connector.
3. **Use as Table Lamp:** The Lower Lamp Section (3 rings) can now be placed on a table. Reconnect the power adapter to this section and plug it into an outlet.



Image 4.1: 2-in-1 Floor and Table Lamp Conversion

5. Operating Instructions

The COSYLUX 5-Ring LED Dimmable Floor Lamp is operated using a built-in foot switch on the power cord.

- **Power On/Off:** Press the foot switch once to turn the lamp on.
- **Adjust Brightness (3-Way Dimmable):**
    a. First press: 100% brightness (Full strength)
    b. Second press: 50% brightness
    c. Third press: 25% brightness
    d. Fourth press: Turns the lamp off.



Image 5.1: 3-Level Dimmable Brightness

6. Maintenance

- **Cleaning:** Disconnect the lamp from power before cleaning. Use a soft, dry cloth to wipe the lamp's surface. Do not use abrasive cleaners or solvents.
- **Storage:** If storing the lamp, ensure it is clean and dry. Store in a cool, dry place away from direct sunlight.

7. Troubleshooting

Problem	Possible Cause	Solution
Lamp does not turn on.	Not plugged in; loose connection; power outage.	Ensure power adapter is securely plugged into both the lamp and the wall outlet. Check if the outlet is functional.

Problem	Possible Cause	Solution
Light flickers or is intermittent.	Loose connection between lamp sections or power adapter.	Unplug the lamp. Re-secure the connection between the upper and lower lamp sections. Ensure the power adapter is firmly connected to the lamp.
Foot switch not responding or dimming incorrectly.	Foot switch malfunction; power issue.	Ensure the lamp is receiving consistent power. If the issue persists, contact customer support.
Lamp feels wobbly after assembly.	Base not securely tightened.	Unplug the lamp. Re-tighten the screws connecting the lamp base to the lower section. Ensure all connections are firm.

8. Specifications

Feature	Specification
Model	5 rings floorlamp
Light Source	Integrated LED
Brightness	Up to 3260 Lumens
Color Temperature	6000K (Daylight White)
Dimmable	3-Way (25%, 50%, 100%)
Wattage	35 Watts
Voltage	100-240V (AC)
CRI	94.00
Lifetime	>50,000 hours
Product Dimensions (Floor Lamp)	7.9"D x 10.4"W x 46.5"H
Base Diameter	7.9 Inches
Material	Acrylic, Aluminum, Metal
Switch Type	Foot Touch Switch
Assembly Required	Yes
Item Weight	6.09 pounds



Image 8.1: Product Dimensions

9. Warranty and Support

Every COSYLUX product undergoes inspection before leaving the factory to ensure quality standards are met. If you encounter any defects with your lamp or are not satisfied with your purchase, you may return or exchange it free of charge. Please contact COSYLUX customer support for assistance.
For further inquiries or support, please visit the official COSYLUX store or contact your retailer.

COSYLUX Store: Visit COSYLUX on Amazon