Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TURNMEON NEW-Black

TURNMEON 12 Ft Inflatable Black Santa Sleigh with Reindeer

Outdoor Christmas Decoration Instruction Manual

Introduction

Thank you for choosing the TURNMEON 12 Ft Inflatable Black Santa Sleigh with Reindeer. This festive outdoor decoration is designed to bring joy to your yard, lawn, or garden during the Christmas season. Featuring built-in LED lights, this inflatable creates a vibrant display. Please read this manual carefully before setup and operation to ensure safe and proper use.

Safety Information

WARNING: To reduce the risk of fire, electric shock, or injury, always follow these safety precautions:

- Always follow the manufacturer's instructions for proper inflation and anchoring.
- Keep the inflatable away from heat sources and open flames.
- Do not operate in high winds.
- Unplug the inflatable before inflating or deflating.
- Do not use if damaged.
- Ensure all electrical connections are dry and protected from moisture.
- This product is for temporary outdoor use during the holiday season. Do not leave it inflated for extended periods.

Package Contents

Before beginning assembly, verify that all parts are present and in good condition. The package should include:

- 1 x 12 Ft Inflatable Black Santa Sleigh with Three Reindeer
- 1 x Power Adaptor (0.7A fan and 12V adapter with UL certification)
- 1 x Rope
- 12 x Plastic Ground Stakes
- 2 x Sandbags (empty, for filling)



Figure 1: Product dimensions and included accessories.

Setup Instructions

Follow these steps to set up your inflatable decoration:

1. **Choose a Location:** Select a flat, clear area in your yard or garden, away from sharp objects, heat sources, and overhead power lines. Ensure the area is large enough for the 12 ft (L) x 4.5 ft (H) inflatable.
2. **Unpack and Unfold:** Carefully remove the inflatable from its packaging and unfold it completely on the chosen surface. Ensure the fabric is not twisted or obstructed.

3. **Connect Power:** Locate the inflatable fan and connect the power adaptor. Ensure the zipper at the bottom of the inflatable is closed before plugging it in.
4. **Inflate:** Plug the power adaptor into a suitable outdoor-rated electrical outlet. The inflatable will begin to self-inflate within minutes.
5. **Secure the Inflatable:** Once fully inflated, secure the decoration using the provided stakes, ropes, and sandbags. This is crucial for stability, especially in windy conditions.
    - **Method 1 (Stakes and Tethers):** Attach the ropes to the tether points on the inflatable. Drive the plastic ground stakes into the ground at an angle, away from the base of the inflatable, and tie the ropes securely to the stakes. Adjust tension to keep the inflatable upright.
    - **Method 2 (Sandbags):** Fill the provided sandbags with sand (or water bottles for weight) and place them inside the base of the inflatable through the zipper opening. Close the zipper securely. This adds internal weight for stability.



Figure 2: Two methods for securing the inflatable.



Figure 3: Key components for setup: power supply, fan, zipper, and tether.

Your browser does not support the video tag.

Video 1: Demonstration of the inflatable Black Santa and Reindeer in an outdoor setting, showcasing its appearance and illumination.

Operating Instructions

Operating your inflatable decoration is straightforward:

- **To Inflate:** Ensure the power adaptor is securely connected to the fan and the zipper is closed. Plug the adaptor into a standard electrical outlet. The inflatable will automatically inflate and the internal LED lights will illuminate.
- **To Deflate:** Unplug the power adaptor from the electrical outlet. For faster deflation, open the zipper located at the bottom of the inflatable.
- **Night Operation:** The built-in LED lights are designed to provide illumination, making the inflatable visible and festive during nighttime hours.



Figure 4: The inflatable illuminated at night.

Maintenance

Proper care will extend the life of your inflatable decoration:

- **Cleaning:** If the inflatable becomes dirty, wipe it gently with a damp cloth. Do not use harsh chemicals or

abrasive cleaners. Ensure it is completely dry before storing.

- **Storage:** After the holiday season, ensure the inflatable is completely deflated and dry. Fold it neatly and store it in its original packaging or a suitable storage bag in a cool, dry place, away from direct sunlight and pests.
- **Inspection:** Periodically inspect the fabric, fan, power cord, and stakes for any signs of wear or damage. Replace any damaged components immediately.

Troubleshooting

If you encounter issues with your inflatable, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Inflatable does not inflate	Power not connected; Zipper open; Fan obstructed; Damaged fan/adaptor	Ensure adaptor is plugged in and outlet is working. Check if the zipper is fully closed. Clear any obstructions from the fan. If damaged, contact support.
Inflatable does not stand upright	Insufficient anchoring; High winds; Uneven surface	Re-secure with all stakes and ropes. Add more weight with sandbags. Move to a more sheltered location or deflate in high winds. Ensure placement on a flat surface.
LED lights not working	Power issue; Damaged lights	Check power connection. If lights are damaged, contact support.
Slow inflation	Partial obstruction of fan; Small tear in fabric	Check fan for debris. Inspect fabric for small tears and patch if necessary.

Specifications

- **Brand:** TURNMEON
- **Model Number:** NEW-Black
- **Theme:** Christmas
- **Character:** Black Santa Claus On Sleigh with Three Reindeer
- **Color:** Colorful (Cool White LED lights)
- **Material:** Thickened Waterproof Polyester Fabric
- **Item Dimensions (Inflated):** Approximately 144 inches (12 ft) Long x 45 inches (4.5 ft) High
- **Power:** 0.7A fan with 12V UL certified adaptor
- **Features:** Self-inflating, Built-in LED Lights, Easy Setup

Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact TURNMEON customer service directly. Keep your purchase receipt for warranty claims.
Contact Information: Please visit the official TURNMEON website or refer to your product documentation for the most current customer support contact details.

© 2023 TURNMEON. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CBKC8SDV

More documents and user manuals: **https://manuals.plus/**