Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

iJoy Stitch Speaker

iJoy Disney Lilo and Stitch Wireless Bluetooth Speaker User Manual

Model: Stitch Speaker | Brand: iJoy

Introduction

Thank you for purchasing the iJoy Disney Lilo and Stitch Wireless Bluetooth Speaker. This portable and splashproof speaker is designed to provide high-quality audio and versatile connectivity options, including Bluetooth, SD card, and FM radio. It features a built-in microphone for hands-free calling and a rechargeable battery for on-the-go use. This manual will guide you through the setup, operation, and maintenance of your new speaker.

What's in the Box

- Bluetooth Speaker
- USB Charging Cable
- Backup AUX Cable
- Owners Manual

Product Overview



Figure 1: Front view of the iJoy Disney Lilo and Stitch Wireless Bluetooth Speaker, showcasing the Stitch character design.



Figure 2: Top view of the speaker revealing the various ports: AUX input, SD card slot, USB port, and Micro USB charging port. These ports are protected by a rubber flap for splash resistance.



Figure 3: Top panel showing the control buttons: Volume Down (-), Play/Pause/Call Answer, Mode (M), Power On/Off, and Volume Up (+). A blue LED indicator light is also visible.



Figure 4: Illustration of the speaker's compact dimensions, approximately 6.3 inches tall and 2.9 inches across, highlighting its portability.

Setup

Charging the Speaker

Before first use, fully charge your speaker. Locate the Micro USB charging port under the rubber flap on the top of the speaker (refer to Figure 2). Connect the supplied USB charging cable to the speaker and the other end to a USB power source (e.g., computer USB port, USB wall adapter). The LED indicator light will illuminate during charging and turn off when fully charged. A full charge takes approximately 2 hours and provides up to 3 hours of playtime.

Powering On/Off

To power on the speaker, press and hold the Power On/Off button (refer to Figure 3) for a few seconds until you hear an audible prompt and the LED indicator light illuminates. To power off, press and hold the Power On/Off button again until the speaker turns off.

Operating Instructions

Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (the LED indicator light may flash).
2. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
3. Select "Stitch Speaker" or a similar name from the list of found devices.
4. Once paired, the speaker will provide an audible confirmation, and the LED indicator light will remain solid.
5. The speaker will automatically attempt to reconnect to the last paired device when powered on.

Music Playback

- **Play/Pause:** Press the Play/Pause button (refer to Figure 3) to play or pause audio.
- **Volume Control:** Press the Volume Up (+) button to increase volume and the Volume Down (-) button to decrease volume.
- **Next/Previous Track:** (Information not explicitly provided in JSON for track control, assuming long press of volume buttons or not available via speaker controls). *Please refer to the included Owners Manual for specific track navigation instructions if available.*

Hands-Free Calling

When connected via Bluetooth to a smartphone, the speaker's built-in microphone allows for hands-free calling.

- **Answer/End Call:** Press the Play/Pause button to answer an incoming call or end an ongoing call.
- **Reject Call:** Press and hold the Play/Pause button to reject an incoming call.

Mode Switching (FM Radio / SD Card / AUX)

The speaker supports multiple audio input modes. Press the 'M' (Mode) button (refer to Figure 3) to cycle through available modes: Bluetooth, FM Radio, SD Card, and AUX input.

- **FM Radio:** In FM mode, the speaker will automatically scan and save available stations. Use the volume buttons to navigate between stations (functionality may vary, refer to full manual).
- **SD Card:** Insert a microSD card with audio files into the SD card slot (refer to Figure 2). The speaker will automatically play audio from the card.
- **AUX Input:** Connect an external audio device using the supplied AUX cable to the AUX port (refer to Figure 2).

Maintenance

Cleaning

Wipe the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents. Ensure all ports are dry before charging or connecting cables.

Water Resistance

The speaker is IPX4 splashproof, meaning it can withstand splashes of water from any direction. It is not designed to be submerged in water. Ensure the rubber flap covering the ports is securely closed to maintain splash resistance.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is depleted.	Charge the speaker fully using the provided USB cable.
No sound from speaker.	Volume is too low or muted. Device not paired correctly. Incorrect mode selected.	Increase volume on both speaker and connected device. Re-pair the Bluetooth device. Press 'M' button to switch to correct input mode.
Bluetooth pairing fails.	Speaker is too far from device. Speaker is already paired to another device. Bluetooth on device is off.	Ensure speaker and device are within 30 feet. Disconnect from other devices. Turn Bluetooth on/off on your device and try again.
Poor FM radio reception.	Weak signal.	Move the speaker to a location with better signal.

Specifications

Feature	Detail
Model Name	Stitch Speaker
Speaker Type	Tower
Special Features	Portable, LED Indicator Lights, Built-in Microphone
Recommended Uses	Cellular Phone, Watches, Smartphones, Tablets
Compatible Devices	iPhone, Universally Compatible With All Bluetooth Enabled Devices, Tablet, Smartphone, Android
Controller Type	Button
Surround Sound Channel Configuration	2.0
Color	Stitch "Cute"
Battery Life	3 Hours
Product Dimensions	3"D x 3"W x 6"H
Item Weight	8 Ounces
Waterproof Rating	IPX4 (Water Resistant)
Battery Capacity	800 Milliamp Hours
Charging Time	2 Hours
Maximum Range	30 Feet (Bluetooth)
Number of Items	1
Control Method	Touch (Buttons)

Feature	Detail
Wireless Communication Technology	Bluetooth
Speaker Size	6 Inches (Audio Driver Size)
Power Source	Battery Powered
Number of Batteries	1 Product Specific (included)
Audio Driver Type	Dynamic Driver
Number of Microphones	1
Connectivity Protocol	Bluetooth
UPC	810116713936
Manufacturer	Quest USA Corp
Date First Available	July 10, 2023
Country of Origin	China
Audio Output Mode	Stereo
Input Voltage	5 Volts
Mounting Type	Tabletop Mount

Warranty Information

This iJoy Disney Lilo and Stitch Wireless Bluetooth Speaker comes with a**90 Day Manufacturer Warranty**. Please retain your proof of purchase for warranty claims. For specific terms and conditions, refer to the detailed warranty information provided with your product or contact customer support.

Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact iJoy customer support. Refer to the contact information provided in the original product packaging or visit the official iJoy website for the most up-to-date support details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CBL3XFT3

More documents and user manuals: **https://manuals.plus/**