**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**ALLIMITY QYSY-OplayMini-QYSY**

# ALLIMITY Replacement Remote Control User Manual

Model: QYSY-OplayMini-QYSY

## Introduction

This user manual provides instructions for the ALLIMITY Replacement Remote Control, model QYSY-OplayMini-QYSY. This remote is designed to replace your original remote for various ASUS Media Player models, including Oplay-Mini, O!Play Mini, Oplay 021, O!Play-Mini, Oplay021, and Oplay Mini. It offers full functionality without the need for programming.

## Setup

### Battery Installation

The remote control requires two AAA alkaline batteries (not included). Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover securely.

Once batteries are installed, the remote is ready for immediate use with compatible devices, as no programming is required.




Image: Side view of the ALLIMITY replacement remote control, highlighting its ergonomic shape and button layout from an angle.

## Operating Instructions

This ALLIMITY remote control is designed to function identically to your original ASUS Media Player remote. Simply point the remote at your media player and press the desired buttons.

### Key Functions:

- **Power Button:** Turns the media player on or off.
- **Navigation Pad (Up, Down, Left, Right, OK):** Used to navigate menus and confirm selections.
- **Volume Buttons (+/-):** Adjusts the audio volume.
- **Mute Button:** Mutes or unmutes the audio.
- **Playback Controls (Play/Pause, Stop, Fast Forward, Rewind, Next, Previous):** Controls media playback.
- **Guide Button:** Accesses the program guide (if supported by your media player).
- **Option Button:** Opens context-sensitive options menus.

- **Return/Back Button:** Returns to the previous screen or menu.
- **Zoom Button:** Adjusts screen zoom.
- **Edit Button:** Accesses editing functions.

Ensure there are no obstructions between the remote control and the media player's infrared receiver for optimal performance. The maximum operating range is approximately 10 meters.






Image: Front view of the ALLIMITY replacement remote control, displaying the full layout of all buttons and their labels.

## Maintenance

### Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the remote's finish or internal components.

### Battery Care

- Replace batteries when the remote's responsiveness decreases or it stops functioning.
- Remove batteries if the remote control will not be used for an extended period to prevent battery leakage.
- Dispose of used batteries according to local regulations.




Image: Angled view of the ALLIMITY replacement remote control, providing a different perspective of its design and button layout.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Remote not responding. | • Dead or incorrectly inserted batteries.<br>• Obstruction between remote and media player.<br>• Remote is out of range. | • Replace batteries with new alkaline batteries, ensuring correct polarity.<br>• Remove any objects blocking the line of sight between the remote and the media player.<br>• Move closer to the media player (within 10 meters). |

| Problem | Possible Cause | Solution |
|---|---|---|
| Certain buttons not working. | • Dirty contacts under the button.<br>• Button malfunction. | • Ensure the remote is clean.<br>• If the issue persists, contact customer support. |

## Specifications

- **Brand:** ALLIMITY
- **Model Number:** QYSY-OplayMini-QYSY
- **Connectivity Technology:** Infrared
- **Compatible Devices:** ASUS Media Player Oplay-Mini, O!Play Mini, Oplay 021, O!Play-Mini, Oplay021, Oplay Mini
- **Special Feature:** No programming required
- **Maximum Range:** 10 Meters
- **Battery Description:** Alkaline (AAA, not included)

## Warranty and Support

Information regarding specific warranty terms and direct customer support contacts for this product is not available in this manual. Please refer to the seller or your purchase documentation for warranty details and support inquiries.

© 2023 ALLIMITY. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

**Open the live page**

**https://manuals.plus/asin/B0CBRRFBJQ**

More documents and user manuals: **https://manuals.plus/**